






Tiller/Cultivator

OWNER'S MANUAL



WELCOME TO THE WORLD OF MANTIS GARDENING!

Here's your new Mantis Tiller/Cultivator . . . the lightweight wonder that's "Changing the Way Americans Garden."[®]

Unlike big tillers, your Mantis Tiller weighs only 20 pounds. So it lifts easily, handles smoothly, tills and weeds precisely. And, unlike other small tillers, it features serpentine tines that churn soil to ten inches deep. It creates a soft, smooth seed bed, even in problem soil.

Once you know how to use your tiller correctly, we guarantee you'll love it. So first, please read this manual. It shows, step by step, how to use your tiller safely. Plus, it shows how the Mantis Border Edger can make light work of your edging needs.

If you have questions about any topic in this Manual, or if you wish to order Mantis Attachments, contact your local authorized Mantis dealer.



TABLE OF CONTENTS

Safety Rules & Warnings	3-5
Safety Decals	4
Engine & Fuel Warnings	5
Assembly and Mixing Fuel	6-9
Starting	10-11
Additional Information	11
What to Do Just in Case	12-13
Getting to Your Garden	13
Tilling & Cultivating	14-16
Tine Positioning	16-17
Cultivating	16

Maintenance	17-20
Storage	21-22
Trouble Shooting & Specifications	23-24
Service Maintenance Guide	25
Using The Border/Edger Attachment	26
Mantis Tiller Assembly Layout	27
Engine Parts Assemblies	28-29
Notes	30
The Mantis Promise	31
Limited Warranty Information	32

SAFETY RULES & WARNINGS

You will notice throughout this Owners Manual **Safety Rules and Important Notes**. Make sure you understand and obey these warnings for your own protection.

I. Special Safety Information

⚠ WARNING • DANGER ⚠
**ATTENTION: THIS SYMBOL POINTS OUT
OUR IMPORTANT SAFETY INSTRUCTIONS.**

**WHEN YOU SEE THIS SYMBOL, ⚠
HEED IT'S WARNING!! STAY ALERT!!**

⚠ WARNING • DANGER ⚠
**TO REDUCE THE POTENTIAL FOR ACCIDENTS, COMPLY WITH
THE SAFETY INSTRUCTIONS IN THIS MANUAL.**


**FAILURE TO COMPLY MAY RESULT IN SERIOUS PERSONAL
INJURY, AND/OR EQUIPMENT AND PROPERTY DAMAGE.**

II. Safety & Warnings

⚠ WARNING • DANGER ⚠
**IMPROPER USE OR CARE OF THIS TILLER/CULTIVATOR
OR FAILURE TO WEAR PROPER PROTECTION
CAN RESULT IN SERIOUS INJURY.**
**READ AND UNDERSTAND THE RULES FOR SAFE OPERATION
AND ALL INSTRUCTIONS IN THIS MANUAL.**
WEAR HEARING AND EYE PROTECTION.

⚠ WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

III. Safety Decal Information



P/N 488M



P/N 4043

IMPORTANT ENGINE INFORMATION:

ENGINE FAMILY: SEH024UB24RD
DISPLACEMENT: 21.2cc
THIS ENGINE MEETS U.S.EPA PHI AND 1995-1998 CALIFORNIA EMISSION REGULATIONS FOR ULGE ENGINES. REFER TO OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS.

KIORITZ CORP. A98

EMISSION CONTROL --
The emission control system for this engine is EM (Engine Modification).

Emission Control Label
located on Engine, EXAMPLE ONLY, information on label varies by FAMILY).



CUTTING HAZARD;
KEEP FEET AND
HANDS AWAY FROM
ROTATING TINES.



DO NOT CARRY THE
TILLER IN THIS
POSITION.



READ OWNER'S MANUAL
BEFORE USING TILLER, OR
PERFORMING ANY REPAIR
OR MAINTENANCE. KEEP
OWNER'S MANUAL IN A
SAFE PLACE.



DON'T FUEL, REFUEL,
OR CHECK FUEL
WHILE SMOKING, OR
NEAR AN OPEN FLAME
OR OTHER IGNITION
SOURCE.




CAUTION: WHEN
ASSEMBLING THE HANDLES,
MAKE SURE FUEL TANK
FACES OPERATOR. THIS IS
THE REAR OF THE TILLER,
REFER TO ASSEMBLY
INSTRUCTION ON PAGE 7.



INCORRECT ASSEMBLY.



WEAR EAR AND EYE
PROTECTION.



MIX UNLEADED GAS
WITH 2 CYCLE 50:1
OIL.

⚠ WARNING • DANGER ⚠

**IF THE TILLER IS USED IMPROPERLY OR SAFETY PRECAUTIONS ARE NOT FOLLOWED,
THE USERS RISK SERIOUS INJURY TO THEMSELVES AND OTHERS.**

READ AND UNDERSTAND THIS MANUAL BEFORE ATTEMPTING TO OPERATE THIS TILLER.

IV. Warnings - Do's

Read and understand the owner's manual. Pay particular attention to all sections regarding safety.

1. Always keep a firm grip on both handles while the tines are moving and/or the engine is running. BE AWARE!! The tines may coast after throttle trigger is released. Make sure tines have come to a complete stop and engine is off before letting go of the tiller.

2. Always maintain a firm footing and good balance. Do not overreach while operating the tiller. Before you start to use the tiller check the work area for obstacles that might cause you to lose your footing, balance or control of the machine.

3. Always keep area clear of children, pets, and bystanders.

4. Always stay alert. Watch what you are doing and use common sense. Do not operate unit when fatigued.

5. Always dress properly. Do not wear loose clothing or jewelry, they might get caught in moving parts. Use sturdy gloves. Gloves reduce the transmission of vibration to your hands. Prolonged exposure to vibration can cause numbness and other ailments. Wear non-skid foot wear to ensure secure and proper footing.

6. Always wear ear and eye protection. Eye protection must meet ANSI Z 87.1. To avoid hearing damage, we recommend

hearing protection be worn whenever using the equipment.

7. Always keep a safe distance between two or more people when working together.

8. Always inspect your unit before each use and ensure that all handles, guards and fasteners are secure, operating, and in place.

9. Always maintain and examine your Tiller with care. Follow maintenance instructions given in manual.

10. Always store tiller in a sheltered area (a dry place), not accessible to children. The tiller as well as fuel should not be stored in a house.

V. Warnings - Don'ts

Don't use tiller with one hand. Keep both hands on handles with fingers and thumbs encircling the handles, while tines are moving, and engine is running.

Don't overreach. Keep a good footing at all times.

Don't attempt to clear tines

while they are moving. Never try to remove jammed material before switching the engine off and making sure the tines have stopped completely.

Don't allow children or incapable people to operate this tiller.

Don't operate while under the influence of alcohol or drugs.

Don't attempt to repair this tiller. Have repairs made by a qualified dealer or repairman. See that only original Mantis parts are used.

⚠ WARNING • DANGER ⚠

HANDLE FUEL WITH CARE, IT IS HIGHLY FLAMMABLE. FUELING A HOT ENGINE OR NEAR AN IGNITION SOURCE CAN CAUSE A FIRE AND RESULT IN SERIOUS PERSONAL INJURY AND/OR PROPERTY DAMAGE.

VI. Engine/Fuel Warnings - Do's

Always use fresh gasoline in the fuel mixture. Stale gasoline can cause damage.

Always pull starter cord slowly until resistance is felt. Then pull cord rapidly to avoid kickback and prevent arm or hand injury.

Always operate engine with spark arrestor installed and operating properly. The use of spark arrestor mufflers is required by law in the state of California (Section 4442 of the California Public Resources Code), as well as in other states

or municipalities. Federal laws apply on federal lands.

VII. Engine/Fuel Warnings - Don'ts

Don't fuel, refuel or check fuel while smoking, or near an open flame or other ignition source. Stop engine and be sure it is cool before refueling.

Don't leave the engine running while the tiller is unattended. Stop engine before putting the tiller down or while transporting from one place to another.

Don't refuel, start or run this tiller indoors or in an improperly ventilated area.

Don't run engine when

electrical system causes spark outside the cylinder. During periodical checks of the spark plug, keep plug a safe distance from cylinder to avoid burning of evaporated fuel from cylinder.

Don't check for spark with spark plug or plug wire removed. Use an approved tester.

Don't crank engine with spark plug removed unless spark plug wire is disconnected. Sparks can ignite fumes.

Don't run engine when the odor of gasoline is present or other explosive conditions exist.

Don't operate the unit if gasoline is spilled. Clean up spill completely before starting engine.

Don't operate your tiller if there is an accumulation of debris around the muffler, and cooling fins.

Don't touch hot mufflers, cylinders or cooling fins as contact may cause serious burns.

ASSEMBLY

WARNING • DANGER

IMPROPER ASSEMBLY OF THIS TILLER
CAN RESULT IN SERIOUS INJURY.
MAKE SURE TO FOLLOW ALL
INSTRUCTIONS CAREFULLY.

IF YOU HAVE ANY QUESTIONS
CONTACT YOUR LOCAL AUTHORIZED
MANTIS DEALER


Your Mantis Tiller comes partially assembled. You must install only the handlebars, the carrying handle, and the tines. This will take just a few minutes if you follow the directions.

First, take all items out of the carton. But do not remove the cardboard from around the Tiller's base.

The list at the right, shows the parts that come with your tiller. Check to make sure you have them.

The bag of hardware is in the plastic bag containing the Owner's Manual and Video.

To assemble your Mantis Tiller, you'll need two 7/16" wrenches or two adjustable wrenches. We suggest that you install all nuts and bolts only "finger tight" — that is, one-half to one full turn — until you've completed assembly. **The nuts are self locking, but you must use a wrench to tighten them completely.**



Quantity	Description	*Key #
1	Upper Handle Without Throttle	5
1	Upper Handle With Throttle	4
2	Lower Handles	6
1	Pair Tiller/Cultivator Tines	46/47
1	Engine Assembly (includes Fender Guard & Worm Gear Transmission)	7
1	Handle Brace	8
1	Plastic Carrying Handle	49
1	Bag of Hardware Containing:	
	4 Cap Screws	11
	6 Lock Nuts	12
	2 Bolts (3" long)	23
	2 Tine Retaining Pins	48
	2 Handle Clamps	22
	1 Throttle Clip	15

*These numbers are the same numbers shown on the Parts Layout on page 27.

ASSEMBLY (continued)

HOW TO ASSEMBLE LOWER HANDLES

To identify part numbers, see pages 6 and 27.

1. Use the protective cardboard sleeve to stabilize your tiller. Stand the engine assembly (#7) up.

2. Lay the handle parts within easy reach. You'll need one of the handle clamps (#22) and one of the lower handles (#6). Note that the lower handles have a short leg on one end. (Picture 1)

3. Fit the handle clamp along the outside of the short leg. Line up the holes on the clamp and the leg.

4. Choose one of the two 3-inch bolts (#23). Slide it through the first set of holes — near the elbow where the lower handle curves. (Picture 2)

5. Now slide the other lower

handle onto the 3-inch bolt. (Picture 3.) Fit the other clamp onto this other handle's short leg. Add a nut and tighten finger tight.

6. Locate the worm gear housing. It starts just above — and extends down through — the tiller's red fender guard. You'll notice that there's a recessed channel on either side of the housing's top. (Picture 4.)

7. Take the lower handles that you've just put together. Slide them into the two recessed channels.


! Make sure you insert them from the rear of the tiller (gasoline tank faces the operator) . . . so that the bolt fits along the back of the housing. (Picture 1 and 2, Page 8)

8. Slide the second 3-inch bolt through the second set of holes in the short legs. Add a nut and tighten finger tight.


NOTE: THE LOCK NUTS ARE STAMPED. FINGER TIGHT IS APPROXIMATELY 1/2 TO 1-1/2 TURNS.




Picture 1




Picture 2



Picture 3



Picture 4



Picture 5


ASSEMBLY (continued)

HOW TO ASSEMBLE UPPER HANDLES & PLASTIC CARRYING HANDLE.

1. Lightly squeeze the lower handles (#6) toward one another so that they line up with the two smaller holes on the carrying handle (#49). Then slide the carrying handle over and down the lower handles. It will rest about four to six inches above the engine. (Picture 1)

2. Gently pull the lower handles out to their original position.

3. Slide the upper handle (#5) — the one with the throttle cable and wire — into either



Picture 1

lower handle. (Choose the lower handle you prefer, depending on which hand, right or left, you'd rather use to press the throttle.)

Use a Cap Screw (#11) and a Lock Nut (#12) to secure the upper handle in place.

(Picture 2). **Be sure you have proper throttle movements and that the throttle cable is not wrapped or twisted around the handle bar.**

Squeeze trigger and let go. The triangle must click in both directions. If there is any doubt, remove air filter and visually check that the throttle triangle hits both the idle screw and the full open stop. **THIS MUST BE DONE BEFORE STARTING THE ENGINE.**

4. Follow the same steps to install the other upper handle onto the other lower handle. (Picture 3)

5. Use the clip (#15) to secure the throttle cable and wire in place on the lower handle. (Picture 4)

6. Now install the Handle Brace. Line it up with the holes on the upper handles. Then insert a Cap Screw and a Lock Nut on either side (Picture 5)

7. Use a wrench to tighten Cap Screws and Lock Nuts.

8. Now use wrench to tighten all nuts and bolts firmly and securely.


IMPORTANT NOTE:

Make sure you have installed the handles properly. When you stand behind your tiller, holding the handles, you should face the gasoline tank.


⚠ WARNING: Improper throttle installation can cause tines to rotate unexpectedly .

⚠ WARNING • DANGER ⚠


REMOVE TINES BEFORE STARTING ENGINE AND MAKING ADJUSTMENTS.



Picture 2



Picture 3



Picture 4



Picture 5

ASSEMBLY (continued)


Assembling the Tines for Tilling

1. Remove the cardboard from around your Tiller's base.
2. Slide the tines onto the axle shafts. The "D" hole goes on the outside.
3. Make sure you've installed the tines properly for tilling. Liken the tines to your fingers. When your palm faces the ground, your fingers curl down. Stand behind the Tiller and hold your hand next to the tines. Do the tine blades curl down, as your fingers do? If so, they are in the *tilling* position. (To switch to the cultivating position, see page 15.)

4. To secure each tine to the axle, insert a tine retaining pin.

IMPORTANT NOTE:

Before you use your Mantis Tiller, read the Safety Rules & Warnings on pages 3-5.



Mixing Fuel

Your Mantis Tiller is powered by a commercial two stroke, air cooled engine which requires a fuel mixture of gasoline and lubricating oil.

Use a mixture of 50 parts unleaded regular gasoline and 1 part two-stroke Mantis oil (50:1.) Use branded 89 octane (R+M+2) unleaded gasoline or gasohol (maximum 10% ethyl alcohol, or 15% MTBE, no methyl alcohol.)



⚠ WARNING • DANGER ⚠

FUEL IS EXTREMELY FLAMMABLE. HANDLE IT WITH CARE. KEEP AWAY FROM IGNITION SOURCES. DO NOT SMOKE WHILE FUELING YOUR EQUIPMENT.

Here's how to mix the oil with the gas:

1. Pour 1/2 of the gasoline into a safe container. Do not mix the fuel and oil in the engine fuel tank.
2. Add 2.6 ounces of two-cycle engine oil to the gasoline and mix. Then add the rest of the gasoline.
3. Screw the cap onto the gasoline can. Then swirl the can to blend the oil and gas.
4. Carefully pour the fuel mix into the tiller's fuel tank. After putting the fuel tank's cap back on, wipe up any spilled fuel from tank and gasoline can.

IMPORTANT:

Two stroke fuel separates and ages. Do not mix more than you will use in a month. Using old fuel can cause difficult starting or engine damage. Shake fuel container to thoroughly mix fuel before each use. Do not attempt to run your engine on gasoline only, use proper fuel mixture.

Need pre-measured engine oil? Contact your local authorized Mantis dealer.

Remember ...

- Always mix two-cycle oil with gasoline before fueling your tiller. Never, ever run your Tiller on gasoline alone. This will ruin your engine and void all warranties.
- Always use a clean gas can and always use unleaded gas.
- Never try to mix the oil and gasoline in the engine fuel tank.
- Always mix oil and gas in the proper proportions: 2.6 ounces of two-cycle engine oil to one gallon of unleaded gasoline.

IMPORTANT NOTE:

Do Not use old or stale oil/gasoline mixture. Always use the proper oil/gasoline mixture. If you do not, your engine will suffer rapid, permanent damage. And you will void the engine warranty.

STARTING

To Start Your Tiller for the First Time:

1. Fill the fuel tank with the proper oil/gasoline mixture. (See previous section.)
2. Hand tighten the gasoline cap just until it's snug.
3. Place the start/stop switch into the "start" position. (Picture 1)
4. Pull out the choke button to close the engine choke. (Picture 2)
5. Locate the **purge bulb** on the upper right of the engine, in front of the fuel tank. (See **Picture 3**) It sends fuel into the carburetor, **for easy starting**. Press the **purge bulb** until you see fuel flow through the **clear fuel return line**. Since you're starting "cold," you may need to press six to eight times. As soon as fuel starts flowing through the clear fuel line, stop pressing! (Picture 3)
6. Pull the starter cord (Picture 4) slowly until resistance is felt. Then give the recoil starter cord a few short, brisk pulls until the engine **fires**.

During cold starting, you may need to pull at least three or four times before the engine fires.

NOTE: When the choke is closed, never pull the cord more than four or five times.


Overpulling may cause flooding. Also, bear in mind that, when the engine **fires, it only coughs or sputters, and will not run on choke**.

7. Push in the choke button to open the choke. (Picture 5)


8. Then pull the starter cord again. The engine should start and run. Let the engine warm up two to three minutes before using.

*Follow these steps whenever you are starting the engine "cold", or when the engine has run dry and you have just added fuel. Remember, always use short, brisk pulls. Don't give the cord a long, forceful yank. **And, do not let the cord snap back into the starter housing.***

Never use starting fluids as they will cause permanent engine damage. Using them will void the warranty. Before you use the tiller, read the Safety & Warning rules on pages 3-6.



Picture 1



Picture 2



Picture 3

! WARNING !


**AVOID ACCIDENTAL
BLADE ENGAGEMENT**

**DO NOT SQUEEZE THE
THROTTLE TRIGGER
WHEN STARTING.**

**MAINTAIN PROPER IDLE
SPEED ADJUSTMENT
(2200-2300 RPM)**



Picture 4



Picture 5

STARTING (continued)

Starting a Warm Engine

1. Slide ignition switch to START position.
2. Push choke button in to the RUN (open) position.
3. If there is no fuel in the

clear return line, push primer bulb 3-4 times or until fuel is visible in the line.

4. Pull starter rope using short pulls, 1/2 to 2/3 of the rope length.

5. If engine fails to start in 4 pulls, use "First Time" starting

procedure on page 10.

6. With engine running, and both hands on the handles, squeeze throttle trigger gradually to increase the engine speed and engage the tines.

ADDITIONAL INFORMATION

⚠ WARNING • DANGER ⚠

IF ENGINE DOES NOT STOP WHEN SWITCH IS PUT IN THE STOP POSITION, RELEASE THE THROTTLE, ALLOW ENGINE TO IDLE. PUT THE TILLER DOWN, AND PULL THE CHOKE BUTTON OUT TO COLD START (CLOSED) POSITION.

CHECK AND RETURN IGNITION SWITCH TO ON POSITION BEFORE STARTING ENGINE AGAIN.

A Tip for Extending Your Engine's Life

After you start the engine, let your tiller warm up for two to three minutes before you use it. Then, before you put your tiller away, let it idle for a minute to give the engine a chance to cool down.

How to Stop the Engine

Simply push the start/stop switch to "stop." (Picture 1) This will stop the engine instantly. If it should ever fail to do so, just pull out the choke button. The engine will stop at once.


About the Choke

The choke controls the amount of air drawn into the engine. Your tiller will run only

if the choke is open — that is, if the choke is pushed in.


A Special Feature (with the idle set properly and the engine running)

Even when the engine is running, the tines won't turn unless you press the throttle lever on the handlebars. And, when you release the throttle lever, the tines will stop.



Picture 1


WHAT TO DO JUST IN CASE



Picture 1



Picture 2



Picture 3

If you follow the normal starting procedure, you should have no problem starting your tiller. But, just in case you do have problems, here's what to do.

Make sure the start/stop switch is on "start." You'd be surprised how many people forget to push the switch into the "start" position.

If the switch was on "stop" when you pulled the cord, you may have flooded the engine.

- First, examine the spark plug. Use the special wrench that comes with our optional Mantis Handy Item Kit (Item #1422) or a 3/4 inch spark plug wrench. (Picture 1)

- Remove the cap over the spark plug.

IMPORTANT NOTE:

To avoid possible damage to the threads, do not try to remove the plug from a hot aluminum cylinder head.

- Unscrew the spark plug. (Picture 2)

! WARNING !

MAKE SURE THE START/STOP SWITCH IS IN THE STOP POSITION.

KEEP PLUG WIRE AWAY FROM ENGINE TO AVOID UNINTENTIONAL SPARK.

Starting a Flooded Engine

1. If the end of the spark plug is wet, the engine may be flooded. **Make sure the switch**

is in the stop position, disconnect spark plug wire and remove plug. Use a paper towel or a clean rag to dry the spark plug, then, with the spark plug out of the engine, pull the starter cord several times. Shake the fuel out of the inside of the plug and air dry. Next, replace the spark plug. Use the wrench to tighten it and replace the cap. Next, put the switch in the start position and pull the choke button out. Pull the starter cord three or four times until the engine coughs or sputters. Open the choke (push the choke button in) and pull the cord a few times. The engine should start and run.

2. If the end of the spark plug is dry, check to see if the fuel line is blocked. The fuel line runs from the fuel tank to the carburetor. Pull it off at the carburetor end. Fuel should drip slowly from the line. Wipe off any excess or spilled fuel.

If fuel does not drip from the line, check the line for any bends or pinches. (Picture 3). Kinks in the line restrict the flow of fuel to the engine. Just straighten out the line. Reconnect. Then follow the normal starting procedure.

If fuel drips too freely, the line may be disconnected from the fuel filter. You'll find the fuel filter inside the fuel tank. Just re-attach the line to the filter, and put the filter back in the tank. Then follow the normal starting procedure.

Here's Another Way to Start your Mantis Tiller

If you follow the steps above and your engine still won't start, try this:

1. Push the switch to "start."

WHAT TO DO JUST IN CASE (continued)

2. Push in the choke button to open the choke.

3. Press the plastic bubble a few times.

4. Give the starter cord a few short, quick pulls. The engine should start and run.

5. If the engine does not start, then pull out the choke button to close the choke. Pull the starter cord four to five times. The engine should sputter or cough.

6. After the engine sputters, push the choke button in. Then pull the starter cord. The engine should start and run.

7. If the engine still does not start, repeat steps 2 through 6.

8. If the engine still does not start, call 1-800-366-6268 and ask for Customer Service or the name of your local Mantis dealer.

IMPORTANT NOTE:

Never use starting fluids. Starting fluids will cause permanent engine damage. Using them will void the warranty.

IMPORTANT NOTE:

Before you use your Mantis Tiller, read the Safety Rules & Warnings on pages 3-5.

GETTING YOUR TILLER TO YOUR GARDEN

Walk it.

Once your tiller is running, you can "walk" it to your garden. Just press the throttle lever gently and let the tiller "tip-toe" across your yard on its tines. It won't hurt your lawn or driveway. (Picture 1)

Carry It.

Make sure the engine is off. Then use one hand to grasp the

convenient carrying handle. Use the other hand to hold the handlebars. (Picture 2) Then lift your tiller and carry it to your garden. Since it weighs only 20 pounds, it won't strain your muscles or tire you out!

Take It for a Ride.

You can easily transport your Mantis Tiller to a friend's or relative's house. Just empty the fuel tank. (This is crucial.)

Then stow your Tiller in the trunk of your car or truck. It fits easily. And you can put it in and take it out without straining your back.

! WARNING !

NEVER CARRY YOUR TILLER AS THE PERSON IN PICTURE 3 IS DOING. IF YOU DO, AND THE TINES ENGAGE, YOU COULD SUFFER SERIOUS INJURY.



Picture 1




Picture 2



Picture 3

TILLING



Picture 1



Picture 2



Picture 3

! WARNING • DANGER !

THE OPERATOR OF THIS TILLER IS RESPONSIBLE FOR ACCIDENTS OR HAZARDS OCCURRING TO HIMSELF, OTHER PEOPLE OR THEIR PROPERTY.

Now You're Ready to Use Your Mantis Tiller.

If you've seen other tillers, your Mantis Tiller may surprise you. It tills best when you pull it backward! You see, when you pull your Mantis Tiller backward, you give extra resistance to the tines, so they dig deeper.

(Picture 1)

What's more when you go backward, you erase your footprints. So your soil stays light and fluffy. With other tillers, by contrast, you walk right over the soil you've just tilled, packing it down, so it's less plantable.

Run Your Mantis Tiller like a Vacuum Cleaner.

Place your Tiller at the head of the row or area you want to till. Start it up. Then use an easy rocking motion. First, pull your Tiller backward. Then use an easy rocking motion. Again, pull your Tiller backward. Then, let it move forward just a little bit. Then pull it backward again. This will help you till deeper.

Keep repeating these steps until you've tilled an entire row. Start again on the next row. It's much like running a vacuum cleaner! (Picture 2)

You Can Even Control Depth.

For Deeper Tilling:

Move your Tiller slowly back and forth, as you would a vacuum cleaner. Work the same area over and over until you've dug to your desired depth.

For Shallow Tilling:

Switch the tines to the cultivating position. (See page 15 to learn how.) Then move your Tiller quickly over your soil surface.

For Big Weeds or Tough Roots:

Let your Tiller rock back and forth over the tough spot, until the tines slice through the weed or root.

Your Mantis Tiller Handles Special Tilling Projects.

Want to turn part of your lawn into a colorful flower border? Your Mantis Tiller makes it easy! Just run your Tiller back and forth until the sod begins to break up. Then continue tilling. Your Tiller will chop the clumps of sod until they're fine. Then, it will work them into the soil. Pretty soon, you'll have a soft, fresh planting bed.

⚠ WARNING • DANGER ⚠

**IF YOUR TINES GET JAMMED OR ENTANGLED, SHUT OFF THE ENGINE AT ONCE.
REMOVE THE OBSTRUCTION WHILE THE ENGINE IS OFF.
NEVER TRY TO REMOVE AN OBSTRUCTION WHILE THE ENGINE IS RUNNING.
SERIOUS INJURY CAN RESULT.**

How about a family-size vegetable garden?

Nowadays many gardeners prefer small gardens — especially in the suburbs, where space is at a premium. But, if you're fortunate enough to own a large lot, you can create a bigger garden — a half acre or more. Here's how:

1. First, hire someone with a tractor or big tiller to break ground for you. This is a one-time-only investment that's well worth the small cost.

2. Then, use your Tiller to break up any remaining clumps of soil or sod. Unlike a tractor or big tiller, your Mantis Tiller is a precision tool. It will pulverize your soil into a smooth seed bed.



Picture 1

Your Mantis Tiller Makes Weeding a Pleasure!

As a tiller, your Mantis Tiller works the soil down to 10" (25.4 cm) deep. But, as a cultivator, it gently cultivates the surface, only 2" to 3" (5.09 cm to 7.62 cm) deep.

First, you must switch the tines to the weeding position. This takes less than a minute.

Then, your Mantis Tiller's sharp "tine teeth" will slice up those pesky weeds, burying them as you go along. And, since the tines in this position won't dig too deep, they won't hurt your plants' precious root systems.

The result? Your Tiller will cut your weeding time in half, and turn a tiresome chore into a pleasure.




Picture 2

How to Switch From Tilling to Cultivating Position


1. Make sure your Tiller is off.
2. Remove the retaining pins from the tines.
3. Remove the tines from the axle.
4. Place the right-side tine onto the left-side axle. Place the left side tine onto the right-side axle. The "D" hole should be to the outside.
5. Here is how to make sure you've installed the tines properly. Stand behind the Tiller and hold your hand, palm up, next to the tines. Do the tine points curl up, as your fingers do? If so, they are in the correct cultivating position.
6. Reinsert the pins.

CULTIVATING



Tilling Position

Tine teeth point in the same direction as the rotation of the tine; or toward the front of the Tiller, away from the operator.



Cultivating Position

Tine teeth point in the opposite direction as the rotation of the tine. Tines point toward the back of the tiller, or toward the operator.

Now You're Ready to Cultivate or Weed.

Guide your Tiller where you want to weed and start it up. Pull your Tiller backward slowly, then let it move forward a bit, in a gentle rocking motion. Watch it slice, shred, and bury those weeds!

Got tough weeds? Lighten your pressure on the throttle to slow your Tiller down. Then work back and forth until your Tiller chops up the weeds. It's easy and effective!

Remember, any tiller will tangle in tall grass, stringy vines, or super-big weeds. So, if you have a "backyard jungle," first use a knife, pruner, or brush cutter to chop up the overgrowth. If the tines become tangled anyway, **turn the engine off completely** before trying to clear them.



MAINTENANCE

Check the Air Filter Often

A wet or dirty air filter can affect the way your engine starts, performs, and wears. So, it's a good idea to check your air filter once a month.

If you work in dusty soil, or if you want to be on the safe side — then check your filter more often (for instance, before each use). But be sure to replace it at least once a year, in the spring or fall. Clean or change it as needed. It is recommended to change the air filter yearly.

How to Check, Clean and Change the Air Filter

1. Loosen the wing nut on the side of the air-cleaner cover. (See Picture 1, or look up Key #9 in Air Cleaner Parts Assembly on page 28.)

2. Take off the cover. Make sure to clear the choke button. (Picture 2)

3. The air filter is the white pad on the inside of the air-cleaner cover. Check whether it is soiled or moist.

Note:

Please check the lip on the Air Cleaner Cover. If the lip is chipped or cracked, it should be replaced. This will prevent dirt from being ingested through the carburetor into the inside of the engine.

4. If the air filter needs cleaning or no longer fits properly, remove it. Just lift an edge carefully and “peel” it out. (Picture 3)

5. Use a brush to remove debris from the pad.


6. If the air filter is so dirty that it won't come clean, you must replace it or severe engine damage will occur. Order a new one directly from your local Authorized Mantis Dealer.

7. Insert your clean filter inside the air-cleaner cover.


IMPORTANT! Make sure filter is “seated” properly in the cover. The filter must fit snugly inside the rim that holds the filter in place.

Installing the filter incorrectly will cause engine damage and void the warranty. Fit the cover back over the air cleaner. (Again, make sure to clear the choke button.)


8. Tighten the wing nut to secure the cover.



Picture 1



Picture 2



Picture 3

MAINTENANCE (continued)

How to Check the Grease Level Inside the Worm Gear Housing

When we built your Mantis Tiller, we lubricated the worm gear housing thoroughly.

It is imperative that you inspect the grease level once a year. Simply remove the cover plate on the worm gear housing. (Picture 1) Then check to make sure the grease comes almost to the top of the housing. If it doesn't, add lithium #0 grease (Item M9985.) This is the only way to add grease to the worm gear housing. (Picture 2) To purchase Mantis grease, contact your local authorized Mantis dealer.

Please do not overfill. Too much grease can create pressure, which could cause seals to fail or the clutch to slip.



Picture 1




Picture 2

Clear Blockages From the Fuel Line & Filter:

After you've used your Tiller for a few seasons, check for blockages in the fuel tank and fuel filter. Such blockages can keep your Tiller from starting.

Clear any blockages you see in the tank, fuel filter, or fuel line. Remember: The fuel filter is located inside the tank. (See Picture 3) Then use the normal starting procedure to start your Tiller.



Picture 3

MAINTENANCE (continued)

! WARNING • DANGER !
**REMOVE TINES BEFORE
STARTING ENGINE AND
MAKING ADJUSTMENTS**

What to Do if Your Engine Idles Too High

What if your engine runs too fast ... or if the tines turn the instant you start the Tiller? You may need to adjust the idle screw (Key #25 under Carburetor on page 28) by itself right below the H and L screws. Gently turn it counter-clockwise. You'll know you've adjusted it correctly when the axles do not turn at low idle.

If you continue to have idle problems, you may need to adjust the throttle cable.

First, locate the metal triangle at the end of the throttle cable. (Picture 1) The idle screw must touch this triangle. But, if the throttle cable's too tight, you'll see a gap between the idle screw and the triangle.

To fix this, loosen the top nut that holds the throttle cable in place. (Picture 2) (Use a 10mm

wrench or an adjustable wrench.) Then, slide the cable down until you close the gap between the triangle and the idle screw. (Picture 1) Now, tighten the bottom nut that holds the throttle cable.

Locate the metal "button" on the triangle. This is the swivel. The large end of the throttle cable must be inside the slot in this swivel. (Picture 3)

What to Do if Your Engine Runs "Rough"

If your engine runs "rough" or stalls, you may need to adjust the carburetor and idle screws.

If you remove the air-cleaner cover, you'll see the two carburetor, adjustment screws next to the black choke button.

The "RED" screw is the HIGH-speed adjustment... The "WHITE" screw is the low speed adjustment.

First, remove the tines from the axle. Then start engine. Let it run for two to three minutes.

"FLASH" the choke several times during the warm-up to clear any air from the Fuel system.

Then stop the engine after it reaches operating temperature.

Now, turn the RED, high-speed screw counter-clockwise all the way to stop... Then turn the WHITE, low speed screw halfway between the counter-clockwise and clockwise stop positions.


Now restart the engine to finish the carburetor adjustment.

Run the engine at full speed two or three seconds to clear out any excess fuel. Then return to idle.


Now, accelerate the engine to full throttle several times to check for a smooth transition from idle to high speed.

If the engine hesitates turn the WHITE, low-speed screw counter-clockwise one-eighth of a turn. Then accelerate the engine.


Repeat the adjustment until you get a smooth transition to high speed.



Picture 1



Picture 2



Picture 3

MAINTENANCE (continued)

How to Reseat the Flange

At some point, you may find that the tines won't turn when you press the throttle. This may mean the engine isn't sitting all the way down on the worm gear housing.


Perhaps you've been using your Tiller for several years. Or perhaps you've removed the engine for use with our hedge trimmer attachment, then replaced it. In either case, the flange bolt (Key #22, page 29) may have come loose and lifted the engine up.

If this happened you'll notice a gap between the bottom of the engine flange (Key #24, page 29) and the top of the worm gear housing. (Picture 1)


To fix this, loosen the flange bolt. Take the engine off the worm gear housing. Notice the hex head on top of the drive shaft (Key #28, Page 27). Inside the flange housing, you'll find the clutch drum (Key #25, Page 29). Make sure the hex head lines up with the clutch drum inside the flange housing.

Then put the engine back on the worm gear housing. Make sure the plastic carrying handle is not under the fuel tank.

If you've followed these steps properly, there will be no gap between the engine flange and the worm gear housing. (Picture 2) Make sure you tighten the flange bolt!



Picture 1 ... Note how the engine doesn't sit all the way down on the transmission.



Picture 2 ... Note how the engine sits all the way down on the transmission.

Cleaning the Muffler Screen

1. Take out the spark plug.
2. Remove the red cylinder cover, (Key #19) which is held on by 2 phillips-head screws. (Key #18)


3. You will see the metal screen fixture, held on by 3 more phillips-head screws. (Key #26) Remove the fixture.

4. Behind the fixture (Key #25) will be the muffler lid (Key #24) and muffler lid gasket (Key #23). The screen sits in the gasket.

5. If the screen (Key #22) is clogged with deposits, it needs to be cleaned. Use carburetor cleaner, and any brush that is not metal.

Brush the screen until you are able to see through it.

6. If the screen remains plugged after attempts at cleaning, it must be replaced.



STORAGE

⚠ WARNING • DANGER ⚠

**DO NOT STORE IN AN AREA
WHERE FUEL FUMES MAY
ACCUMULATE AND REACH A
FLAME OR SPARK.**

Each fall — or before you store your Mantis Tiller for any long period — be sure to take these measures:

1. Do not store your Tiller with fuel still in it. Even under ideal conditions, stored fuel containing ethanol or MTBE can start to go stale in 30 days. And, since stale fuel has a high gum content, it can clog the carburetor, this, in turn, will restrict fuel flow. **So, when you're ready to store your Tiller, or will not be using it for more than 2 weeks, drain the fuel tank completely.** (Picture 2)

2. Next, restart the engine to make sure no fuel is left in the carburetor. Then run the engine until it stops. This will prevent gum deposits, forming inside of the carburetor and possible engine damage.

3. Disconnect spark plug wire and remove the spark plug. (Use the wrench that comes in our **optional** Handy item Kit, Item #1422. Or use a 19mm or 3/4" spark-plug wrench.) Pour about a teaspoon of clean, air-cooled, two-cycle oil through the spark-plug hole into the combustion chamber. (Picture 3) Slowly pull the starter cord two or three times to coat the inside of the cylinder wall.

4. Inspect the spark plug, and, if necessary, clean it. If you need to replace it, buy a NGK-BPM7Y. A replacement spark plug is included in the **optional** Handy Item Kit item # 1422.


5. Install the spark plug, but leave the spark plug wire disconnected.

6. Clean the air filter as described on Page 17.


7. Clean dirt, grass, and other materials from the entire machine.

8. Wipe the tines with oil or spray them with WD-40, to prevent rusting.


9. Oil the throttle cable and all visible moving parts. (Do not remove the engine cover.)



Picture 1



Picture 2



Picture 3

STORAGE (continued)

10. Check the grease level in the worm gear housing, as described on page 18.

11. Order new parts to replace any that are badly worn or broken. Just contact your local authorized Mantis dealer. But do it early, so you'll have the parts well before the next gardening season starts.

12. Store your Tiller — in an upright position — in a clean, dry place. (Picture 1, preceding page)

13. Do you have fuel left over from last season? Dispose of it properly. Buy fresh oil and gasoline next season.

How to Prepare Your Mantis Tiller for Restarting

In the Spring, when you take your Tiller out of storage, remove the spark plug. Pull the starter cord three or four times to clean oil from the combustion chamber. (Picture 1) Wipe oil from the spark plug. Place the spark plug back into the cylinder. Re-connect the spark plug wire back on the spark plug. Then follow the steps on pages 9 & 10 to refuel and restart your Tiller.

Again, Check the Carburetor.

If your Tiller won't restart in the Spring — or if it lacks its usual power — the carburetor may need attention. Follow the steps on page 19 for adjusting the H and L screws. (Picture 2)

Check the Spark Plug Too.

If your Tiller won't restart, or if it lacks full power, the spark plug may be at fault. Check to see if the plug is fouled with oily black deposits. Clean or replace it if it is. (Picture 3)

Also, check whether the center electrode is rounded at the end, or if the ground electrode is worn. If either is the case, you should replace it with a NGK-BPM7Y spark plug. Use a 19mm or a 3/4" spark-plug wrench to install it. Adjust the plug gap .024 - .028 in. (0.6 to 0.7 mm)

Caution: Do not over tighten the plug. The correct torque is 18 to 22 ft.-lbs. (24-30 n.m)

IMPORTANT NOTE:

To avoid possible damage to the threads, do not try to remove the plug from a hot aluminum cylinder head.



Picture 1



Picture 2



Picture 3

TROUBLE SHOOTING

Problem	Cause	Remedy
1. Tines don't turn when throttle is depressed	Engine is not seated properly on the gear housing.	Re-install engine following the instructions on page 20 (How to re-seat the flange).
2. Engine fails to start	Start/Stop switch is in Stop position. No fuel in tank. Fuel strainer clogged. Fuel line clogged. Spark plug shorted or fouled. Spark plug is broken (cracked porcelain or electrodes broken) Ignition lead wire shorted, broken or disconnected from spark plug. Ignition inoperative	Move switch to start. Fill Tank. Replace Strainer. Clean fuel line. Install new spark plug. Replace spark plug. Replace lead wire or attach to spark plug. Contact your local authorized dealer.
3. Engine hard to start.	Water in gasoline or stale fuel mixture. Too much oil in fuel mixture. Engine under or over choked. Carburetor out of adjustment. Gasket leaks (carburetor or cylinder base gasket). Weak spark at spark plug.	Drain entire system and refill with fresh fuel. Drain and refill with correct mixture. If flooded by over choking, proceed according to instructions in operation section. If under choked, move choke lever to closed position and crank two or three times. See "Carburetor Adjustment" Replace gaskets. Contact your local authorized dealer.
4. Engine misses.	Dirt in fuel line or carburetor. Carburetor improperly adjusted. Spark plug fouled, broken or incorrect gap setting. Weak or intermittent spark at spark plug.	Remove and clean. See "Carburetor Adjustment". Clean or replace spark plug - set gap to .024-.028 in. (0.6-0.7 mm) Contact your local authorized dealer.

TROUBLE SHOOTING (continued)

Problem	Cause	Remedy
5. Engine lacks power.	Air filter clogged. Carburetor out of adjustment. Muffler clogged. Clogged exhaust ports. Spark Arrestor Clogged. Poor compression.	Clean or replace air filter. See "Carburetor Adjustment". Clean carbon from muffler. Remove muffler, rotate engine until the piston is at top of cylinder. With a wooden scraper or blunt tool, remove all carbon from exhaust ports. Be careful not to scratch or damage piston or cylinder walls. Blow out all loose carbon with compressed air. Install muffler and gasket. Clean Spark Arrestor Contact your local authorized dealer.
6. Engine overheats.	Insufficient oil in fuel mixture Air flow obstructed	Mix fuel as described in starting instructions. Clean flywheel cylinder fins and screen.
7. Engine noisy or knocking.	Spark plug in incorrect heat range. Bearings, piston ring or cylinder walls are worn.	Replace with plugs specified for engine. Contact your local authorized dealer.
8. Engine stalls under load.	Carburetor adjustment too "lean". Engine overheats.	See "Carburetor Adjustment". Remove dust and dirt from between fins.

ENGINE SPECIFICATIONS

Dry Weight	2.5kg — 5 lbs., 10 ounces
Type of Engine	Air Cooled, Two stroke, Single-Cylinder, Gasoline Engine
Rotation	Clockwise, viewed from TOP
Bore	32.2 mm (1.268 in.)
Stroke	26.0 mm (1.04 in.)
Spark Plug	NGK BPM7Y
Fuel	Premixed two stroke fuel
Fuel Oil Ratio	50:1 ratio with Mantis oil
Gasoline	Unleaded (see page 9)
Displacement	21.2 cc (1.294 cu. in.)
Exhaust System	Spark arrester muffler
Carburetor	ZAMA diaphragm model C1U type
Ignition System	Flywheel magneto, capacitor discharge ignition type
Starter	Automatic rewind type
Oil	Designated, two-stroke, air-cooled engine oil
Fuel Tank Capacity	0.4 lit. (13.57 oz.)
Starter System Clutch	Automatic rewind starter Centrifugal type

SERVICE MAINTENANCE GUIDE

Area	Maintenance	Frequency
Air Filter	Clean Replace	Daily or every 4 hrs. use Every 3 mths. or 100 hrs. use
Spark Plug	Clean Replace	Every 3 mths. or 100 hrs. use 6 months or 300 hrs. use
Carburetor	Check / Rebuild Replace	6 months or 300 hrs. use Yearly or 600 hrs. use*
Cooling System	Inspect / Clean	Before Use
Muffler (Spark Arrestor)	Inspect / Clean	Monthly
Gear Housing	Check Grease	Yearly
Blades	Inspect / Clean / Lubricate	After Use
Fuel Leaks	Inspect / Repair	Before Use
Fasteners	Inspect / Tighten / Replace	Before Use
Labels	Inspect / Replace	Before Use
Handles	Inspect / Replace	Before Use
Guards / Safety Devices	Inspect / Replace	Before Use
Fuel Line	Inspect / Replace	Monthly
Starter Rope	Inspect / Replace	Monthly
Fuel Strainer	Replace	Every 3 mths. or 100 hrs. use
Choke	Check	With each re-fueling
Ignition System	Clean Replace	No maintenance For coil and flywheel

* Replacement will be required for commercial use after 600 hours. For Consumer use, cleaning every 6 months is required. Cleaning includes Rebuild Kits.

IMPORTANT: Time Intervals shown are maximum. Actual use and your experience will determine the frequency of required maintenance.

Notes:

[illegible]

USING THE BORDER EDGER ATTACHMENT

Your Mantis Tiller has been designed and built to accept a wide range of Mantis Tiller Attachments to increase its usefulness in your lawn and garden. And, all Mantis Tiller Attachments have been designed for quick and easy attachment to the Tiller or Engine.


The Border Edger (Item #3222)

The most popular attachment, the Border Edger can be used to cut clean, neat edges along walkways, or around trees, shrubs, and garden beds.

The Border Edger has two parts: a wheel and a hardened steel blade, with pointed tines.

How to Install the Border Edger

The following instructions refer to “right” and “left” axles. Assume that you’re standing behind your Tiller, as you would for tilling and cultivating.



Picture 1

Some areas of your yard may harbor roots and other underground obstructions. In places like this you’ll want to edge your borders shallowly (1” to 2” deep). Here’s how to install the Border Edger for shallow edging:

1. First remove your tilling/cultivating tines.
2. Then slide the edger’s wheel onto the right axle.
3. Now slide the Edger blade onto the left axle. The blade’s angled face should hit the ground when you spin the blade forward.

4. Insert retaining pins on both left and right axles.

Around walkways and garden beds, you’ll want to edge more deeply (3” to 4” deep). Here’s how to install the Border Edger for that purpose:

1. Remove the tilling/cultivating tines.
2. Slide the Edger’s blade onto the right axle. The blade’s pointed face should hit the ground when you spin the blade forward.



Picture 2

3. Slide the wheel onto the left axle.

4. Insert retaining pins on both sides.

How to Use the Border Edger

1. Position your Mantis Tiller so that the Edger blade is right along the garden edge and the wheel is outside (on the lawn, on the sidewalk, wherever). (Picture 1)

2. Start your Tiller and pull your Mantis backward along the garden edge. (Picture 2)

The Border Edger Can Handle Special Projects!


1. Install the Edger for deep edging, as directed above. Then use it to cut sod strips.
2. Edge and weed at the same time! Just attach the Edger blade on one axle and a Tiller blade on the other axle, “Mix and match” blades; don’t be afraid to experiment.

IMPORTANT NOTE:


If you do a lot of edging, you’ll appreciate the Mantis Wheel Set (Item#9222.) It gives you added stability, for even easier handling.

To order the wheel Set, or any Mantis Attachment, contact your local authorized Mantis dealer.

MANTIS TILLER ASSEMBLY




P/N 438LA



When you look at a Tine with the raised hub facing you and the teeth are pointing in a **CLOCKWISE** rotation, you have a **LEFT HAND TINE**.

P/N 438RA



When you look at Tine with the raised hub facing you and the teeth are pointing in a **COUNTER CLOCKWISE** rotation, you have a **RIGHT HAND TINE**.


KEY PART No. No.	QTY.	DESCRIPTION	KEY PART No. No.	QTY.	DESCRIPTION	KEY PART No. No.	QTY.	DESCRIPTION
1 382	1	Throttle Lever	21 467-2	1	Throttle Cable Assy.	341 431	1	Tine Shaft
2 383	1	Grip-Thru	22 377	2	Handle Clamp	42 430	2	Worm Gear Thrust Washer
3 619	1	Grip	23 470	2	Long Bolt 1/4-20 x 3" Lg.	43 432	2	Worm Gear Bearing
4 4062	1	Upper Handle - w/o Throttle	25 465	1	Fender Guard	44 434	2	Bearing Seal
5 4061	1	Upper Handle - with Throttle	26 140	2	Bolt 1/4-20 x 3/8" Lg.	45 435	2	Bearing Seal Retainer
6 4063	2	Lower Handle	27 380E-4B1E	1 (Qty.)	Engine	46 438RA	1	Tine Assembly (R.H.)
7 488M	1	Label	28 468	1	Drive Shaft	47 438LA	1	Tine Assembly (L.H.)
8 148	1	Handle Brace	29 466	1	Worm Gear Housing	48 418-1	2	Tine Retaining Hair Pin
9 464	1	Switch Bracket	31 436	1	Gasket	49 402	1	Carrying Handle
10 479	1	Switch	32 437A	1	Housing Cover	50 487MA	1	Engine Label
11 410	4	Cap Screw 1/4 -20x1" Lg.	33 651	1	Rd. Hd. Self Tapping Screw	51 4043	1	Tine Label
12 972	6	Lock Nut 1/4-20	34 423	1	Roller Bearing	53* AA7222	Trans - Transmission Assembly	
15 478	2	Throttle Clip	35 425	1	Worm Bearing Race	54 458	1	Roller Bearing
16 477	1	Connector Female	36 424	1	Worm Thrust Bearing	55 4058	1	Mantis Label
17 476	1	Connector Male	37 422	1	Worm Shaft	56 1612-70A	1	Switch Cover
18 4075	1	Ground Wire	38 426	1	Worm Disk			
19 379	2	Cable Retainer	39 428	1	Retaining Ring			
20 413	1	Retaining Ring	40 429	1	Worm Gear			

*Does not include Key or #48 w/transmission

**P/N468 is included in AA7222-trans.

SV-4B1E ENGINE PARTS ASSEMBLIES


CARBURETOR




KEY NO.	PART NO.	QTY	DESCRIPTION
	12520013122	1	Carburetor Asy Includes the following:
1	12534405360	2	Screw
2	12536308560	1	Ring
3	12538108660	1	Pump, Purge
4	12531005360	2	Screw
5	12538305360	1	Base, Purge
6	A B	1	Diaphragm, Metering
7	A B	1	Gasket, Metering
8	12533942030	1	Screw
9	A	1	Pen, Metering Arm
10	A	1	Lever, Metering
11	A	1	Spring, Metering Lever
12	A	1	Valve, Inlet Needle
13	A	1	Plug, Welch
14	12531649030	1	Valve, Throttle
15	12531413930	1	Screw
16	12531813120	1	Needle, Low Speed
17	12532909860	1	Cap, Limiter L.L.
18	12532013310	1	Needle, High Speed
19	12532939030	1	Cap, Limiter H.S.
20	12532713930	1	Clip

KEY NO.	PART NO.	QTY	DESCRIPTION
21	12537242030	1	Swivel
22	12531713310	1	Shaft, Throttle
23	12531342030	1	Spring, Throttle Return
24	12537813930	1	Piece, Friction
25	12533306960	1	Screw, Idle Adjust
26	12533306960	2	Screw
27	12532412820	1	Cover, Pump
28	A B	1	Gasket, Fuel Pump
29	A B	1	Diaphragm, Fuel Pump
30	A	1	Strainer
31	12537649030	1	Nozzle, Main Check Valve
32	12532715130	1	Clip
33	12533406560	1	Spring, Adjust Screw
A	12530012820	1	Rebuild Kit
B	12530320560	1	Gasket/Diaphragm Kit


AIR CLEANER, MUFFLER, & THROTTLE



KEY NO.	PART NO.	QTY	DESCRIPTION
1	13001042032	1	Gasket, Intake
2	90023805020	2	Screw 5 x 20
3	17851004560	1	Rod, Choke
4	13030104560	1	Case, Air Cleaner
5	17881005230	1	Grommet
6	13041005360	1	Bracket, Air Cleaner
7	90024205057	2	Screw 5 x 57
8	89012140630	1	Label, Choke
9	90052800005	1	Nut, Wing
10	13032611521	1	Cover, Air Cleaner
11	13031004560	1	Filter, Air
12	17851504560	1	Shutter, Choke
13	17851600830	1	Spacer
14	12520013122	1	Carburetor Assy
15	13001642031	1	Gasket, Intake




KEY NO.	PART NO.	QTY	DESCRIPTION
16	13001742031	1	Insulator
17	90050000005	2	Nut 5
20	14580011821	1	Muffler Asy (Includes Items 21-26)
21	14551042031	2	Gasket, Muffler (Included In Kit 88900045131)
22	14586240630	1	Screen, Muffler
23	14586642031	1	Gasket, Muffler Lid (Included In Kit 88900045131)
24	14587642030	1	Lid, Muffler
25	14586306960	1	Fixture, Screen
26	90024204010	3	Screw 4 x 10
27	90010505050	2	Bolt 5 x 50
28	90060000005	2	Washer 5
29	14587105360	1	Cover, Muffler



KEY NO.	PART NO.	QTY	DESCRIPTION
40	178001-11820	1	Throttle Cable
41	900502-00006	2	Nut, 6
42	900610-00006	2	Washer, Lock 6
44	163400-02160	1	Switch, On/Off
50	900220-05028	1	Screw, Shoulder 5 x 25
51	178110-05330	1	Screw 5 x 28
52	900500-00005	1	Locknut 5
53	900560-00005	1	Nut 5
54	178024-06130	1	Throttle Bracket
55	178010-06460	1	Throttle Trigger
56	178043-05230	1	Spring Throttle Return


SV-4B1E ENGINE PARTS

FUEL TANK



KEY NO.	PART NO.	QTY	DESCRIPTION
18	90027505015	3	Screws 5x15
19	90060300005	3	Washers
20	13100511820	1	Tank, Fuel
21	13201011520	1	Pipe 3x5x210
22	13130056430	1	Valve, Check
23	13011100530	1	Clip, Pipe
24	13131244330	1	Pipe 3x 5x 70
25	13201049030	1	Pipe 3x6x50
26	13211546730	1	Grommet, Fuel
27	13201309820	1	Clip
28	13120507320	1	Strainer, Fuel
29	13100453530	1	Cap Asy, Fuel Tank (Includes Item 30)
30	13101655830	1	Gasket, Fuel Cap


STARTER, PAWL CATCHER & CLUTCH



KEY NO.	PART NO.	QTY	DESCRIPTION
1	177200 12820	1	Starter Asy
2	17722042030	1	Spring, Rewind
3	17721544430	1	Drum, Starter
4	17723644330	1	Screw
5		1	Rope Starter (Use Bulk Rope 99944400040 3 x 890 (.12 x 33.5))
6	17727742030	1	Guide, Rope
7	17728811120	1	Grip, Starter
8	90023804016	4	Screw 4x16
9	90060500008	1	Washer, Spring 8
10	90016204022	2	Bolt 4 x 22
11	15660152130	1	Coil, Ignition
12	99944500071	1	Spark Plug BPM-7Y
13	15901103432	1	Coil, Spark Plug
14	15901201620	1	Cap, Spark Plug
15	15611004920	1	Bushing
16	15680105360	1	Flywheel
17	17720212220	1	Pawl Asy, Starter (Includes Items 18 & 19)
18	17723442030	2	Spring, Pawl Return
19	17721844330	2	Pawl, Starter
20	90060000005	1	Washer 5
21	90060500005	1	Washer, Spring 5
22	90011505025	1	Bolt 5x25
23	90023804014	4	Screw 4x14
24	61022311520	1	Case Clutch
25	17501004633	1	Drum, Clutch
26	90023806012	1	Screw 6x12
27	17501411520	1	Washer, Clutch
28	17504404630	1	Washer, Clutch
29	90080836000	1	Bearing, Ball 6000
30	90060000010	1	Washer 10
31	17501904630	1	Plate, Clutch
32	17500007531	1	Clutch Asy (Includes Items 33-35)
33	17500905131	2	Shoe, Clutch
34	17501805130	2	Spring, Clutch
35	17501605020	1	Hub, Clutch
36	16202152830	1	Lead, Ignition

BLOCK

KEY NO.	PART NO.	QTY	DESCRIPTION
1	10020411520	1	Crankcase kit (Includes Items 2-6)
2	10021242030	2	Seal, Oil
3	10021503930	2	Pin, Dowel
4		1	Gasket, Crankcase (Included in Kit 889000045131)
5	90081036201	2	Bearing, Ball 620
6	90016205028	3	Bolt 5x28
7	10010013120	1	Crankshaft Asy
8	61032502730	1	Key, Woodruff
9	10000048732	1	Piston, Kit (Includes Items 10-14)
10	10001105330	2	Ring, Piston
11	10001504630	2	Circlip, Piston Pin
12	10001411520	2	Spacer, Piston Pin
13	10001251230	1	Bearing, Needle
14	10001311520	1	Pin, Piston
15	10101044332	1	Gasket, Cylinder Base (Included in Kit 889000045131)
16	10101106562	1	Cylinder
17	90016205022	2	Bolt 5x22
18	90023804018	2	Screw 4x18
19	10150612820	1	Cover, Cylinder



MANTIS®

D EG-KONFORMITÄTS-ERKLÄRUNG
F DÉCLARATION DE CONFORMITE CE
GB EC DECLARATION OF CONFORMITY
NL EG CONFORMITEITSVERKLARING
N EU OVERENSTEMMELSESERKLÆRING

E DELARACION DE CONFORMIDAD CEE
I DICHIARAZIONE DI CONFORMITA' CEE
S EG KONFORMITETSFÖRKLARING
DK EU OVERENSTEMMELSESERKLÆRING
SF EU-YHDENMUKAISUUSVAKUUTUS

D Wir
F Nous,
GB We,
NL Wij,
E Nosotros,
I Noi,
S Vi,
DK Vi,
N Vi,
SF Me,

Mantis
1028 Street Road
Southampton,
PA, 18966
USA

erklären in alleiniger Verantwortung, dass die Maschine:
 déclarons sous notre seule responsabilité qu la machine:
 declare on our sole responsibility that the machine:
 verklaren als enig veratwoordeikue, dat de machine:
 declaramos por responsabilidad exclusiva que la máquina:
 dichiariamo sotto la nostra unica responsabilità
 förklara på eget ansvar att nedanstående maskin:
 erklærer under aneansvar, at maskinen:
 erklærer på eget ansvar, at maskinen:
 vakuutamme täten, että kone:

D	Modell:	7222ME, (E)	Seriennummer(n):	siehe auf dem Gerät	Konstruktionsjahr:	siehe auf dem Gerät
F	Modèle:	7222ME, (E)	Numéro(s) de série:	voir sur l'appareil	Année de construction:	voir sur l'appareil
GB	Model:	7222ME, (E)	Serial number(s):	see tool	Year of manufacture:	see tool
NL	model:	7222ME, (E)	seriennummer(s):	zie op het apparaat	constructiejaar:	zie op het apparaat
E	Modelo:	7222ME, (E)	Número(s) de seire:	véase an la máquina	Año de construccion:	véase en la máquina
I	Modello:	7222ME, (E)	Numero(i) di serie:	vedi la targhetta sull'apparecchio	Anno di costruzione:	vedi la targhetta sull'apparecchio
S	modell:	7222ME, (E)	seriennummer:	se apparat	konstruktionsjahr:	se apparat
DK	model:	7222ME, (E)	seriennummer(re):	se apparatet	konstruktionsar:	se apparatet
N	model:	7222ME, (E)	seriennummer:	se apparatet	konstruktionsar:	se apparatet
SF	Malli:	7222ME, (E)	Sarjanumero/-numerot:	ks. työkalua	Valmistusvuosi:	ks. työkalua

D ...beschrieben in der beigelegten Dokumentation mit der EG-Maschinenrichtlinie 89/302/EEC, geändert durch 91/368/EEC, 93/44/EEC, und 93/68/EEC sowie der EG-Maschinenrichtlinie zur elektromagnetischen Kompatibilität 89/336/EEC, geändert durch die Richtlinien 91/263/EEC, 92/31/EEC, und 93/68/EEC entspricht.

F ...décrite dans les documents ci-joints est conforme à la directive sur les machines, relative aux exigences essentielles de santé et de sécurité 89/392/EEC, modifiée par les directives 91/368/EEC, 93/44/EEC et 93/68/EEC, et à la directive de compatibilité électromagnétique modifié par les directives 91/263/EEC, 92/31/EEC et 93/68/EEC.

GB ...described in the accompanying documentation conforms to the Essential Health and Safety Requirements of the Machinery Directive 89/392/EEC as amended by 91/368/EEC, 93/44/EEC and 93/68/EEC and the Electromagnetic Compatibility Directive 89/336/EEC as amended by 91/263/EEC and 93/68/EEC.

NL ...beschreven in de bijgevoegde documentatie voldoet aan de Essentiële gezondheids- en veiligheidsvereisten van de EG-machinerichtlijn, 89/392/EEC gewijzigd door 91/368/EEC, 93/44/EEC en 93/68/EEC, en de EG-elektromagnetische compatibiliteitsrichtlijn 89/336/EEC, gewijzigd door 91/263/EEC, 92/31/EEC en 93/68/EEC.

E ...descrita en al documentacion adjunta, se conforma a los requisitos esenciales de salud y seguridad de la Directiva de Maquinarias 89/392/EEC, enmendada por medio de la 91/368/EEC, 93/44/EEC y 93/68/EEC y la Directiva de Compatibilidad Electromagnética 89/368/EEC, enmendada por medio de 91/263/EEC, 92/31/EEC y 93/68/EEC.

I ...descritta nella documentazione di accompagnamento, soddisfa quanto prescritto in materia di Sicurezza e Salute di base dalla direttiva sulle macchine 89/392/EEC, modificata dalla direttive 91/368/EEC, 93/44/EEC e 93/68/EEC e dalla direttiva sulla compatibilità elettromagnetica 89/336/EEC, modificata dalle direttive 91/263/EEC, 92/31/EEC e 93/68/EEC.

S ...som beskrivs i bifogade dokumentation överensstämmer med väsentiga hälso- och säkerhetskrav i EG-riktlinjerna för maskiner 89/392/EEC, som ändrats genom EG-riktlinjerna 91/368/EEC, 93/44/EEC och 93/68/EEC samt EG-riktlinjerna för elektromagnetisk kompatibilitet 89/336/EEC, som ändrats genom EG-riktlinjerna 91/263/EEC, 92/31/EEC och 93/68/EEC.

DK ...beschreven in de bijgevoegde documentatie voldoet aan de Essentiële gezondheids- en veiligheidsvereisten van de EG-machinerichtlijn, 89/392/EEC gewijzigd door 91/368/EEC, 93/44/EEC en 93/68/EEC, en de EG-elektromagnetische compatibiliteitsrichtlijn 89/336/EEC, gewijzigd door 91/263/EEC, 92/31/EEC en 93/68/EEC.


N ...beskrives i vedlagte dokumentering som er i samsvar med Nødvendig Helso - og Sikkerhetskrav i EU-maskindirektiv 89/392/EEC, og revidert med EU-direktivene 91/368/EEC, 93/44/EEC og 93/68/EEC og Elektromagnetisk kompatibilitetsdirektiv 89/336/EEC, revidert med EU-direktivene 91/263/EEC, 92/31/EEC og 93/68/EEC.

SF ...joka on kuvattu oheisissa asiakirjoissa täyttää koneita koskevan direktiivin 89/392/EEC oleelliset terveys- ja turvallisuusvaatimukset, direktiivin 91/368/EEC, 93/44/EEC ja 93/68/EEC muutosten mukaisesti, sekä sähkömagneettista yhteensopivuutta koskevan direktiivin 89/336/EEC vaatimukset, direktiivin 91/263/EEC, 92/31/EEC ja 93/68/EEC muutosten mukaisesti.

D Name, Vorname: **Pfeiffer, Mark**
F Nom, Prénom: **Pfeiffer, Mark**
GB Surname, First Name: **Pfeiffer, Mark**
NL Naam, Voornaam: **Pfeiffer, Mark**
E Apellido, Nombre: **Pfeiffer, Mark**
I Cognome, Nome: **Pfeiffer, Mark**
S Namn, Fornamn: **Pfeiffer, Mark**
DK Navn, Fornavn: **Pfeiffer, Mark**
N Navn, Fornavn: **Pfeiffer, Mark**
SF Sukunimi, etunimi: **Pfeiffer, Mark**

D Stellung: **Executive V.P. of Mantis**
F Position: **Executive V.P. of Mantis**
GB Position: **Executive V.P. of Mantis**
NL Positie: **Executive V.P. of Mantis**
E Posición: **Vice Presidente Ejecutivo de Mantis**
I Posizione: **Executive V.P. of Mantis**
S Position: **Executive V.P. of Mantis**
DK Stilling: **Adm. direktor for Mantis**
N Stilling: **Adm. dir. for Mantis**
SF Asema: **Mantis, Varatoimitusjohtaja**

SOUTHAMPTON, PA USA JANUARY 9, 1997



D Ort. Datum, Unterschrift
F Lieu, Date, Signature
N Sted, og, Underskrift
GB Place, Date, Signature
NL Plaats, Datum, Handtekening
SF Paikka, Päivämäärä, Allekirjoitus

E Lugar y fecha, Firma
I Luogo e date, Firma
S Ort. datu, Underskrift
DK Sted, dato, underskrift

MANTIS®

MODEL 7222E, (ME)

D GERÄUSCHEMISSION
F EMISSION DU BRUIT
GB NOISE EMISSION
NL GELUIDSAFGIFTE
N LYDEMISJON

E EMISION DE RUIDO
I EMISSIONE DI RUMORE
S BULLERNIVÅ
DK STØJEMISSION
SF MELUEMISSIO

D Schalldruck am Ohr des Bedieners bei Ladebetrieb: 93dB(A)_{L_{eq}}
 Schalleistung 106L_{WA}

F Pression acoustique au niveau de l'oreille de l'opérateur à une charge de fonctionnement de 93dB(A)_{L_{eq}}
 Puissance acoustique de 106L_{WA}

GB Sound Pressure at operator's ear, at load operation: 93dB(A)_{L_{eq}}
 Sound Power 106L_{WA}

NL Geluidscrak bij het oor van de gebruiker, bij belast gebruik: 93dB(A)_{L_{eq}}
 Geluidsvermogen 106L_{WA}

N Lydtrukk ved operatørens øre, i løpet av lasteoperasjonen 93dB(A)_{L_{eq}}
 Bakke-kraft 106L_{WA}

E Pressione acustica all'orecchio dell'operatore, al momento dell'operazione di carico 93dB(A)_{L_{eq}}
 Potenza acustica 106L_{WA}

I Pressione acustica all'orecchio dell'operatore, al momento dell'operazione di carico 93dB(A)_{L_{eq}}
 Potenza acustica 106L_{WA}

Ljudtrycket vid användarens öra, i full drift: 93dB(A)_{L_{eq}}
 Ljudeffekt 106L_{WA}

DK Støjtryk ved operatørens øre ved belastningsdrift: 93dB(A)_{L_{eq}}
 Lydstryke 106L_{WA}

SF Äänenpaine koneekäyttäjän korvassaduormituksella 93dB(A)_{L_{eq}}
 Ääniteho 106L_{WA}

D SCHWINGUNGSMESSUNG:
F MESURE DE VIBRATION:
GB VIBRATION MEASUREMENTS:
NL TRILLINGMETIG:
N VIBERASJONSMÅLINGER

E MEDICIÓN DE VIBRACIONES:
I MISURA DELLA VIBRAZIONI:
S MÄTLING AV SVÄNGNINGEN:
DK VIBRATIONSÅLING
SF TÄRINÄN MITTAUKSET

RH*	LH*
x 4.9	x 5.15
y 2.48	y 3.53
z 3.17	z 6.19

*RH & LH =

GB ACCELERATION RIGHT HAND AND LEFT HAND

I ACCELERAZIONE MANO DESTRA E SINISTRA

D BESCHLEUNIG RECHTE HAND UND LINKE HAND

F ACCÉLÉRATION MAIN DROIT ET MAIN GAUCHE

DK PÅVIRKNING AF HØJRE HÅND OG VENSTRE HÅND

E ACELERACIÓN MANO DERECHA A MANO IZQUIERDA

S ACCELERATION HÖGER HAND OCH VÄNSTER HAND

NL VERSNILLING RECHTER HAND EN LINKER HAND

N AKSELERASJON HØYRE HÅND OG VINSTRE HÅND

SF OIKEAN JA VASEMMANPUOLEINEN KIIHDYTYS

LIMITED WARRANTY INFORMATION FOR MANTIS TILLER

Mantis extends only to the original consumer purchaser a limited warranty against defects in material and workmanship for a period of two years from date of purchase. This warranty covers all portions of the MANTIS Tiller.

MANTIS will repair or, at its option, replace any defective part or parts of the product free of charge. In the event of a defect or malfunction, the purchaser must return the product on an authorized Mantis dealer.

MANTIS assumes no responsibility in the event that the product was assembled or used in contravention of any assembly, care, safety, or operating instructions contained in the Owner's Manual; was not used with reasonable care; or was used for other than normal and intended purposes.

MANTIS MAKES NO EXPRESS WARRANTIES OR REPRESENTATION EXCEPT THOSE CONTAINED HEREIN. THE DURATION OF ANY IMPLIED WARRANTY, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. MANTIS DISCLAIMS ALL LIABILITY FOR INDIRECT AND/OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THAT ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Mantis
1028 Street Road
Southampton , PA 18966
(215) 355-9700

Specifications, descriptions, and illustrative material in this literature are as accurate as known at the time of publication, but are subject to change without notice.

P/N 4094
© Mantis 8/99
Printed in USA