



**MODEL:**

933330  
36 HYDRO MID-15 KAW Z-CTRL

934330  
48 HYDRO MID-17 KAW Z-CTRL

935330  
54 HYDRO MID-17 KAW Z-CTRL

# PARTS MANUAL

MAN 4160481  
Rev. C 12-2008

OPERATOR'S MANUAL 4160480



**CALIFORNIA  
Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.



**WARNING**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

**Californie Proposition 65  
Avertissement**

Les échappements des moteurs diesel et certains de leurs composés sont reconnus par l'Etat de Californie pour être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.



**AVERTISSEMENT**

L'émission du moteur de ce matériel contient des produits chimiques que l'Etat de Californie considère être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.

**California Advertencia  
de la Proposicion 65**

El estado de California hace saber que los gases de escape de los motores diesel y algunos de sus componentes producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.



**ADVERTENCIA**

El estado de California hace saber que los gases de escape de este producto contienen productos químicos que producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.

**CALIFORNIA  
Proposition 65 Warning**

Battery posts, terminals, wiring insulation, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.  
**WASH HANDS AFTER HANDLING.**

## IMPORTANT MESSAGE

Thank you for purchasing this Schiller Grounds Care, Inc. product. You have purchased a world class mowing product, one of the best designed and built anywhere.

This machine comes with an Operation and Safety Manual and a separate Setup, Parts and Maintenance Manual. The useful life and good service you receive from this machine depends to a large extent on how well you read and understand these manuals. Treat your machine properly, lubricate and adjust it as instructed, and it will give you many years of reliable service.

Your safe use of this Schiller Grounds Care, Inc. product is one of our prime design objectives. Many safety features are built in, but we also rely on your good sense and care to achieve accident-free operation. For best protection, study the manuals thoroughly. Learn the proper operation of all controls. Observe all safety precautions. Follow all instructions and warnings completely. Do not remove or defeat any safety features. Make sure those who operate this machine are as well informed and careful in its use as you are.

See a Schiller Grounds Care, Inc. dealer for any service or parts needed. Schiller Grounds Care, Inc. service ensures that you continue to receive the best results possible from Schiller Grounds Care, Inc. products. You can trust Schiller Grounds Care, Inc. replacement parts because they are manufactured with the same high precision and quality as the original parts.

Schiller Grounds Care, Inc. designs and builds its equipment to serve many years in a safe and productive manner. For longest life, use this machine only as directed in the manuals, keep it in good repair and follow safety warnings and instructions. You'll always be glad you did.

**Schiller Grounds Care, Inc.**  
**One Bob Cat Lane**  
**Johnson Creek, WI 53038-0469**

TABLE OF CONTENTS.....	FIGURES .....	PAGE
SAFETY.....		2
ASSEMBLY/SET-UP INSTRUCTIONS .....		3-10
LUBRICATION.....		11-13
MAINTENANCE .....		14, 15
SERVICE CHART.....		16
SERVICE RECORD .....		17
ADJUSTMENTS.....		18-21
BELT REPLACEMENT.....		22
PARTS SECTION.....		23
UPPER ENGINE DECK ASSY.....	FIGURE 1 .....	24, 25
LOWER ENGINE DECK ASSY/CLUTCH.....	FIGURE 2 .....	26, 27
DRIVE WHEELS .....	FIGURE 3.....	28, 29
PARKING BRAKE .....	FIGURE 4.....	30, 31
RECOIL START UPPER HANDLE.....	FIGURE 5.....	32, 33
TRACTION CONTROLS .....	FIGURE 6.....	34, 35
HYDRAULICS .....	FIGURE 7.....	36, 37
DECALS .....	FIGURE 8.....	38, 39
WIRE DIAGRAM-RECOIL START .....	FIGURE 9.....	40, 41
WIRING SCHEMATIC-RECOIL START .....	FIGURE 10.....	42
THIS PAGE LEFT BLANK INTENTIONALLY .....		43
CUTTERDECK MOUNTING .....	FIGURE 11 .....	44, 45
HYDROGEAR PUMP.....	FIGURE 12.....	46, 47
MOUNTING-36" FIXED DECK.....	FIGURE 13.....	48, 49
MOUNTING-48" FIXED DECK.....	FIGURE 14.....	50, 51
MOUNTING-54" FIXED DECK.....	FIGURE 15.....	52, 53
BAFFLES.....	FIGURE 16.....	54, 55
CASTER ASSY-FIXED DECKS.....	FIGURE 17.....	56, 57
SPINDLE ASSEMBLY .....	FIGURE 18.....	58, 59
CUTTERDECK DECALS.....	FIGURE 19.....	60, 61
WEIGHTS.....	FIGURE 20.....	62, 63

**NOTICE !!!**

Unauthorized modifications may present **extreme** safety hazards to operators and bystanders and could also result in product damage.

Schiller Grounds Care, Inc. strongly warns against, rejects and disclaims any modifications, add-on accessories or product alterations that are not designed, developed, tested and approved by Schiller Grounds Care, Inc.'s Engineering Department. Any Schiller Grounds Care, Inc. product that is altered, modified or changed in any manner not specifically authorized after original manufacture-including the addition of "after-market" accessories or component parts not specifically approved by Schiller Grounds Care, Inc.-will result in the Schiller Grounds Care, Inc. Warranty being voided.

Any and all liability for personal injury and/or property damage caused by any unauthorized modifications, add-on accessories or products not approved by Schiller Grounds Care, Inc. will be considered the responsibility of the individual(s) or company designing and/or making such changes. Schiller Grounds Care, Inc. will vigorously pursue full indemnification and costs from any party responsible for such unauthorized post-manufacture modifications and/or accessories should personal injury and/or property damage result.



This symbol means:  
**ATTENTION!**  
**BECOME ALERT!**

Your safety and the safety of others is involved.

**Signal word definitions:**

The signal words below are used to identify levels of hazard seriousness. These words appear in this manual and on the safety labels attached to Schiller Grounds Care, Inc. machines. For your safety and the safety of others, read and follow the information given with these signal words and/or the symbol shown above.

**⚠ DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **WILL** result in death or serious injury.

**⚠ WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

**⚠ CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **COULD** result in minor or moderate injury. It may also be used to alert against unsafe practices or property damage.

**CAUTION**

**CAUTION** used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, **MAY** result in property damage.

***Schiller Grounds Care, Inc.***

One Bobcat Lane  
Johnson Creek, WI 53038 U.S.A  
Phone: 920-699-2000  
Fax: 920-699-3683

MODEL NUMBER

SERIAL NUMBER

**MODEL NUMBER:** This number appears on sales literature, technical manuals and price lists.


**SERIAL NUMBER:** This number appears only on your mower. It contains the model number followed consecutively by the serial number. Use this number when ordering parts or seeking warranty information.




**GENERAL NOTE: FRONT, REAR, RIGHT HAND AND LEFT HAND REFERENCES BELOW ARE WITH RESPECT TO AN OPERATOR AT THE CONTROLS.**

1. UNCRATE - Place shipping crate on a level surface and remove sides and top.


2. Remove shipping brackets **A**, at all (4) locations.




3. Remove wire ties **B** securing tires, upper handle and rods. Set aside for later use.




4. Raise the rear of the machine at location **C** and support with jackstands.




5. Install upper handle **B** to lower handle **D** using (2) 3/8-16 X 1" bolts and (2) 3/8-16 nuts, and (2) 3/8-16 X 1-1/2" bolts and (2) 3/8-16 nuts at location **F** provided in parts bag.




6. Install upper handle **B** to lower handle **D** using (2) 3/8-16 X 1" bolts and (2) 3/8-16 nuts removed in Step 5 at location **E**, and (2) 3/8-16 X 1-1/2" bolts and (2) 3/8-16 nuts at location **F**.




7. Install (2) springs **P** and (2) 3/8-16 nylon locknuts **M** from parts bag onto bolt **F** on each side of the machine. Attach springs to bolts on neutral return brackets **N** as shown.




8. Open the bypass valves **X** on each pump by rotating handle counter-clockwise two revolutions.




9. Cut and remove wire ties **S** from the control levers **A**. Place the control levers in the neutral position in the control panel.





10. Install the tracking control assembly **W** removed in Step 4 on the left hand control **Z** using pins **U**. Adjust swivel **X** to align with pump arm **Y**. Install pin **U** and tighten jam nut **V**.



11. Install the right hand control rod **J**, the shorter of the remaining rods removed in Step 4, on the right hand control **G** using (2) pins **H** from the parts bag. Adjust swivel **L** to align with pump arm **K**. Install pin **H**.




12. Insert threaded end of brake rod **Q** through the slot on the engine deck and attach the other end to the brake control arm **R** and secure in place with hairpin **S** as shown.






13. Connect swivel on threaded end of brake rod **Q** to the brake arm **T** and secure in place with hairpin **S** as shown. Adjust swivel to provide adequate braking when the brake control arm is engaged. See adjustment section of this manual.



14. Close bypass valves **X** by rotating clockwise until firmly seated.



15. Attach cutterdeck per the instructions on the following pages then return to Step 25 of this section.

16. Fill engine with oil. (See engine manual for specifications.)

17. Fill fuel tank with clean, fresh unleaded fuel.



**WARNING** GASOLINE IS HIGHLY FLAMMABLE!

- Fill fuel tank with good quality, clean, regular unleaded gasoline.
- Do not use hi-test fuel.
- Do not smoke.
- Do not spill fuel.
- Fill outdoors.
- Do not overfill. Fill to 1" below bottom of filler neck to allow room for expansion.
- USE A FUNNEL TO FILL GAS TANK

18. Check oil level in hydraulic oil reservoir and adjust as necessary.

19. Adjust tire pressure in drive wheels and casters to 14 psi (1 kg/cm<sup>2</sup>).

20. Before attempting to start the mower, read and understand all sections of the Operation & Safety manual.

**NOTICE:** Special setup instructions.

- Before engaging the cutterdeck, run the engine for five minutes at full RPM. This is recommended for new engine installation to permit complete engine lubrication prior to load.
- Do not engage the cutterdeck at full throttle. Set the throttle half way between the highest and lowest engine speed, engage the PTO switch and increase the engine speed to full before cutting.



- Do not use this machine without an approved grasscatcher, grass discharge chute or mulching plate(s) correctly fitted.


**CUTTERDECK ATTACHMENT:** Two types of cutterdeck mounting systems are available, fixed and floating. Fixed mounting rigidly attaches the cutterdeck to the power unit. Floating mounting allows the cutterdeck to move independent of the power unit providing a more uniform cut. Follow the appropriate instructions below for the type of cutterdeck being attached to the power unit.




### FIXED CUTTERDECK ATTACHMENT

1. Remove the cutterdeck from the crate.
2. Unbolt the caster wheels and the shipping brackets from the crate.
3. Remove the shipping bracket from the caster wheel by loosening the caster bolt and sliding the shipping bracket off and retighten caster bolt.
4. Remove quick pin and remove the appropriate number of spacers for the desired height of cut. See height of cut chart below.

**NOTE:** Height of cut chart is also located on bottom of belt cover or in the Operation & Safety Manual.


5. Repeat for other caster wheel assembly.




 CUTTING HEIGHT		 A (1/8") B (1/4") C (1/2")			 DECK PIN POSITION		4109861 NUMBER OF SPACERS BETWEEN SPINDLE AND BLADE (1/4" THICK)
		A	B	C			
1.375	35	1	1	0	5		2
1.625	41	1	1	0	5		1
1.875	48	1	1	0	5		0
2.125	54	1	0	2	4		2
2.375	60	1	0	2	4		1
2.625	67	1	0	2	4		0
2.875	73	1	1	3	3		2
3.125	79	1	1	3	3		1
3.375	86	1	1	3	3		0
3.625	92	1	0	5	2		2
3.875	98	1	0	5	2		1
4.125	105	1	0	5	2		0
4.375	111	1	1	6	1		2
4.625	118	1	1	6	1		1

6. Remove belt cover and set aside.
7. Block the rear of the cutterdeck with the appropriate height block for the desired height of cut **B**. See Support Block Chart below.


CUTTING HEIGHT	HOLE POSITION ON ENGINE DECK*	BLOCK HEIGHT AT REAR OF DECK (B)
1.375" - 1.625"	5	1.25"
1.875" - 2.375"	4	2.00"
2.625" - 3.125"	3	2.75"
3.375" - 3.875"	2	3.50"
4.125" - 4.625"	1	4.25"
* Position 1 is the highest hole on the engine deck.		



8. Position the power unit behind the cutterdeck.
9. Move the power unit towards the cutterdeck until the guide pins **A** engage the appropriate hole **C** on the power unit for the desired height of cut. Fasten with (4) M12-1.75 X 30 bolts at **D**.
10. Loop the PTO belt **E** around the electric clutch pulley. Using a 3/8" ratchet wrench or 3/8" breaker bar rotate the PTO belt idler while looping the PTO belt around the cutterdeck pulley.



11. Reinstall belt cover and fasten in place with knobs **F**.
12. Remove support block from the rear of cutterdeck.
13. Remove support from the rear of the power unit.






### MACHINE LUBRICATION

Every 50 Working Hours - Lubricate the following points with grease:

- 1) Caster wheel pivots (2 points)
- 2) Neutral eccentric pin (2 points)
- 3) Idler pivot bearings:
  - a) Engine to cutterdeck belt tensioner
  - b) Cutterdeck belt tensioner
  - c) Hydro drive belt tensioner

**NOTE:** The spindles used on these machines use a superior sealed bearing which does not require relubrication.



## ENGINE

### DAILY



Remove the dipstick **S** and check that the oil level reaches the full mark. If necessary, top off with fresh oil. To obtain the correct oil level, the machine must be level. See engine manufacturer's manual for proper oil viscosity and grade.  
**DO NOT OVER FILL!**

### AFTER THE FIRST 5 WORKING HOURS

While the engine is warm, remove the drain plug **P** and drain the crankcase. Replace oil filter **T**. Clean and replace the plug. Fill the crankcase through the filler hole with fresh oil to the full mark. See engine manufacturers manuals for oil and filter change intervals.

Engine operator's manuals are shipped with each machine. Shop manuals for the engines are available from your local engine dealer.

- For Kawasaki FH541V, order: 99924-2045-08




### HYDRAULIC RESERVOIR CHECK, DRAIN AND FILL

Check level every 100 hours or when a leak has occurred. To check level: Remove reservoir cap. Add 10W30 oil until the oil level reaches the bottom of the filler tube. Do not overfill.

#### EVERY 500 HOURS:

Change hydraulic oil and filter. Remove plug **D** to drain reservoir. Remove and replace filter. Filter is located on front of tank at **G**. Reinstall plug and fill with 10W30 oil to the bottom of the filler tube **F**.



## ENGINE - KAWASAKI KAI

The maintenance schedule detailed is for average operating conditions. Under extreme conditions (dusty, dirty or more than 8 hrs continuous use) maintain more frequently.

### Oil (daily)

Remove the dipstick **N** and check that the oil level reaches the full mark. If necessary, top off with fresh oil. To obtain the correct oil level, the machine must be level. See engine manufacturer's manual for proper oil viscosity and grade. **DO NOT OVER FILL!**

### AFTER THE FIRST 5 WORKING HOURS

While the engine is warm, remove the drain plug **T** and drain the crankcase. Replace oil filter **U**. Clean and replace the plug. Fill the crankcase through the filler hole with fresh oil to the full mark. See engine manufacturers manuals for oil and filter change intervals.

### Cooling Fins and Air Intake screen (daily)

Ensure that the cooling fins and air intake screen **W** are cleaned daily. Continued operation with a clogged cooling system will cause severe overheating and result in engine damage.

### Air Cleaner




Dual element air cleaners have a paper air cleaner element **Z** with an oiled, foam precleaner element **V** on the dirty side of the paper element. Both should be inspected regularly and maintained.

Clean and re-oil precleaner element every 25 hours (more often under dusty conditions).

1. Disassemble air cleaner cover **F**.
2. Remove precleaner **V** by sliding it off the paper cartridge **Z**.
3. Wash precleaner in kerosene or liquid detergent and water.
4. Wrap precleaner in cloth and squeeze to remove cleaner.
5. Saturate precleaner in engine oil. Squeeze to remove excess oil.
6. Re-install precleaner over paper cartridge. Reassemble air cleaner components and screw assembly **X** down tight.

Every 100 hours (more often under very dusty or dirty conditions), check the paper cartridge.

- Clean by tapping gently.
- Do not wash the cartridge or use compressed air
- Replace when cartridge is dirty, bent or damaged.



## Blade Sharpening

Blades may be sharpened by filing or grinding, but with either method the balance of the blades must be maintained at 5/8 oz/in or less. Failure to maintain balance causes excess vibration, wear and shortened life of not only the blades, but most all components of the machine. To balance a blade after sharpening: attach 1/8 oz of weight 5" from center on the light end. This should make the light end the heavy end. If it does not: File or grind the heavy end until the addition of weight makes the light end the heavy end.



### NOTE:

- Do not overheat or weaken the blades.
- Do not straighten bent blades. Replace with new Schiller Grounds Care, Inc. blades.  
If lift portion of blade is worn thin replace with a new Schiller Grounds Care, Inc. blade.
- ALWAYS replace with Schiller Grounds Care, Inc. blades—do not use another manufacturer's blades as this could be dangerous.
- Replace cracked or bent blades.

## BLADE REMOVAL

**NOTE:** Follow these instructions to prevent injury when bolt releases.

1. Use a box wrench or socket with a long breaker bar to remove spindle bolt under cutterdeck.
2. Slip tube over breaker bar or wrench if necessary to gain leverage.
3. Keep hands clear as blades may rotate when bolt releases.
4. When changing blades, wear thickly padded gloves.
5. Block blades from turning by using a piece of wood.



**Cutterdeck Pulley Assembly**

**NOTE:** To prevent blade from turning, place block of wood at **A**, with grain perpendicular to blade.

## BLADE RE-INSTALLATION

1. Place the desired number of spacers (no more than 2) on the spindle bolt below the cutterdeck between the blade and spindle shaft.
2. Insert the cutter spindle bolt (from bottom) complete with washer, blade and spacers.
3. Place remaining spacer(s) on the spindle bolt above the cutterdeck between the conical washer and nut (as shown). Replace nut and tighten to 70 ft-lbs.

## SPARK PLUG

- Remove plug and check condition.
- Good operating conditions are indicated if the plug has a light grey or tan deposit. A white blistered coating may indicate overheating. A black coating usually means an "over rich" fuel mixture caused by a clogged air cleaner or improper carburetor adjustment. Do not sandblast, wire brush or otherwise try to clean a dirty plug. Best results are obtained with a new plug.
- See engine manufacturers manual for proper spark plug gap.

## SERVICE CHART

## Hydro Midsize

**NOTE: CHANGE ENGINE OIL AND FILTER AFTER FIRST 5 HOURS OF OPERATION.**

<b>SERVICE OPERATION</b>	<b>FIRST 5 HOURS</b>	<b>DAILY</b>	<b>EVERY 25 HOURS</b>	<b>EVERY 50 HOURS</b>	<b>EVERY 100 HOURS</b>	<b>EVERY 500 HOURS</b>
<b>ENGINE</b>						
Check Oil Level		X				
Check for Oil & Air Leaks		X				
Clean Air Intake		X				
Clean Air Cleaner		X				
Change Oil & Filter*	X	SEE ENGINE MANUFACTURER'S MANUAL *				
Clean Fuel Sediment Bowl				X		
Replace/Adjust Spark Plug	SEE ENGINE MANUFACTURER'S MANUAL					
<b>HYDRAULIC OIL RESERVOIR</b>						
Check Oil Level		X			X	
<b>MACHINE</b>						
Check Tire Pressures		X				
Lubricate All Points				X		

Consult the manufacturer's manual for your engine for further information and instructions.

## This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. There are no margins, text, or other markings on the paper.


**NOTE: After first 5 hours of operation replace engine oil and filters.**



**NOTE:** Make all adjustments with the engine shut off, spark plug wire disconnected and mower drive disengaged.

### Speed Control Bar

The speed control bar **F** is held by friction pads. If the setting will not hold, tighten knob **E** to increase friction on speed control bar **F**.



### PARKING BRAKE



Apply parking brakes and open the bypass valves on the hydraulic pumps. Try to push the machine forward. If wheels rotate, adjust brakes as follows.

#### TO ADJUST:

1. Remove the hairpin cotter **A** from the brake rod at the brake lever **C** as shown.
2. Slide the brake rod out of the brake lever and turn the rod in or out of the brake swivel **B** as needed.

**NOTE:** The brake should initially be adjusted so that the brake rod extends through swivel **B** 1-1/4" as shown. If more brake pressure is required adjust as necessary.

3. Reassemble brake rod to the brake lever using hairpin **A** removed in Step 1.
4. Apply parking brakes and try to push the machine forward. If wheels rotate, readjust brakes.
5. Close bypass valves on the hydraulic pumps.






**TRACTION DRIVE HYDROSTAT ADJUSTMENTS:** The following adjustments must be done in order.

### STEP 1 - Set Neutral



Neutral is set at the factory. If it should require adjustment, raise the wheels off the ground by supporting the machine on jackstands or blocks. Disconnect the control rod **A** at each pump end. Loosen bolt **S** securing the neutral plate eccentric shaft just enough to turn the shaft. Start the engine and run at low speed. Turn eccentric shaft **T** to raise or lower the point at which the follower bearing is held in the center of the "V" until the wheels stop turning. Tighten the eccentric shaft bolt. Increase the throttle setting and check the adjustment. Readjust if necessary. Shut the engine off before proceeding to Step 2.



### STEP 2 - Adjust Control Rods

First adjust neutral, as outlined in Step 1. Set control levers to neutral. Adjust swivels **B** on lower ends of control rods **A** so they just go into the holes on the pump arm control plates.

After adjusting swivel **B** on left side, tighten jam nut **C**.




### TRACKING ADJUSTMENT TURNBUCKLE

The tracking adjustment turnbuckle provides tracking control to correct for any hydraulic circuit or linkage differences from one side to the other.


To correct tracking:

1. Loosen wingnut **X**.
2. Rotate the tracking adjustment turnbuckle **Y** to the right to make the machine track to the right.
3. Rotate the tracking adjustment turnbuckle **Y** to the left to make the machine track to the left.
4. Tighten wingnut **X**.




### CONTROL LEVERS

The control levers are controlled by spring tension, and require no adjustment.



### HANDLE BAR HEIGHT ADJUSTMENT


To adjust handle bar height: Remove swivel **B** at each pump control arm and the parking brake rod. Remove bolts **G** and loosen bolts **E** on each side of handlebars. Raise or lower as required. Reposition upper handle and reinsert bolts at location **G** into appropriate hole in lower handle and tighten. Readjust control rods and swivels and reinstall. Readjust parking brake and rod.



### TRACK WIDTH ADJUSTMENT

The track width originally set from the factory can be increased an additional 3-1/4" overall by performing the following steps.

1. Loosen wheel lug nuts on both drive tires.
2. Raise rear of unit so that drive tires are off the ground. Support the unit with jack stands.
3. Remove wheel lug nuts and wheels. Reattach wheels with the tires rotated so the wheel offset is the opposite of when they were previously installed. Install and tighten lugnuts until they are snug
4. Lower machine off of the jack stands and torque wheel lug nuts to 85 ft-lbs.



### TIRE PRESSURE ADJUSTMENT

Tire pressures should be maintained at 14 psi (1.0 kg/cm<sup>2</sup>).



### PTO BELT

1. Rotate idler arm using a 3/8" ratchet or breaker bar and remove belt.




### CUTTERDECK BELT

1. Remove PTO belt.
2. Rotate idler arm using a 3/8" ratchet or breaker bar and remove belt.
3. Replace in the reverse order.



### PUMP-DRIVE BELT

1. Remove PTO belt from the engine clutch.
2. Disconnect the clutch wire harness.
3. Unbolt clutch bracket from clutch and rotate the clutch to allow enough clearance to remove the clutch bracket.
4. Rotate idler arm using a 3/8" ratchet or breaker bar inserted into the square hole in the idler arm.
5. Remove pump-drive belt.
6. Replace by following steps in reverse order.



View under engine deck


# PARTS SECTION



# UPPER ENGINE DECK ASSY

Hydro  
Midsized

FIGURE 1



# Hydro Midsize

## UPPER ENGINE DECK ASSY

FIGURE 1

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1-1	4130320	CAP-FUEL GASOLINE 3.5	1				
1-2	4163068-1	TANK-FUEL (INCLUDES ITEM 4)	1				
1-3	4163016	GROMMET-FUEL TANK	1				
1-4	4163012	S FUEL SHUT-OFF VALV	1				
1-5	88042N	HOSE CLAMP	4				
1-6	4162977-007	HOSE,.25IDX.50OD X 8"L 6A - CUT TO 6" LONG 6B - CUT TO 5" LONG	1				
1-7	38666	FILTER, FUEL	1				
1-8	4131068.2	WLDMT-DECK ENG HYDRO	1				
1-9	64123-39	BOLT-HEX 1/2-13X1-1/4	6				
1-10	64229-05	LOCKNUT, 1/2-13 NYLON	6				
1-11	64002-04	LOCKWASHER, EXT. 5/16	1				
1-12	64163-31	WASHER, 25/64X1X12	3				
1-13	64006-03	LOCKWSHR-HELICAL 3/8	4				
1-14	64205-018	BLT MET M8-1.25 X 15	1				
1-15	64229-02	LOCKNUT-NYLON 5/16-18	4				
1-16	2306127	S-HYD RESEVOIR W/LABS	1				
1-17	64123-15	BLT-HEX 3/8-16X3/4	4				
1-18	4120917.7	HANDLE-LOWER, HYDRO	1				
1-19	64018-9	BLT-CRG 5/16-18 X 3/4	4				
1-20	38542	CLAMP-DOCU TUBE	2				
1-21	64006-01	LOCKWSHR-HELICAL 1/4	2				
1-22	64123-89	BLT-HEX 1/4-20 X 3/4	2				
1-23	38061A	SHIELD-SPINDLE	2				
1-24	2306144	S DOCU TUBE W/LAB	1				
1-25	48255-01	STREET ELBOW 90DEG 3/8	1				
1-26	4156981	ENG-17HP KAW KAI W/CHG (USED ON 934330 AND 935330 MODELS)	1				
	4156980	ENG-15HP KAW KAI W/CHG (USED ON 933330 MODEL ONLY)	1				
	2722214	OIL FILTER					
	4153902	AIR FILTER PAPER ELEMENT					
	4153903	FILTER FOAM PRECLEANER					
1-27	48228-2A	CLAMP-3/4 CLIP	1				
1-28	4158114	MUFFLER-15HP KAW (USED ON 933330 MODEL ONLY)	1				
	4158116	MUFFLER-17HP KAW (USED ON 934330 AND 935330 MODELS)					

FIGURE 2






FIGURE 2

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
2-1	2721647	PULLEY-4.50E.O.D.	1				
2-2	64163-31	WASHER, 25/64 X 1 X 12	11				
2-3	2721110	CLUTCH-ELECTRIC	1				
2-4	2721331.7	WLDMT-CLUTCH STOP MID	1				
2-5	2721642	BELT-HA 49.0	1				
2-6	2722244	PULLEY- A SECTION 4.50	2				
2-7	38304-03	BRG-FLANGED PLASTIC	1				
2-8	4121540	PIN-CLUTCH	1				
2-9	64123-15	BLT-3/8-16 X 3/4	1				
2-10	2721641.7	WLDMT-IDLER	1				
2-11	4116712	PIN-PIVOT	1				
2-12	64163-65	WASHER-.890X1.375X18GA	6				
2-13	64205-013	BLT-MET M6-1 X 12	2				
2-14	64123-138	BLT-HEX 3/8-16X3-3/4	1				
2-15	64229-03	LOCKNUT-NYLON 3/8-16	7				
2-16	2308000	PULLEY-IDLER 4.00 EOD	1				
2-17	33148-01	SPACER	1				
2-18	38219	SPRING-TENSION	1				
2-19	64123-87	BLT-HEX 3/8-16 X 1-3/4	1				
2-20	64141-4	NUT-WLF 3/8-16	3				
2-21	64163-51	WSHR.453 X 1.38 X 7GA	1				
2-22	64197-005	BLT-TDFM 3/8-16X1-1/4	4				
2-23	64123-155	BLT-HEX 7/16-20 X 3	1				
2-24	64006-06	LOCKWSHR-HELICAL 7/1	1				
2-25	64123-54	BOLT, 5/16-18X3/4 HEX	2				
2-26	64163-03	WSHR-.256ID X.62DX18GA.	2				
2-27	64229-02	LOCKNUT-NYLON 5/16-18	2				
2-28	64164-12	1/4X1/4X1 SQ END KEY	1				
2-29	64123-75	BOLT, 3/8-16X3 HEX	2				
2-30	2720949	ASSY-CLUTCH WIRE	1				
2-31	4163316	PUMP-HYDRO LH	1				
2-32	4163317	PUMP-HYDRO RH	1				
2-33	2721541	PULLEY-IDLER 5 IN	1				
2-34	2721401.7	WLDMT-IDLER ARM	1				
2-35	64163-61	WSHR .81X.406X16GA	1				
2-36	64123-16	BLT-HEX 3/8-16X1-1/4	4				
2-37	2188131	SPRING-EXTENSION	1				
2-38	4131068.2	WLDMT-DECK ENG HYDRO	1				
2-39	4116691	PIN-PIVOT	1				
2-40	64123-70	BOLT-HEX 3/8-16X1-1/2	1				
2-41	64044-6	SCREW-SET 5/16-18 X 1/4	4				
2-42	64238-03	KEY-MET 5MM SQ X 28	2				
2-43	64209-09	WASHER-CONICAL SPRING	2				
2-44	64221-04	E-RING.875	2				

FIGURE 3




FIGURE 3

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
3-1	4131068.2	WLDMT-DECK ENG HYDRO	1				
3-2	2721620.7	WLDMT-HUB	2				
3-3	2721956	ASSY-WHEEL 16 X 7.50 X 8	2				
	2721956-01	TIRE-16X7.50X8 MLTI TRC	1				
	2721956-02	WHEEL W/ DUAL VALVES	1				
3-4	64267-01	NUT-HEX FLANGED 1/2-20	8				
3-5	64025-06	NUT-HEX 3/4-16 2A	2				
3-6	2308051	MOTOR-WHEEL ROSS MF	2				
3-7	64141-13	NUT WLF 1/2-13	8				
3-8	64164-28	KEY-WOODRUFF	2				
3-9	64123-72	BLT-HEX 1/2-13X2-1/2	8				

FIGURE 4





FIGURE 4

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
4-1	4131746	WLDMT-BRAKE SHAFT	1				
4-2	33103	SWIVEL	1				
4-3	64168-2	COTTER-HAIRPIN.08X1.19	2				
4-4	64001-6	NUT-HEX JAM 3/8-16	1				
4-5	64123-138	BLT-HEX 3/8-16X3-3/4	1				
4-6	2188131	SPRING-EXTENSION	1				
4-7	64163-17	25/64 X 2 X 11GA WASHR	1				
4-8	64171-2	WAVE WASHER	1				
4-9	4131072.7	PLATE-BRK SHFT RETNR	2				
4-10	64123-50	BOLT-HEX 3/8-16X1	3				
4-11	64123-16	BLT-HEX 3/8-16X1-1/4	1				
4-12	38404-01	GRIP,CONTROL LEVER	1				
4-13	4116495.7	LEVER-BRAKE ARM	1				
4-14	64229-03	LOCKNUT-NYLON 3/8-16	5				
4-15	4135058	ROD-BRAKE	1				

[illegible]

## Midsize



# Hydro Midsize

## RECOIL START UPPER HANDLE

FIGURE 5

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
5-1	4120259	S-UP HNDLE W/ LABELS	1				
5-2	64018-9	BLT-CRG 5/16-18X3/4 G5	1				
5-3	64229-02	LOCKNUT-NYLON 5/16-18	1				
5-4	64152-46	SCREW-SLT HH 10-24X1/2	2				
5-5	64123-07	BOLT, 1/4-20X1-1/2 HEX	2				
5-6	64229-01	LOCKNUT-NYLON 1/4-20	2				
5-7	64163-61	WSHR .81X.406X16GA	1				
5-8	4116398	BSHG-IGUS, .50 IDX.13 THK	10				
5-9	64221-05	E-CLIP, .328 ID	8				
5-10	4118586.2	PANEL-COVER, HYDRO	1				
5-11	4118392	ROD-REVERSE ASSIST	1				
5-12	64229-05	LOCKNUT, 1/2-13 NYLON	2				
5-13	38357-06	CONTROL-THROTTLE	1				
5-14	64025-15	NUT-HEX #10-24 KEPS	2				
5-15	4120917.2	HANDLE-LOWER, HYDRO	1				
5-16	64141-4	NUT-WLF 3/8-16	4				
5-17	64123-70	BOLT-HEX 3/8-16X1-1/2	2				
5-18	64123-50	BOLT-HEX 3/8-16X1	2				
5-19	4114727	KNOB-SPEED CONTROL	1				
5-20	64215-05	RIVET-POP IFI# 64	5				
5-21	2308066	WSHR-FRICTION	2				
5-22	4116405.2	WLDMT-SPEED CONTROL	1				
5-23	38148	SWITCH-ENGINE STOP	1				
5-24	2721505	SWITCH-PTO	1				
5-25	4116374	BAR-HYDRO CONTROL	2				
5-26	4116404	WLDMT-RH CNTRL, HYDRO	1				
5-27	4116403	WLDMT-LH CNTRL, HYDRO	1				
5-28	4116953.2	PLATE-PIVOT SHAFT	2				
5-29	64152-23	1/4-20X3/8 LG SP SCREW	6				
5-30	108208	SWITCH-OP PRESENCE	2				
5-31	64197-015	BLT-TDFM 10-32X1/2 TORX	4				
5-32	4119625	BHSG-CONTROL LEVER	2				
5-33	4116376	TUBE-CONTROL	2				
5-34	4117741	GRIP-MOTION LVR, MIDSZE	2				
5-35	4116380	SPACER-CONTROL	2				
5-36	4118378	SPRING-EXTENSION	2				

FIGURE 6







FIGURE 6

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
6-1	4120259	S-UP HNDL W/ LBLS, HYD	1				
6-2	64123-70	BOLT-HEX 3/8-16X1-1/2	2				
6-3	4120917.7	HANDLE-LOWER, HYDRO	1				
6-4	64123-02	BLT-HEX 3/8-24X1	2				
6-5	64006-03	WSHR, 3/8 HELICAL LOCK	2				
6-6	64163-61	WSHR .81X.406X16GA	2				
6-7	64141-4	NUT-WLF 3/8-16	2				
6-8	4119746	SPRING-NEUTRAL RETURN	2				
6-9	64229-03	LOCKNUT-NYLON 3/8-16	2				
6-10	64123-68	BOLT-HEX 5/16-18X1	2				
6-11	64141-6	NUT, 5/16-18	6				
6-12	2721617.7	WLDMT-SPEED CONTROL	2				
6-13	2303058	SHAFT-ECCENTRIC (HEX)	2				
6-14	64163-06	WASHER	2				
6-15	2308076-02	BEARING-PLASTIC	2				
6-16	64144-16	RING,CLIP-.75X.062	2				
6-17	85010N	ZERK, 1/4-28 STR SLFTHRD	2				
6-18	2228065	DAMPENER	2				
6-19	64123-56	BLT-HEX 5/16-18X2	2				
6-20	38372	BEARING-BALL	4				
6-21	64163-02	WSHR-.321X.593X11GA	2				
6-22	4114742.7	WLDMT-RH PUMP CNTRL	1				
6-23	4114745.7	WLDMT-LH PUMP CNTRL	1				
6-24	64237-05	LOCKNUT-NYLON M8-1.25	4				
6-25	64192-04	SET SCREW SQ 5/16-18X5/8	2				
6-26	33103	SWIVEL	2				
6-27	4121937	ROD-RH CONTROL	1				
6-28	4121897	ROD-LH CONTROL, UPPER	1				
6-29	4121898	TURNBUCKLE-3/8-16	1				
6-30	64214-02	NUT-WING 3/8-16	1				
6-31	4121896	ROD-LH CONTROL, LOWER	1				
6-32	64168-2	COTTER-HAIRPIN.08X1.19	7				
6-33	2306127	S HYD RESERVOIR W/LABS	1				
6-34	64001-6	NUT-HEX JAM,3/8-16	1				

FIGURE 7



## FIGURE 7


ITEM	PART NO.	DESCRIPTION	QTY
7-1	58026-01	3-WAY CONNECTOR	2
7-2	108029	PLUG, MAGNETIC	1
7-3	158058-04	FITTING-90 BARB, ADJ.	2
7-4	108205-02	ELBW-MALE 45 8X8 37-ORB	4
7-5	88042-04	CLAMP-HOSE 5/8"	12
7-6	2720396	FLTR, 25 MCRN SM CAM	1
7-7	69060-01	FTG-BARB 9/16 X 3/8 ST	2
7-8	69216.7	CAP-RESERVOIR	1
7-9	64123-60	BOLT, 1/4-20X2 HEX	2
7-10	64229-01	LOCKNUT-NYLON 1/4-20	2
7-11	2306127	S HYD RESER W/LABS	1
7-12	2308051	MOTOR WHEEL ROSS	2
7-13	2692300-01	HOSE-1/2 37/ORB X 18.5 LG	2
7-14	2692300-02	HOSE-1/2 37/ORB X 18.5 LG	2
7-15	4163317	PUMP-HYDRO RH	1
(SEE FIG 16 FOR PARTS BREAKDOWN)			
7-16	4163316	PUMP-HYDRO LH	1
(SEE FIG 16 FOR PARTS BREAKDOWN)			
(69053-05 IS A SERVICEABLE LENGTH OF 55")			
7-17	69053-05	3/8 HI TEMP HOSE 17.0"	1
7-18	69053-05	3/8 HI TEMP HOSE 5.0"	1
7-19	69053-05	3/8 HI TEMP HOSE 5.0"	1
7-20	69053-05	3/8 HI TEMP HOSE 7.5"	1
7-21	69053-05	3/8 HI TEMP HOSE 6.8"	1
7-22	69053-05	3/8 HI TEMP HOSE 12.0"	1

### SERVICEABLE HYDRAULIC O-RINGS

SAE PORT 'O' RING		
PART NUMBER	THREAD SIZE	AS-568#
158061-10	9/16-18	-906
158061-11	3/4-16	-908
158061-12	7/8-14	-910
158061-13	1-1/16-12	-912
158061-14	1-5/16-12	-916
158061-16	1-5/8-12	-920
158061-03	1-7/8-12	-924

**NOTE:**  
**DO NOT use sealant tape on any hydraulic fittings. Use a liquid pipe sealant.**

FIGURE 8



### FIGURE 8

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
8-1	4119905	LABEL-CTRL PNL HYD	1				
8-2	2000672	LABEL-PARKING BRAKE	1				
8-3	2000570	LABEL-WARN FUEL PICT	1				
8-4	340830	DECAL-CAUTION SPANISH	1				
8-5	2000571	LABEL-IMPORTANT	1				
8-6	4158402	LABEL-BOBCAT, S	2				
8-7	2000572	LABEL-WARNING BLADES	1				
8-8	2000677	LABEL-DANGER/WARNING	1				
8-9	2000678	LABEL-ROT PRTS/B-WSHR	2				
		(LOCATED UNDER BELT COVER)					
8-10	2000704	LABEL-MIDSIZE PATENT	1				
8-11	2000673	DECAL - OP MAN/TIRES	1				
8-12	2000661	LABEL-HYD TANK WARN	1				
8-13	4120256	LABEL-Z CONTROL	1				
8-14	4158401	LABEL-BOBCAT, L	1				
8-15	4120215	LABEL-SPEED CONTROL	1				
8-16	00214-10	DECAL-PATENT NUMBER	1				
8-17	4163037	LABEL-DURADECK	1				

# WIRE DIAGRAM-RECOIL START

Hydro  
Midsized

FIGURE 9




FIGURE 9

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
9-1	2721110	CLUTCH-ELECTRIC (INCLUDES ITEM 2)	1				
9-2	2720949	ASSY-CLUTCH WIRE	1				
9-3	4131438	HARNESS-MID GEAR DRV (INCLUDES ITEM 6)	1				
9-4	38148	SWITCH-ENGINE STOP	1				
9-5	108208	SWITCH DBL POLE NC/NO	2				
9-6	148082-10	FUSE 10 AMP	1				
9-7	2721505	SWITCH-PTO	1				
9-8	4131439	JUMPER-GEAR DRIVE	1				



FIGURE 10






FIGURE 11




FIGURE 11

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
11-1	64263-018	BLT-FLG HD M12-1.75 X 30	4				
11-2	64246-04	NUT-WHIZ M12-1.75	4				

FIGURE 12




FIGURE 12

**4112782 & 4163317 PUMP-HYDRO RH ILLUSTRATED AS SHOWN**  
**2721615 & 4163316 PUMP-HYDRO LH ILLUSTRATED AS SHOWN EXCEPT GROUP A IS ROTATED 180° AROUND THE CENTERLINE OF THE PUMP.**

12-1	70516	----	HOUSING KIT	1
12-2	*70517	----	END CAP KIT	1
	^71615	----	END CAP KIT	1
12-3	50641	----	STRAIGHT HEADLESS PIN	2
12-4	50969	2721615-01	FLANGE BOLT M8-1.25 X 60	4
12-5	*51232	2721615-02	HOUSING O-RING	1
	^52629	4163316-01	HOUSING O-RING	1
12-6	2513027	2721615-03	CHARGE PUMP KIT (STD)	1
12-7	50273	2721615-04	STD GEROTOR ASSEMBLY	1
12-8	9004101-1340	2721615-05	O-RING	1
12-10	*50095	2721615-06	SOCKET HEAD M6-1.0 X 20	2
	^50975	4163316-02	SOCKET HEAD M6-1/0 X 20	2
12-15	2513030	----	BYPASS VALVE KIT (BLANK)	1
12-18	70521	2721615-07	PUMP SHAFT KIT	1
12-19	50315	----	BALL BEARING 17 X 40 X 12	1
12-20	51161	----	LIP SEAL 17 x 40 x 12	1
12-21	50951	----	SPACER	1
12-22	50329	----	RETAINING RING	1
12-25	*70331	38345-12	CYLINDER BLOCK KIT	1
	^70723	4163316-03	CYLINDER BLOCK KIT	1
12-29	2003014	----	BLOCK SPRING	1
12-30	2003017	----	BLOCK THRUST WASHER	1
12-31	51246	2721615-09	VALVE PLATE	1
12-32	2003087	2721615-10	SWASHPLATE	1
12-34	50551	2721615-11	BALL THRUST BEARING	1
12-37	2003005	2721615-12	TRUNNION ARM	1
12-38	2000015	2721615-13	SLOT GUIDE	1
12-42A	2510027	2721615-14	CHECK VALVE KIT (.031")	1
12-42B	2510050	2721615-15	CHECK VALVE KIT (BLANK)	1
12-44	*70403	2721615-16	CHARGE RELIEF VALVE KIT	1
	^70402	4163316-04	CHARGE RELIEF VALVE KIT	1
12-49	2513043	2721615-17	TRUNNION SEAL/RETAINER KIT	1
12-56	9005110-4400	----	STRAIGHT THREAD PLUG	1
12-66	9005110-3100	----	5/16 SAE PLUG	1
12-100	70525	2721615-18	OVERHAUL SEAL KIT	1

\*Use for: 934330 S/N 167 and below

^Use for: 934330 S/N 168 and below

^ Use for 933330 and 934330

# MOUNTING-36" FIXED DECK

Hydro  
Midsize

FIGURE 13








FIGURE 13

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
13-1	112111-02	BLADE 18.00 OFFST HLFT	2				
13-2	128169	PULLEY, IDLER 5.50	1				
13-3	4163871.7	WLDMT-DECK IDLER	1				
13-4	4124108	S CASTER SUPPORT	2				
13-5	2308140	PULLEY-ENGINE	2				
13-6	2721097	S-ASSY SPINDLE 6 LONG	1				
13-7	2721323	S-ASSY SPINDLE 6 SHORT	1				
13-8	2721477	BELT-HB 56.75	1				
13-9	2721478	BELT-HB 85.25	1				
13-10	2721479	PULLEY-6.75	1				
13-11	2721485	SPACER-IDLER	1				
13-12	64123-77	BLT-HEX 5/8-18X8 1/2	1				
13-13	64123-265	BLT-HEX 5/8-18X7 1/2	1				
13-14	38219	SPRING-TENSION	1				
13-15	38524	KNOB-4 PRONG 3/8-16	2				
13-16	4115420.7	GUIDE-BELT	1				
13-17	64229-03	LOCKNUT-NYLON 3/8-16	16				
13-18	4116661	PIN-PIVOT	1				
13-19	4119064.2	COVER-BELT, 36 FIXED	1				
13-20	4131477.2	CHUTE-DECK, 32-54 SD	1				
13-21	108074-13	FLEX TRIM 44.38	1				
13-22	4120257.2	BRKT-CHUTE SUPPORT	1				
13-23	4121969	S-36SDFIXED DK W/ LABS	1				
13-24	4135265	PULLEY-V IDLER	1				
13-25	64006-05	LOCKWSHR-HELICAL 1/2	1				
13-26	64262-012	BLT-FLG HD 3/8-16 X 1-1/4	12				
13-27	64025-16	NUT-HEX 5/8-18	2				
13-28	64123-05	BLT-HEX 1/2-20X1-1/2	1				
13-29	64123-139	BOLT-3/8-16X4 HEX	1				
13-30	64262-010	BLT-FLG HD 3/8-16 X 3/4	8				
13-31	64123-50	BOLT-HEX 3/8-16X1	4				
13-32	64123-88	BOLT, 3/8-16X2-3/4 HEX	1				
13-33	64163-12	.635/.640X1.0X.25 WASH	4				
13-34	64163-16	WSHR-41/64X1-3/8X12GA	2				
13-35	64163-31	WASHER, 25/64X1X12	1				
13-36	64163-65	WASHER-.890X1.375X18GA	1				
13-37	64164-12	KEY-1/4X1/4X1 SQ END	1				
13-38	64164-13	1/4X1/4X2 SQ KEY	1				
13-39	64209-03	SPRING WASHER.67 ID	2				
13-40	64221-04	E-RING.875	1				
13-41	64141-4	NUT-WLF 3/8-16	10				

FIGURE 14




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
14-1	108074-09	S CHANNEL-FLEX TRIM 7.121					
14-2	112111-01	BLADE 16.25 OFFST HLFT	3				
14-3	128110	BELT-CUTTERDECK	1				
14-4	128169	PULLEY, IDLER 5.50	1				
14-5	2188131	SPRING-EXTENSION	1				
14-6	4124108	S CASTER SUPPORT	2				
14-7	2308140	PULLEY-ENGINE	3				
14-8	2721097	S-ASSY SPINDLE 6 LONG	1				
14-9	2721323	S-ASSY SPINDLE 6 SHORT	2				
14-10	2722160	BELT-HB 73.00	1				
14-11	2722161	PULLEY-6.75 EOD	1				
14-12	64123-77	BLT-HEX 5/8-18X8 1/2	1				
14-13	64123-265	BLT-HEX 5/8-18X7 1/2	1				
14-14	38524	KNOB-4 PRONG 3/8-16	2				
14-15	4110580.7	WLDMT-IDLER	1				
14-16	4116661	PIN-PIVOT	1				
14-17	4131477.2	CHUTE-DECK, 32-54 SD	1				
14-18	4119381	S 48 SD FIXED DK W/LABS	1				
14-19	4119515.2	COVER-BELT FIXED 48	1				
14-20	64262-012	BLT-FLG HD 3/8-16 X 1-1/4	18				
14-21	4120257.2	BRKT-CHUTE SUPPORT	1				
14-22	64006-05	LOCKWSHR-HELICAL 1/2	1				
14-23	64025-16	NUT-HEX 5/8-18	3				
14-24	64123-05	BLT-HEX 1/2-20X1-1/2	1				
14-25	64262-010	BLT-FLG HD 3/8-16 X 3/4	8				
14-26	64123-50	BOLT-HEX 3/8-16X1	4				
14-27	64123-88	BOLT, 3/8-16X2-3/4 HEX	1				
14-28	64163-12	.635/.640X1.0X.25 WASH	6				
14-29	64163-16	WASHR-41/64X1, 3/8X12GA	3				
14-30	64141-4	NUT-WLF 3/8-16	10				
14-31	64163-65	WASHER-.890X1.375X18GA	1				
14-32	64164-12	KEY-1/4X1/4X1 SQ END	2				
14-33	64164-13	1/4X1/4X2 SQ KEY	1				
14-34	64209-03	SPRING WASHER.67 ID	3				
14-35	64221-04	E-RING.875	1				
14-36	64229-03	LOCKNUT-NYLON 3/8-16	21				



ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
15-1	2721512	ROLLER-5X2.75 CENTERED	1				
15-2	112111-02	BLADE 18.00 OFFST HLFT	3				
15-3	2188176	BELT-CUTTERDECK 54	1				
15-4	128169	PULLEY, IDLER 5.50	1				
15-5	2188131	SPRING-EXTENSION	1				
15-6	4124108	S-CASTER SUPPORT 9 IN.	2				
15-7	2308140	PULLEY-ENGINE	3				
15-8	2721097	S-ASSY SPINDLE 6 LONG	1				
15-9	2721323	S-ASSY SPINDLE 6 SHORT	2				
15-10	2722570	BELT-HB 75.75	1				
15-11	2722161	PULLEY-6.75 EOD	1				
15-12	64123-77	BLT-HEX 5/8-18X8 1/2	1				
15-13	64123-265	BLT-HEX 5/8-18X7 1/2	1				
15-14	38524	KNOB-4 PRONG 3/8-16	2				
15-15	4110580.7	WLDMT-IDLER	1				
15-16	4116661	PIN-PIVOT	1				
15-17	4131477.2	CHUTE-DECK, 32-54 SD	1				
15-18	4128849	S 54 SD CUT DECK W/ LABS	1				
15-19	4129134.2	WLDMT-COVER BELT 54	1				
15-20	64262-012	BLT-FLG HD 3/8-16 X 1-1/4	18				
15-21	4120257.2	BRKT-CHUTE SUPPORT	1				
15-22	64006-05	LOCKWSHR-HELICAL 1/2	1				
15-23	64025-16	NUT-HEX 5/8-18	3				
15-24	64123-05	BLT-HEX 1/2-20X1-1/2	1				
15-25	64262-011	BLT-FLG HD 3/8-16 X 1	8				
15-26	64123-50	BOLT-HEX 3/8-16X1	4				
15-27	64123-88	BOLT, 3/8-16X2-3/4 HEX	1				
15-28	64163-12	.635/.640X1.0X.25 WASH	6				
15-29	64163-16	WASHR-41/64X1, 3/8X12GA	3				
15-30	64141-4	NUT-WLF 3/8-16	10				
15-31	64163-65	WASHER-.890X1.375X18GA	1				
15-32	64164-12	KEY-1/4X1/4X1 SQ END	2				
15-33	64164-13	1/4X1/4X2 SQ KEY	1				
15-34	64209-03	SPRING WASHER.67 ID	3				
15-35	64221-04	E-RING.875	1				
15-36	64229-03	LOCKNUT-NYLON 3/8-16	22				
15-37	64123-173	BLT-HEX 3/8-16X4-1/2	1				
15-38	2720685	SPACER-ROLLER	1				

FIGURE 16



### FIGURE 16

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
16-1	64018-2	BLT-CRG 1/4-20X3/4 (NOT USED ON 36" DECKS)	4				
16-2	64018-3	BLT-CRG 3/8-16X1 (NOT USED ON 48" DECKS)	1				
16-3	64123-50	BOLT-HEX 3/8-16X1					
		QTY USED ON 36" DECK	5				
		QTY USED ON 48" DECK	7				
		QTY USED ON 54" DECK	8				
16-4	64262-012	BLT-FLG HD 3/8-16 X 1-1/4 QTY USED ON 48" DECK	1				
16-5	64229-01	LOCKNUT-1/4-20 NYLON (NOT USED ON 36" DECKS)	4				
16-6	64268-03	NUT-FL NYLON LOCK 3/8-16					
		QTY USED ON 36" DECK	6				
		QTY USED ON 48" DECK	7				
		QTY USED ON 54" DECK	8				
16-7	4115864.7	BAFFLE-DISCHARGE (USED ON 36", 54" DECK)	1				
16-8	4120208.7	BAFFLE-DISCHARGE 32-48 (USED ON 48" DECKS ONLY)	1				
16-9	4120175.7	BAFFLE-48 FRONT LH (USED ON 48" DECKS ONLY)	1				
16-10	4134336.7	BAFFLE-FRONT CTR (USED ON 48" DECKS ONLY)	1				
16-11	4118427.7	BAFFLE-FRONT LH (USED ON 54" DECKS ONLY)	1				
16-12	4134338.7	BAFFLE-FRONT CTR (USED ON 54" DECKS ONLY)	1				
16-13	4134343.7	BAFFLE-RIGHT FRONT (USED ON 54" DECKS ONLY)	1				
16-14	4134342.7	BAFFLE-RIGHT FRONT (USED ON 48" DECKS ONLY)	1				
16-15	4147035.7	BAFFLE-FRONT DECK (USED ON 36" DECKS ONLY)	1				



FIGURE 17




FIGURE 17

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
	4124110	ASSY-CASTER 9IN BOBCAT	2	17-23	38504	S TIRE-9x3.50-4 SMOOTH	1
	(INCLUDES ITEMS 1-3, 7-11 & 20 QTYs LISTED)				*38505	S TUBE-9x3.50-4	1
	(NOTE 2 ASSYS REQUIRED PER MACHINE)				OPTIONAL FLAT PROOF WHEEL & TIRE		
17-1	64173-04	QUICK PIN	1	17-24	4114430	ASSY-WHEEL 9"CAREFREE	1
17-2	64163-07	1-1/32X1-3/4X1/4 WASH	1		(WITH 2.75 DIA. BOLT CIRCLE		
17-3	64163-22	1-1/32X1-3/4X1/2 WASHR	7		INCLUDES ITEMS 11-15, 17-19, 24 & 26)		
17-4	4129801	BUSHING-FLANGED	2		(WITH 2.81 DIA. BOLT CIRCLE		
17-5	4124108	S CASTER SUPPORT	1		INCLUDES ITEMS 11-15, 20-22, 24 & 26)		
	(INCLUDES ITEMS 4 & 6, QTYs LISTED)						
17-6	85010N	ZERK GREASE FITTING	1	17-25	4114430-01S-TIRE 9 CAREFREE		1
17-7	64163-84	WSHR-1.015 X 1.75 X .125	1	17-26	64251-005	WASHER	2
17-8	2721484.7	WLDMT-CASTER YOKE	1		* NOT ILLUSTRATED		
17-9	64229-05	LOCKNUT-NYLON 1/2-13	1				
17-10	64123-166	BLT-HEX 1/2-13X5-1/2	1				
17-11	2722591	SPACER-3/4 INCH BRG	2				
17-12	2722230-04	SPANNER	1				
17-13	64123-01	BLT-HEX 5/16-24X3/4	4				
17-14	2722682	BEARING-9" WHEEL	2				
17-15	64141-1	NUT-WLF 5/16-24	4				
17-16	2722681	ASSY-9" WHEEL	1				
	(INCLUDES ITEMS 11-15, 17-19 23 & 24)						
	(WITH 2.81 DIA. BOLT CIRCLE						
	INCLUDES ITEMS 11-15 & 20-24)						
17-17	2720644	S WHEEL HALF	1				
17-18	2720645	S WHL HALF, VALVE SD	1				
17-19	2722680	HUB-9"WHEEL W/BRGS	1				
	(INCLUDES ITEMS 13 & 14)						
17-20	4132614	S-WHEEL HALF VLV SIDE	1				
17-21	4132615	S-WHEEL HALF CLSD SIDE	1				
17-22	4132616	ASSY-HUB W/BEARINGS	1				
	(INCLUDES ITEMS 13 & 14)						

FIGURE 18




FIGURE 18

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
18-1	38348-01	BEARING-SPINDLE SEALED	2				
18-2	33179-02	SPINDLE-SHORT (USED IN ITEM 8)	1				
18-3	33179-01	SPINDLE-LONG (USED IN ITEM 7)	1				
18-4	2721096	HOUSING-SPINDLE 6 HOLE	1				
18-5	64144-38	SNAP-RING	1				
18-6	38315	NUT-SPINDLE	1				
18-7	2721097	ASSY-SPINDLE LONG (INCLUDES ITEMS 1, 3, 4-6)	1				
18-8	2721323	ASSY-SPINDLE SHORT (INCLUDES ITEMS 1, 2, 4-6)	1				

FIGURE 19




FIGURE 19

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
19-1	4158442	LABEL-BOB-CAT, LARGE	1				
19-2	2000677	LABEL-DANGER/WARNING	1				
19-3	2000572	LABEL-WARNING BLADES	1				
19-4	2000678	LABEL-ROT PARTS/WSHR	2				
19-5	4116761	LABEL-MADE IN USA	1				
19-6	4158440	LABEL-BOB-CAT, SMALL	1				

FIGURE 20






FIGURE 20

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
20-1	4163349.7	WEIGHT (QTY 8 ON THE 48" DECK) (QTY 2 ON THE 54" DECK)					
20-2	64229-03	NUT-NYLOC 3/8-16	4				
20-3	64123-82	BOLT, 3/8-16X2 1/2 HEX (USED ON 48" ONLY)	4				
	64123-16	BOLT-3/8-16X1-1/4 (USED ON 54" ONLY)	2				
20-4	4163960.7	COVER-36 SD WEIGHT	1				
20-5	64268-03	NUT-FLG LOCK 3/8-16	2				
20-6	64123-79	BOLT, 3/8-16X3-1/4 HEX	2				
(ITEMS 4-6 USED ON 36" DECK ONLY)							

**SCHILLER GROUNDS CARE, INC.**  
**ONE BOB-CAT LANE**  
**P.O. BOX 469**  
**JOHNSON CREEK, WI 53038**  
**920-699-2000**  
**[www.schillergc.com](http://www.schillergc.com)**

