

744865DREN-O-THIN BRIGGS & STRATTON

744877A REN-O-THIN HONDA



PARTS MANUA

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

A WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Californie Proposition 65 Avertissement

Les échappements des moteurs diesel et certains de leurs composés sont reconnus par l'Etat de Californie pour être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.

▲ AVERTISSEMENT

L'émission du moteur de ce matériel contient des produits chimiques que l'Etat de Californie considère être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.

California Advertencia de la Proposicion 65

El estado de California hace saber que los gases de escape de los motores diesel y algunos de sus componentes producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.

▲ ADVERTENCIA

El estado de California hace saber que los gases de escape de este producto contienen productos químicos que producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.

CALIFORNIA Proposition 65 Warning

Battery posts, terminals, wiring insulation, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

WASH HANDS AFTER HANDLING.

IMPORTANT MESSAGE

Thank you for purchasing this Schiller Grounds Care, Inc. product. You have purchased a world class product, one of the best designed and built anywhere.

This machine comes with an Operator's and a Parts manual containing safety, operation, parts, maintenance and service information. The useful life and good service you receive from this machine depends to a large extent on how well you read and understand this manual. Treat your machine properly, lubricate and adjust it as instructed, and it will give you many years of reliable service.

Your safe use of this Schiller Grounds Care, Inc. product is one of our prime design objectives. Many safety features are built in, but we also rely on your good sense and care to achieve accident-free operation. For best protection, study the manual thoroughly. Learn the proper operation of all controls. Observe all safety precautions. Follow all instructions and warnings completely. Do not remove or defeat any safety features. Make sure those who operate this machine are as well informed and careful in its use as you are.

See a Schiller Grounds Care, Inc. dealer for any service or parts needed. Schiller Grounds Care, Inc. service ensures that you continue to receive the best results possible from Schiller Grounds Care, Inc. products. You can trust Schiller Grounds Care, Inc. replacement parts because they are manufactured with the same high precision and quality as the original parts.

Schiller Grounds Care, Inc. designs and builds its equipment to serve many years in a safe and productive manner. For longest life, use this machine only as directed in the manual, keep it in good repair and follow safety warnings and instructions. You'll always be glad you did.

Schiller Grounds Care, Inc. One Bob Cat Lane Johnson Creek, WI 53038-0469

TABLE OF CONTENTS	PAGE
LABELS	
SET-UPADJUSTMENTS	,
BELT / BLADE REPLACEMENT	
STORAGE/SPECIFICATIONS	
PARTS SECTIONCHASSIS GROUP FIGURE 1	
ENGINE AND GUARD GROUP FIGURE 2	14, 15
FLAIL BLADE REEL FIGURE 3	
1/16" FIXED BLADE REEL FIGURE 5	,
1/32" FIXED BLADE REEL FIGURE 6	, -
HANDLE FIGURE 7	24, 25

OPERATOR'S MANUAL 4163709

01-2010 **1**

NOTICE !!!

Unauthorized modifications may present **extreme** safety hazards to operators and bystanders and could also result in product damage.

Schiller Grounds Care, Inc. strongly warns against, rejects and disclaims any modifications, add-on accessories or product alterations that are not designed, developed, tested and approved by Schiller Grounds Care, Inc. Engineering Department. Any Schiller Grounds Care, Inc. product that is altered, modified or changed in any manner not specifically authorized after original manufacture—including the addition of "after-market" accessories or component parts not specifically approved by Schiller Grounds Care, Inc.—will result in the Schiller Grounds Care, Inc. Warranty being voided.

Any and all liability for personal injury and/or property damage caused by any unauthorized modifications, add-on accessories or products not approved by Schiller Grounds Care, Inc. will be considered the responsibility of the individual(s) or company designing and/or making such changes. Schiller Grounds Care, Inc. will vigorously pursue full indemnification and costs from any party responsible for such unauthorized post-manufacture modifications and/or accessories should personal injury and/or property damage result.



This symbol means:

ATTENTION! BECOME ALERT!

Your safety and the safety of others is involved.

Signal word definitions:

The signal words below are used to identify levels of hazard seriousness. These words appear in this manual and on the safety labels attached to Schiller Grounds Care, Inc. machines. For your safety and the safety of others, read and follow the information given with these signal words and/or the symbol shown above.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, **WILL** result in death or serious injury.

AWARNING

WARNING indicates a hazardous situation which, if not avoided, **COULD** result in death or serious injury.

ACAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, **COULD** result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol is used to address practices no related to personal injury.



MODEL NUMBER: This number appears on sales literature, technical manuals and price lists.

SERIAL NUMBER: This number appears only on your mower. It contains the model number followed consecutively by the serial number. Use this number when ordering parts or seeking warranty information.

MAINTENANCE AND STORAGE SAFETY

In general

- Maintain machine according to manufacturer's schedule and instructions for maximum safety and best results.
- Park machine on level ground.
- Never allow untrained personnel to service machine.
- Guards should only be removed by a qualified technician for maintenance or service. Replace guards when work is complete.
- Adjust or repair only after the engine has been stopped and the blades have guit rotating.
- Disconnect spark plug wire(s) before making any repairs.
- Replace parts if worn, damaged or faulty.
 For best results, always replace with parts recommended by the manufacturer.
- Do not dismantle the machine without releasing or restraining forces which may cause parts to move suddenly.
- Provide adequate support, e.g. jackstands for lifted machine or parts if working beneath.
- Do not put hands or feet near or under rotating parts.
- Clean up spilled oil or fuel thoroughly.
- Replace faulty mufflers.
- To reduce fire hazards, keep the engine, muffler, and fuel storage area free of grass, leaves, debris buildup or grease.
- Particular care must be taken when adjusting the carburetor while the engine is running. Keep hands and feet clear. Shut off PTO.
- When working underneath lifted parts or machines, make sure adequate support is provided.
- Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- Replace worn or damaged parts for safety.
- Use only replacement parts supplied by original manufacturer.
- Stop the engine and allow to cool before storing
- Do not store the machine or fuel container near heating appliances with an open flame such as a water heater or an appliance with a pilot light.

- Keep petrol (gasoline) storage area free of grass, leaves and excessive grease to reduce fire hazard.
- Keep the machine and fuel containers in a locked storage place to prevent tampering and to keep children from playing with them.

Blades

- Only replace blades. Never straighten or weld them.
- Keep other persons away from blades.

Fuel

- Petrol (gasoline) and diesel fuels are flammable; petrol (gasoline) vapors are explosive. Use extra care when handling.
- Drain the fuel tank outdoors only.
- Store only in containers specifically designed for fuel.
- When refueling or checking fuel level:
 - Stop the engine and allow to cool;
 - Do not smoke;
 - Refuel outdoors only;
 - Use a funnel:
 - Do not overfill;
 - If fuel is spilled, do not attempt to start the engine until the spill is cleaned up and vapors have cleared.
 - Replace caps on fuel contianers and tanks securely.

Sparks from static electricity can start fires or cause explosions. Flowing fuel can generate static electricity. To prevent static electricity sparks:

- Keep fuel containers electrically grounded.
- Do not fill containers in a vehicle or on a truck or trailer bed with a plastic liner. Fill containers on the ground away from the vehicle.
- When practical, remove petrol (gasoline) powered equipment from the truck or trailer and refuel it on the ground. If equipment must be refueled on the truck or trailer, refuel from a portable container rather than a dispenser nozzle.
- Keep the dispenser nozzle in contact with the rim of the fuel tank or container opening until fueling is complete. Do not use a nozzle lock-open device.





GENERAL NOTE: FRONT, REAR, RIGHT HAND AND LEFT HAND REFERENCES BELOW ARE WITH RESPECT TO AN OPERATOR AT THE CONTROLS.

EQUIPMENT AND PARTS INSPECTION

Remove equipment and parts from the packing box and inspect for possible shipping damage. You should have the following items:

- -Upper and lower handle.
- -Pre-assembled chassis and engine.
- -Loose parts bag.
- -Reel assembly (if ordered with unit).

ASSEMBLY INSTRUCTIONS.

HANDLE INSTALLATION

- 1. Assemble the upper and lower handle sections using the hardware provided in the loose parts bag.
- Mount the handle to the unit by placing the bottom ends of the handle over the pins at the top edge center of the chassis. Secure the handle with hairpins (from loose parts bag).
- 3. Connect one end of the spring (from loose parts bag) to the clutch cable and the other end to the arm of the clutch bail on the handle.
- 4. Remove the belt guard.



REEL INSTALLATION


1. Set the reel on the floor in front of the machine with the pulley to the left side of the machine.


ACAUTION

Block the unit as required to prevent it from falling accidentally.

2. Tilt the machine back and push it over the reel. Install the reel camp rods C into the reel clamps A, then left the reel into posistion andsecure with the reel clamp, washers, and nuts E on each side. The grooves in the bearing housings provide correct alignment of the bearings. Tighten nuts E securely but do not over tighten. Check reel to make sure it rotates freely.


IMPORTANT: When this unit is tilted backwards, oil will flow into the valve cover. Limit tilt time to less than one minute to prevent oil from running into carburetor through the breather hose.






PULLEY AND BELT INSTALLATION

- 1. Gently tap the woodruff key (from loose parts bag) into the slot on the reel shaft.
- 2. Start the two (2) set screws into the reel pulley.
- 3. Slide the pulley **F**, hub side inward, onto the reel shaft. Tap it into position over the woodruff key.
- Align the reel pulley with the engine pulley H.
 Placing a straight edge across both pulleys will
 show when the two pulleys are aligned.
- 5. Tighten the reel pulley set screws and check the engine pulley set screws to make sure they are also tight.
- 6. Place the new belts between the idler pulley **I** and the snubber **G** on the idler arm, then over the engine and reel pulleys.



CONTROL CABLE INSTALLATION

- 1. Pull the bail back against the handle. The idler pulley should be tight against the reel belts when the bail is against the handle.
- Release the bail. The idler pulley should move away from the reel belts and allow the belts to slip on the engine pulley when the bail is released.
- Reinstall the belt guards. The belt stop rods K should be positioned outside the belts. See Belt Guard Rod Adjustment



WHEEL BEARING LUBRICATION

Grease the wheel bearings. Do this at setup and after every 25 hours of service.

NOTE: Fill each wheel cavity at setup. The cavity is full when grease is seen coming out of bearing.


BLADE HEIGHT ADJUSTMENT

Blade height is adjusted by loosening the locking lever ${\bf L}$ and turning the adjusting knob ${\bf M}$ to raise or lower the front wheels.

After installing any reel, make the first adjustment on a hard level surface.


Adjust the blades to 1/8" (3 mm) above the surface. Test this setting on a small area, then adjust the blades to turf conditions as required. Each number on the adjustment decal represents a change of 1/8" (3mm).

If the desired blade position cannot be obtained by adjusting the front wheels, the rear wheels can be adjusted. Mounting the wheels in the top hole lowers the blades and mounting the wheels in the bottom hole raises the blades. The front axle may be locked in the down position to prevent the floating action if desired. Install and secure 1/2" screws, washers, lock washers and nuts in the slots above the axle. This will prevent the axle from moving.



BELT GUARD ROD ADJUSTMENT

There are two belt guide rods **A** mounted in the belt guard. The guides hold the belt so it doesn't grab when declutched. Adjust as necessary so belt declutches.




BELT REPLACEMENT

Belt tension is maintained by a spring loaded idler, controlled by the clutch bail. No belt tension adjustment is necessary when proper belts are used.

NOTE: A matched pair of belts must be used for correct operation. If one belt needs to be replaced, you **MUST** replace both belts to assure proper belt tension.

- 1. Remove belt guards and old belts from unit.
- 2. Place the new belts between the idler pulley **E** and the snubber **F** on the idler arm and then over the engine and reel pulleys.
- Install the belt guards. Make sure the belt stop rod G is outside of the belt.



BLADE REPLACEMENT

Fixed Blade Reels - To replace worn or damaged blades or to change to different blade and/or spacer combination.

- 1. Remove reel assembly from chassis.
- Remove bearing from end of shaft (opposite the pulley end). Loosen the set screw securing the locking collar. With a small punch, tap the bearing approximately one quarter turn in the opposite direction of the reel rotation. This relieves the cam lock action of the bearing and it can be removed from the shaft.
- Hold the shaft to keep it from turning and remove the shaft nut. Remove the blades and spacers from the shaft and replace or rearrange as required.

NOTE: When reassembling the reel, it is important to start and end with a spacer. **DO NOT** assemble with a blade next to the shaft nut at either end.

Fixed blades must be placed on the shaft in a pattern 60° off center from the previous blade.


- 4. Re-install the shaft nut and tighten securely to keep the blades from coming loose.
- 5. Re-install the reel bearing by exactly reversing the steps taken to remove it.


NOTE: Blades that are worn on one cutting face may be reversed and used again.

Flail Blade reels

Work on only one of the six blade shaft assemblies at a time.

- 1. Remove reel assembly from chassis.
- 2. Remove the cotter pin from one end of one of the blade shafts and pull the shaft out.
- 3. Replace the blades and other worn parts and re-assemble in the proper order while sliding the shaft back into place.
- 4. Replace blades only in sets to maintain balance.
- 5. Install a new cotter pin to secure the shaft.





STORAGE INSTRUCTIONS

AWARNING

To prevent possible explosion or ignition of vaporized fuel, do not store equipment with fuel in tank or carburetor in enclosure with open flame (for example, a furnace or water heater pilot light).

After daily usage of unit.

- 1. Wash the unit with water after the engine has cooled down.
- 2. Check the reel blades for damage. Replace any cracked, broken, bent or worn blades.
- 3. Check the engine oil level and inspect the air cleaner for excessive dirt or any obstructions.
- 4. Service engine according to engine manufacturer's recommendations. Refer to engine manual for all recommendations.

Before the equipment is put in to storage for any period exceeding 30 days, the following steps should be taken.

- 1. Drain all fuel from the fuel tank and fuel lines.
- Start the engine and run until all the fuel is used from the carburetor float bowl and the engine stops.
- While the engine is still warm, drain the crankcase oil and replace with the proper weight oil corresponding to the season the equipment will next be used.
- 4. Remove the spark plug and squirt a small amount of engine oil into the cylinder. Slowly pull the starter a few times to distribute oil in the cylinder and reinstall the spark plug.
- Check the reel for damaged blades and replace as needed.
- 6. Lubricate the wheel bearings with a standard lithium based lubricant.

To put the equipment into service after an extended period of storage:

- 1. Check for loose parts and tighten if necessary.
- 2. Check for damaged blades and replace as necessary.
- 3. Fill the fuel tank and then check the engine oil level.
- 4. Start the engine and check for fuel leaks. Repair any leaks before operating the unit.

PARTS SECTION






FIGURE 1

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1 2	64140-1 64123-107	COTTER PIN, 1/8X1 BLT-HEX 5/16-18X7/8	2 2				
3	64006-02	LCKWSHER-HELICAL 5/16					
4	64123-31	BOLT-1/2-13X3 HEX	2				
5	64025-02	NUT-HEX 5/16-18	2				
6	64025-30	NUT-HEX 1/2-20 SLOT	2				
7	64025-19	NUT-1/2-13 HEX	4				
8	517226	BRG,SLV .33 .50 .20 IRON	2				
9	4164055.7	CLAMP, REEL	2				
10	4130674	CLAMP, ROD LOWER	2				
11	520875	BUSHING,FLANGED	2				
12	520877	ROD,HINGE (PLATED)	1				
13	522256	WASHER,FELT	4				
14	522375	LEVER, LOCKING (PLATING	G) 1				
15	522385	AXLE PLATING	1				
16	4164061	CHASSIS AY - SERVICE	1				
	(INCLUDES	ITEMS 17 & 19)					
17	4163713	DECAL,INSTRUCTION	1				
18	64236-03	NUT-3/8-24 FLEXLOCK	2				
19	4163712	DECAL, WARNING-OPER	1				
20	4161123	LABEL-FRONT, RYAN	1				
21	64163-55	WASHER .328X.75X14 GA	2				
22	64163-73	WSHR625IDX1.12DX.062	2				
23	545859	PIVOT AY (PLATED)	1				
	(INCLUDES	ITEM 24)					
24	316947	PIN,SPIROL.312 1.250PS	2				
25	545861	SHIELD AY,TRAILING	1				
	(INCLUDES	ITEM 26)					
26*	64215-13	RIVET- POPIFI #66 LG HD	5				
27	540273	SCREW AY,ADJUSTING	1				
28	4124193	WHEEL, 8X1.75 .75BRG SF	9 4				
	(INCLUDES	ITEM 29)					
29	520983	BALL BEARING	8				
30	64229-02	LOCK NUT-NYLON 5/16-18					
31	64163-31	WASHER, 25/64X1X12	2				
32	64163-67	WASHER516X1X12GA	10				
33	64163-61	WSHR .81X.406X16GA	1				
34	64168-7	COTTER-HAIRPIN .091X1.	882				
35	64140-3	COTTER PIN-3/32X3/4	1				
36	4124338	LABEL-FRONT, REN-O-TH	IN 1				


*NOT ILLUSTRATED



ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	64163-55	WASHER .328X.75X14GA					
	(QTY 1 USEI						
	(QTY 2 USE	O ON HONDA)					
2	64268-02	NUT-FL NYLON LCK 5/16-1	8 4				
3	64164-19	KEY WOODRUFF.19X.75 #					
4	64123-271	BOLT,HEX 5/16-24 X 1	1				
5	64025-01	NUT-1/4-20 HEX	2				
6	64123-69	BOLT-5/16-18X1-1/2 HEX	4				
7	64123-16	BLT-HEX 3/8-16X1-1/4	1				
8	64141-6	NUT, 5/16-18	4				
9	517226	BRG,SLV .33 .50 .20	1				
10	517139	PULLEY	1				
11	4133104.7	ARM,DEFLECTOR	1				
12	520870	PULLEY,2.75 DIA	1				
13	64163-29	WASHER	2				
14	64207-08	NUT-HEX M58 EDGE LOC					
15	520902	ROD,STUD THREADED	2				
16	4164270.7	GUARD-MUFFLER (HONDA	,				
17	4163591	LABEL-BELTS/SERV EU	1				
18	4133065.7 4164344	ARM AY,IDLER GUARD AY	1 1				
19		ICLUDES 8 & 15)	ı				
	(11)	ICLODES 6 & 15)					
20	4136053	CABLE AY	1				
21	64151-2	NUT,3/8-16 HX EDGELCK	2				
22	64163-31	WASHER, 25/64X1X12	1				
23	64163-19	WSHR-33/64X1-1/4X12GA	1				
24	524801	BELT,V-2 MATCHED 30 3/8	1				
25	64163-61	WSHR .81X.406X16GA	2				
26 27	64044-18 64123-07	SCREW-SET 5/16-18 x 5/16 BOLT-1/4-20X1-1/2 HEX	i 4 1				
28	64139-13	BLT-WLF 5/16-18X1/2	3				
29	548995	SPRING, EXTENSION	1				
30	64123-87	BOLT-HEX 3/8-16X1-3/4	1				
31	64164-39	KEY,.19SQ X 1-34	1				
32	524779	PULLEY, 3 INCH DIA.	1				
33	4161125	DECAL, RYAN	1				
34*	4163971	SPARK PLUG-B&S ONLY	1				
35	4164186.7	GUARD, MUFFLER (B&S)	1				
36	4160485.7	BRKT-HORIZONTAL	1 1				
37	4160484.7	BRKT-VERTICAL	1				
38	64163-02	WSHR .321/.328X.593/.608X1	-				
39	64208-038	BLT-METRIC M6-1.00X20	4				
40	64152-56	SCREW-HS STAP #12X1/2	4				
41	64006-01	LOCKWSHR-1/4 HELICAL	4				
	(ITEMS 34-41	USED ON B&S ENGINES ONL	Y)				




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	306956	COTTER PIN	6				
2	64163-67	WASHER516X1X12GA	18				
3	516897	BLADE,FLAIL	18				
4	517155	SHAFT	6				
5	517162	SPACER, .328 (8mm)	24				
6	517163	SPACER, .891 (23mm)	24				
7	545640	PILLOW BLOCK AY	2				
	(INCLUDES I	TEMS 8 & 9)					
3-8	548101	BEARING	2				
3-9	521857	COLLAR, BRG LOCKING	2				
3-10	546377.7	SHAFT	1				
3-11*	544440A	REEL AY, FLAIL	1				
	(INCLUDES I	TEMS 1-10)					
	`	•					



ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	305134	NUT,.88-14 YS HX JAM (KO	C) 2				
2	516898	BLADE, 1/8" (3.2mm)	10				
3	516904	SPACER, .700 (19.6mm)	2				
4	516905	SPACER, .900 (23mm)	18				
5	517148	SHAFT	1				
6	545640	PILLOW BLOCK AY	2				
	(INCLUDES	TEMS 7 & 8)					
7	548101	BEARING	2				
8	521857	COLLAR, BRG LOCKING	2				
9	548176	WSHR,.88 1.50.10 YS FLA	T 2				
10	820484	WSHR, FLAT 1.17 1.75 .13	A/R				
	(USE WASHI	ERS AS REQUIRED SO THA	AT.				
	THE NUT (IT	EM 1) WILL NOT CONTACT					
	HEX SHAFT	(ITEM 5) WHEN TIGHT)					
11*	545440A (INCLUDES I	REEL AY, .12 BLADE X 2.0 TEMS 1-10)	1				

^{*} NOT ILLUSTRATED



ITEN	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	305134	NUT,.88-14 YS HX JAM (KC	C) 2				
2	516900	BLADE, DE-THATCH. 075 T					
3	516903	SPACER	14				
4	516905	SPACER	12				
5	517148	SHAFT	1				
6	545640	PILLOW BLOCK AY	2				
	(INCLUDES	ITEMS 7 & 8)					
7	548101	BEARING	2				
8	521857	COLLAR, BRG LOCKING	2				
9	548176	WSHR,.88 1.50.10 YS FLAT	T 2				
10	820484	WSHR, FLAT 1.17 1.75 .13	A/R				
	(USE WASHI	ERS AS REQUIRED SO THA	AT.				
	THE NUT (IT	EM 1) WILL NOT CONTACT					
	HEX SHAFT	(ITEM 5) WHEN TIGHT)					
11*	547452A	REEL AY, .06 BLADE X 1.5	1				
• • • • • • • • • • • • • • • • • • • •	(INCLUDES I	•	'				
	,	- · · · · · · · · · · · · · · · · · · ·					
				1			

^{*} NOT ILLUSTRATED





FIGURE 6

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	305134	NUT,.88-14 YS HX JAM (K	C) 2				
2	516901	BLADE, 1/32" (0.8mm)	25				
3	516903	SPACER, .500 (12.7mm)	2				
4	516904	SPACER, .700 (19.6mm)	24				
5	517148	SHAFT	1				
6	545640	PILLOW BLOCK AY	2				
	(INCLUDES	ITEMS 7 & 8)					
7	548101	BEARING	2				
8	521857	COLLAR, BRG LOCKING	2				
9	548176	WSHR,.88 1.50.10 YS FLA	T 2				
10	820484	WSHR, FLAT 1.17 1.75 .13	A/R				
	(USE WASHI	ERS AS REQUIRED SO THA	AΤ				
	THE NUT (IT	EM 1) WILL NOT CONTACT	-				
	HEX SHAFT	(ITEM 5) WHEN TIGHT)					
11*	547453A	REEL AY, FIXED 1/32 X 3/4	l 1				
	(INCLUDES	,					
	•	•					

* NOT ILLUSTRATED



ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	64025-02	NUT-HEX 5/16-18	2				
2	64123-07	BOLT, 1/4-20X1-1/2 HEX	4				
3	64163-03	WSHR256IDX.620DX18G/	A 4				
4	4163430.7	HANDLEBAR, UPPER	1				
5	520869.7	HANDLEBAR, LOWER	1				
6	64163-31	WSHR 25/64X1X12	4				
7	521744	RELEASE 'S' HOOK	1				
8	547441	BAIL CONTROL AY	1				
9	4136053	CABLE AY	1				
10	2702144	SPRING, EXTENSION. 63 4.3	3 1				
11	64151-17	LOCKNUT, HEX	4				
12	64018-34	BLT-CAR 5/16-18 X 1-1/2	1				
13	64229-02	NUT-NYLON LOCK 5/16-18	3				
14	517226	BRG SLV .33 .50 .20	1				
15	64163-29	WSHR-21/64 X 1 X 11GA	3				
16	64123-68	BLT-HEX 5/16-18X1	1				
17	4164054	LATCH-CLUTCH	1				
18	33288	STUD-DOUBLE ENDED	1				

