

MAN 4176928
Rev. A 10-2018



912480A
BC QUICKCAT 4000 FX651V KAW 48" SD
(S/N 1400 to 1575)

912520A
BC QUICKCAT 4000 FX691V KAW 52" SD
(S/N 1900 to 2217)

912610A
BC QUICKCAT 4000 FX730V KAW 61" SD
(S/N 0900 to 1017)

912480ACA
BC QUICKCAT 4000 FX651V KAW 48" SD
(S/N 80100 and higher)

912520ACA
BC QUICKCAT 4000 FX691V KAW 52" SD
(S/N 80100 and higher)

912480AAU
BC QUICKCAT 4000 FX651V KAW 48" SD
(S/N 90100 to 90102)



OPERATOR'S / PARTS MANUAL

CALIFORNIA PROPOSITION 65



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.



ADVERTENCIA: Cáncer y Daño Reproductivo - www.65Warnings.ca.gov.

⚠ WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

⚠ ADVERTENCIA

El estado de California hace saber que los gases de escape de este producto contienen productos químicos que producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.

IMPORTANT!

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered or grass-covered land unless the engine is equipped with a spark arrestor, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

To acquire a spark arrestor for your unit, see your Engine Service Dealer.

Please refer to the engine manufacturer's information included with the machine.

Labeled power ratings are supplied by the engine manufacturer in accordance with SAE testing and gross/net power rating standards (J1940, J1995, J1349).

IMPORTANT MESSAGE

Thank you for purchasing this Schiller Grounds Care, Inc. product. You have purchased a world class mowing product, one of the best designed and built anywhere.

This machine comes with an Operation and Safety Manual and a separate Setup, Parts and Maintenance Manual. The useful life and good service you receive from this machine depends to a large extent on how well you read and understand these manuals. Treat your machine properly, lubricate and adjust it as instructed, and it will give you many years of reliable service.

Your safe use of this Schiller Grounds Care, Inc. product is one of our prime design objectives. Many safety features are built in, but we also rely on your good sense and care to achieve accident-free operation. For best protection, study the manuals thoroughly. Learn the proper operation of all controls. Observe all safety precautions. Follow all instructions and warnings completely. Do not remove or defeat any safety features. Make sure those who operate this machine are as well informed and careful in its use as you are.

See a Schiller Grounds Care, Inc. dealer for any service or parts needed. Schiller Grounds Care, Inc. service ensures that you continue to receive the best results possible from Schiller Grounds Care, Inc. products. You can trust Schiller Grounds Care, Inc. replacement parts because they are manufactured with the same high precision and quality as the original parts.

Schiller Grounds Care, Inc. designs and builds its equipment to serve many years in a safe and productive manner. For longest life, use this machine only as directed in the manuals, keep it in good repair and follow safety warnings and instructions. You'll always be glad you did.

Schiller Grounds Care, Inc.
One Bob Cat Lane
Johnson Creek, WI 53038-0469

TABLE OF CONTENTS	FIGURES	PAGE
SAFETY		2-7
ASSEMBLY AND SETUP		8-9
LABELS		10-12
CONTROLS		12-15
OPERATION		16-19
MAINTENANCE CHART		20
MAINTENANCE RECORD		21
MAINTENANCE		22-28
ADJUSTMENTS		29-32
BELT REPLACEMENT		33
SPECIFICATIONS		34-36
PARTS SECTION		37
ENGINE DECK ASSEMBLY	FIGURE 1	38, 39
RIDER PLATFORM ASSEMBLY	FIGURE 2	40, 41
WHEEL & TRANSAXLE ASSEMBLY	FIGURE 3	42, 43
FUEL TANK & BATTERY ASSEMBLY	FIGURE 4	44, 45
PARKING BRAKE ASSEMBLY	FIGURE 5	46, 47
UPPER WIRE HARNESS	FIGURE 6	48, 49
48" & 52" LOWER WIRE HARNESS	FIGURE 7	50, 51
61" LOWER WIRE HARNESS	FIGURE 8	52, 53
TOWER ASSEMBLY	FIGURE 9	54, 55
RIDER PAD & FENDER ASSEMBLY	FIGURE 10	56, 57
CONTROLS ASSEMBLY	FIGURE 11	58, 59
DECK LIFT ASSEMBLY	FIGURE 12	60, 61
CASTER & BELT COVER ASSEMBLY	FIGURE 13	62, 63
48" SIDE DECK ASSEMBLY	FIGURE 14	64, 65
52" SIDE DECK ASSEMBLY	FIGURE 15	66, 67
61" SIDE DECK ASSEMBLY	FIGURE 18	72, 73

NOTICE !!!

Unauthorized modifications may present **extreme** safety hazards to operators and bystanders and could also result in product damage.

Schiller Grounds Care, Inc. strongly warns against, rejects and disclaims any modifications, add-on accessories or product alterations that are not designed, developed, tested and approved by Schiller Grounds Care, Inc. Engineering Department. Any Schiller Grounds Care, Inc. product that is altered, modified or changed in any manner not specifically authorized after original manufacture-including the addition of "after-market" accessories or component parts not specifically approved by Schiller Grounds Care, Inc.-will result in the Schiller Grounds Care, Inc. Warranty being voided.

Any and all liability for personal injury and/or property damage caused by any unauthorized modifications, add-on accessories or products not approved by Schiller Grounds Care, Inc. will be considered the responsibility of the individual(s) or company designing and/or making such changes. Schiller Grounds Care, Inc. will vigorously pursue full indemnification and costs from any party responsible for such unauthorized post-manufacture modifications and/or accessories should personal injury and/or property damage result.



This Operator's Manual should be regarded as part of the machine. Suppliers of both new and second-hand machines must make sure that this manual is provided with the machine.



¡LEA EL INSTRUCTIVO!

Si no lee Ingles, pida ayuda a alguien que si lo lea para que le traduzca las medidas de seguridad.



This symbol means:
ATTENTION!
BECOME ALERT!

Your safety and the safety of others is involved.

Signal word definitions:

The signal words below are used to identify levels of hazard seriousness. These words appear in this manual and on the safety labels attached to Schiller Grounds Care, Inc. machines. For your safety and the safety of others, read and follow the information given with these signal words and/or the symbol shown above.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices or property damage.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, **MAY** result in property damage


MODEL NUMBER: This number appears on sales literature, technical manuals and price lists.

SERIAL NUMBER: This number appears only on your mower. It contains the model number followed consecutively by the serial number. Use this number when ordering parts or seeking warranty information. Located behind rider pad on frame of unit.

PREPARING FOR SAFE OPERATION

Operator preparation and training

- Read, understand, and follow instructions and warnings in the manual and on the machine, engine, and attachments. If you don't understand something or it is unclear; contact your dealer representative for clarification.
- Become familiar with the safe operation of the equipment, operator controls and safety signs. Be prepared to stop the engine and attachments quickly in an emergency. Do not operate or allow another person to operate this machine if there are any questions about safety.
- Only allow operators who are responsible, trained, familiar with the instructions, and physically capable to operate or service the machine. The owner is responsible for training the users.
- Wear appropriate clothing, including long trousers and safety goggles or safety glasses with side shields when operating mower. Do not operate barefoot or wearing open sandals. Long hair, loose clothing or jewelry may get tangled in moving parts.
- If an operator or mechanic cannot read English, it is the owner's responsibility to explain this material to them.



CAUTION

This machine produced sound levels in excess of 85dBA at the operator's ear. Extended periods of exposure can cause hearing loss.

- Wear hearing protection.
- Never allow children, unskilled or improperly trained people to operate this equipment. Local regulations can restrict the age of the operator.
- Only adults and mature teenagers should operate a mower. Mature teenagers should have adult supervision. Be sure a teenager:
 1. Has read and understands the operator manual and understands the risks involved.
 2. Is sufficiently mature to use caution; and
 3. Is of sufficient size and weight to operate the controls comfortably and to manage the mower without taking risks.

- Data indicates that those operators age 60 years and above are involved in a large percentage of riding mower-related injuries. Those operators should evaluate their ability to operate the riding mower safely enough to protect themselves and others from injury.
- Do not carry passengers, especially small children. They may fall off and be seriously injured.
- Keep warning labels and this operator's manual legible and intact. Replacement labels and manuals are available from the factory.
- Do not operate machine while under the influence of drugs or alcohol or any other condition of impairment.
- The owner/user can prevent and is responsible for accidents or injuries occurring to themselves, other people or property.



Site preparation and circumstances

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
- Clear the area to be mowed of objects such as rocks, toys, wire or other debris that may be picked up or thrown by the mower.
- Be sure the area is clear of pets and people, especially young children. Never assume they will remain where you last saw them. Stop the machine if any enter the area.
- Mow only in daylight or in good artificial light.
- Do not mow wet grass as tires may lose traction.

MACHINE PREPARATION

- Do not tamper with or defeat safety devices. Keep guards, shields and interlock safety devices in place and in proper working condition. They are for your protection.
- Keep all fasteners such as nuts, bolts and pins well secured.
- Visually inspect blades, blade bolts and the cut-deck assembly for wear or damage. Replace worn or damaged blades and bolts to preserve balance.
- Verify that machine and attachments, if any, are in good operating condition.
- Grass catcher components are subject to wear, damage and deterioration which could expose moving parts or allow objects to be thrown.

FUELING

WARNING



- Gasoline can be extremely flammable; gasoline vapors are explosive. Use extra care when handling. A fire or explosion from gasoline can burn you or others and /or cause property damage.
- Fill the fuel tank outdoors on level ground, in an open area, when the engine is cold and wipe up any spilled gasoline.
- If the engine has been running, stop the engine and allow to cool for several minutes.
- Do not smoke, stay away from open flames or other possible ignition sources.
- Refuel outdoors, do not refuel in indoors or in an enclosed trailer.
- Use a funnel.
- Do not overfill. Fill to the bottom of the filler neck. The empty space allows for expansion. Overfilling may result in fuel leakage or damage to the engine or emissions system.
- If fuel is spilled, do not attempt to start the engine until the spill is cleaned up and vapors have cleared.
- Replace caps on fuel containers and tanks securely.
- Do not operate without the entire exhaust system in place and in good working condition.

WARNING



Under certain conditions, static electricity can cause sparks during fueling and start fires or cause explosions. Flowing fuel can generate static electricity. To prevent static electricity sparks:

- Keep fuel containers electrically grounded.
- Do not fill containers in a vehicle or on a truck or trailer bed with a plastic liner. Fill containers on the ground away from the vehicle.
- When practical, remove gas powered equipment from the truck or trailer and refuel it on the ground. If equipment must be refueled on the truck or trailer, refuel from a portable container rather than a dispenser nozzle.
- If a dispenser nozzle must be used, keep the dispenser nozzle in contact with the rim of the fuel tank or container opening until fueling is complete. Do not use a nozzle lock-open device.
- Replace caps on fuel cans and tanks securely.
- Fill the fuel tank outdoors.
- Store fuel only in containers specifically designed for fuel.

WARNING



Gasoline is harmful or fatal if swallowed. Long-term exposure to vapors has caused cancer in laboratory animals.

- Avoid prolonged breathing of vapors.
- Keep face away from nozzle and gas tank/container opening.
- Keep away from eyes and skin.
- Do not siphon by mouth.

OPERATING SAFELY  **WARNING**

Operating engine parts, especially the muffler, become extremely hot. Severe burn can result from contact. Debris such as grass clippings, leaves, brush, etc. can catch fire.

- Allow engine parts, especially the muffler, to cool before touching.
- Remove accumulated debris from engine and muffler area.

 **WARNING**

Engine exhaust contains carbon monoxide, which is an odorless gas that can kill you.

DO NOT run the engine indoors or in a confined small area (such as an enclosed trailer) where carbon monoxide fumes can collect.

Starting

- Start only according to instructions in this manual or on the machine.
- Lightning can cause severe injury or death. If lightning is seen or thunder is heard in the area, DO NOT operate the machine; seek shelter.
- Be sure all drives are in neutral and parking brake is engaged before starting engine.
- Do not change engine governor settings or overspeed the engine. Operating the engine at excessive speed can increase the hazard of personal injury.

Operation

- Do not put hands or feet near rotating parts or under the machine. Keep clear of the discharge opening at all times.
- This mower was designed for use by one operator. Keep all others away during operation.
- Do not operate when people, especially children, or pets are in the area.
- Stop the machine if anyone enters the area.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Slow down and use caution when making turns and crossing roads and sidewalks.
- Stop blades when not moving.
- Stop blades when crossing surfaces other than grass.

- Do not mow with the discharge deflector raised, removed or altered unless there is a grass collection system or mulch kit in place and working properly.
- Do not start the cutting blades until you are ready to start mowing.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- Do not direct discharge towards others.
- Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator.
- Obey safety instructions. Failure to do so may cause injury to yourself and/or others.
- Never leave a running machine unattended. Park on level ground, turn off blades, stop engine and remove key before leaving the operator position.


Stopping

- Park the machine on level ground. Stop the engine, remove the key and wait for all parts to stop moving before:
 - Checking cleaning or working on the mower.
 - After striking a foreign object or an abnormal vibration occurs. Inspect and make any necessary repairs before restarting and operating the mower.
 - Before clearing blockages or unclogging.
- Park the machine on level ground. Stop the engine, remove the key and wait for all parts to stop moving.
 - Whenever you leave the mower.
 - Before refueling.
 - Before emptying the grass catcher.
- Be sure all drives are in neutral and parking brake is engaged before starting engine.
- Do not change engine governor settings or overspeed the engine. Operating the engine at excessive speed can increase the hazard of personal injury.

CHILDREN

- Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the mowing activity. Never assume that children will remain where you last saw them.
- Keep children out of the operating area and under the watchful care of a responsible adult other than the operator.
- Do not carry children, even with the blade(s) shut off. Children could fall off and be seriously injured or interfere with safe machine operation. Children who have been given rides in the past could suddenly appear in the mowing area for another ride and be run over or backed over by the machine.

MOWING SLOPES



WARNING

Operating on wet grass or steep slopes can cause sliding and loss of control. Wheels dropping over edges, ditches, steep banks, or into water can cause roll overs, which may result in serious injury, death or drowning. Slopes are a major factor related to accidents. Operation on slopes requires extra caution.

- DO NOT mow slopes when grass is wet.
- DO NOT mow near drop-offs or water.
- Reduce speed and use extreme caution on slopes.
- Do not operate machine under any condition where traction, steering, or stability is in question. Tires could slide even if the wheels are stopped.
- Avoid sudden turns or rapid speed changes.
- Do not mow on slopes if uneasy or uncertain. Ultimate responsibility for safe operation on slopes rests with the operator.
- Do not mow excessively steep slopes.
- With ride-on machines, including articulated steering machines, mow up and down slopes, not across, except for zero turn machines. Zero turn machines should mow across slopes.
- With walk-behind machines, mow across slopes, not up and down.
- With zero turn machines, mow across slopes, not up and down. If the machine will not stay on the slope, it is too steep.

- Mid-mount zero turn (belly mounted deck) machines have much greater traction pointed up slope then down slope. Be aware that traction may be lost going down a slope. Do not operate a mid-mount zero turn on slopes it cannot back up.
- Avoid starting or stopping on a slope. If tires lose traction, disengage the blades and proceed slowly straight down the slope.
- With a zero turn machine, if tires lose traction going down a slope, steering control may be regained by speeding up.
- Keep all movement on the slopes slow and gradual. Do not make sudden changes in speed or direction.
- Do not turn on slopes unless necessary, and then turn slowly and downhill when possible.
- Stay away from slopes if the ground is loose or if caught in the rain during mowing.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine.
- Remove obstacles such as rocks, tree limbs, etc. from the grass cutting area.
- Avoid driving over obstacles such as ruts, holes, rocks and roots whenever possible. Be alert to dips and rises. Uneven terrain can overturn a mower or cause it to slide. Tall grasses can hide obstacles.
- Do not mow drop-offs, ditches or embankments. The machine could suddenly turn over if a wheel runs over the edge or an edge caves in.
- Follow the manufacturer's recommendations for wheel weights or counterweights to improve stability.
- Be aware that operating on wet grass, across steep slopes or downhill may cause the mower to lose traction. Loss of traction to the drive wheels may result in sliding and loss of braking and steering. Use a walk behind mower and /or hand trimmer near drop-offs, ditches, steep banks or water.

TOWING

- Follow the manufacturer's recommendation for weight limits for towed equipment and towing on slopes.

BOB-CAT

QUICKCAT

Transporting WARNING

Loading a machine onto a trailer or truck increases the possibility of tip-over and could cause serious injury or death.

- Use extreme caution when operating a machine on a ramp.
- Use only a full-width ramp; do not use individual ramps for each side of machine.
- Avoid sudden acceleration or deceleration while driving the machine on a ramp as this could cause a loss of control or a tip-over situation.
- If applicable, shut off fuel when transporting.
- Secure the machine to the truck or trailer.

MAINTENANCE SAFETY

In General

- Keep the machine in good working order.
- Maintain machine according to manufacturer's schedule and instructions for maximum safety and best mowing results.
- Park machine on level ground.
- Never allow untrained personnel to service machine.
- Adjust or repair only after the engine has been stopped and the blades have quit rotating.
- Inspect grass catcher components regularly. If worn, damaged or deteriorated, they may expose moving parts or allow objects to be thrown.
- Replace worn, damaged or faulty parts. For best results, always replace with parts recommended by the manufacturer.
- Disconnect battery or remove spark plug wire(s) before making any repairs. Disconnect the negative terminal first and the positive last. Reconnect positive first and negative last.
- Do not dismantle the machine without releasing or restraining forces which may cause parts to move suddenly.
- Provide adequate support for lifted machine or parts if working beneath.
- Keep hands or feet away from moving parts.
- Clean up oil or fuel spillage thoroughly.
- Replace faulty mufflers.
- To reduce fire hazards, keep the engine, muffler, battery compartment and fuel storage area free of grass, leaves, debris buildup or grease.

- Hydraulic fluid can penetrate skin, use paper to check for leaks. Relieve hydraulic pressure before disconnecting hoses. Make sure connections are tight and hoses are in good condition.

HYDRAULIC SYSTEM

WARNING



Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

- If equipped, make sure all hydraulic fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to hydraulic system.
- Keep body and hands away from pinhole leaks or nozzles that eject high pressure hydraulic fluid.
- Use cardboard or paper, not your hands, to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system by placing the motion control levers in neutral and shutting off the engine before performing any work on hydraulic system.

WARNING

Charging or jump starting the battery may produce explosive gases. Battery gases can explode causing serious injury.

- Keep sparks, flames, or cigarettes away from battery.
- Ventilate when charging or using battery in an enclosed space.
- Make sure venting path of battery is always open once battery is filled with acid.
- Always shield eyes and face from battery!

CAUTION

If the ignition is in the "ON" position there is potential for sparks and engagement of components. Sparks could cause an explosion or moving parts could accidentally engage causing personal injury. Be sure ignition switch is in the "OFF" position before charging the battery.

BLADES



- Mower blades are sharp and can cut. Use extra caution when handling. Remove obstructions with care. Wrap the blade(s) or wear gloves.
- Be aware that rotating one blade on multi blade mowers can cause other blades to rotate.
- Only replace blades. Never straighten or weld them.
- Keep other persons away from blades.

BATTERY



Battery electrolyte contains sulfuric acid which is poisonous and can cause severe burns. Swallowing electrolyte can be fatal. Batteries can produce hydrogen gas which is explosive.

- When working with battery electrolyte, use protective equipment such as, but not limited to, goggles, face shield, rubber gloves and apron.
- Avoid leaning over a battery.
- Do not expose a battery to open flames or sparks.
- Be sure batteries with filler caps are properly filled with fluid.
- Do not allow battery acid to contact eyes or skin. Flush any contacted area with water immediately and get medical help.
- Charge batteries in an open, well ventilated area, away from sparks and flames. Unplug charger before connecting or disconnecting from battery.

Jump starting

1. Be sure the jumper cables are in good condition. Turn off the ignition and all electrical accessories on both machines.
2. Position the machine with a good (charged) battery next to but not touching the machine with the dead battery so jumper cables will reach.
3. When making cable connections:
 - make sure the clamps do not touch anywhere except to intended metal parts.
 - Never connect a positive ("+" or red) terminal to a negative ("–" or black) terminal.
 - Make sure the cables won't get caught in any parts after the engines are started.
4. Connect one end of the first jumper cable to the **positive** terminal on one battery. Connect the other end to the **positive** terminal on the other battery.
5. Connect one end of the other cable to the **negative** terminal of the machine with a good (charged) battery. Make the final connection on the engine of the machine to be started, away from the battery.
6. Start the vehicle with the good battery, then the machine with the discharged battery.
7. Remove the cables in the exact reverse order of installation. When removing each clamp, take care it does not touch any other metal parts while the other end remains attached.

STORAGE SAFETY

- Stop the engine and allow to cool before storing.
- Drain the fuel tank outdoors only.
- Store fuel in an approved container in a cool, dry place.
- Keep the machine and fuel containers in a locked storage place to prevent tampering and to keep children from playing with them.
- When the machine is to be parked, stored or left unattended, lower the cutterdeck unless a positive mechanical lock is used.
- Do not store the machine or fuel container near heating appliances with an open flame such as a water heater or an appliance with a pilot light.
- Keep gasoline storage area free of grass, leaves and excessive grease to reduce fire hazard.
- Clean grass and debris from cutting units, drives, mufflers and engine to help prevent fires.

TOOLS REQUIRED FOR ASSEMBLY

- Wrenches: 3/4"
- Utility knife
- Tire pressure gauge

NOTE: All references below to the "right" or "left" are with respect to an operator at the controls.

UNCRATE UNIT

1. Discard packing materials. Remove and discard shipping brackets.
2. Set rear tire pressures to 12 lbs/in² (0.8 kg/cm²). Tires are overinflated for shipping. Front tires should be 15 lbs/in² (1.05 kg/cm²).

FINAL PREPARATIONS

3. Check the engine and hydraulic oil levels. Top up with the correct oil if necessary. Use SAE 10W30 motor oil for the engine. Use fresh, clean SAE 20W50 motor oil for the hydraulic system. After running for one hour, let hydraulic system oil cool. When cold, check levels.







WARNING Battery acid is caustic and fumes are explosive and can cause serious injury or death.




Use insulated tools, wear protective glasses or goggles and protective clothing when working with batteries. Read and obey the battery manufacturer's instructions.


Be certain the ignition switch is OFF and the key has been removed before servicing the battery.

- a) Verify battery polarity before connecting or disconnecting the battery cables.
 - b) When installing the battery, always assemble the RED, positive (+) battery cable first and the ground, BLACK, negative (-) cable last.
 - c) Tighten cables securely to battery terminals and apply a light coat of silicone dielectric grease to terminals and cable ends to prevent corrosion. Keep terminal covers in place.
- Read Operation and Safety Manual before starting.
 - Deck can be adjusted to allow for the best horsepower, best quality of cut, or best striping. See deck leveling procedure in the Adjustments Section in this manual to set as desired.
 - Run engine at full RPM for 5 minutes before engaging blades to allow the engine to be fully lubricated before load is applied.
 - Check the hydrostat neutral adjustment. Neutral is set at the factory but may require readjustment if air trapped during the initial oil fill has worked out of the system. See Adjustments Section later in this manual.
 - Do not use the machine without an approved grass collector, the grass discharge chute or mulching plates correctly fitted.



BOB-CAT QUICKCAT





FRONT REFERENCE BAR ADJUSTMENT

	<p>! DANGER</p> <p>ROTATING BLADES</p> <ul style="list-style-type: none"> - KEEP HANDS AND FEET AWAY - STOP ENGINE AND LET BLADES STOP BEFORE REMOVING GRASS COLLECTOR OR UNCLOGGING. 		<p>! WARNING</p> <p>THROWN OBJECTS</p> <ul style="list-style-type: none"> - KEEP AREA CLEAR OF PEOPLE AND PETS. - REMOVE OBJECTS BLADE MAY STRIKE AND THROW. - STOP BLADES TO CROSS GRAVEL AREAS. - DO NOT OPERATE WITHOUT CHUTE, MULCHER OR ENTIRE GRASS COLLECTOR IN PLACE. <p>4164269</p>
--	---	--	--

<p>6 3/4" ± 1/8"</p> <ul style="list-style-type: none"> - SPRING LENGTH FOR WHEN INSTALLING NEW BELTS ONLY - DO NOT READJUST AFTER USE 	<p>BELT ROUTING</p> <p>4171408</p>
--	---

! WARNING !


- REMOVE DEBRIS BUILDUP. DEBRIS UNDER BELT COVER OR NEAR MUFFLER CAN CAUSE FIRES.
- BLADES CONTINUE TO ROTATE FOR A FEW SECONDS AFTER BLADES ARE TURNED OFF.
- BLADES MUST BE AT LEAST 1/8" ABOVE BOTTOM OF HOUSING.
- ALL BLADES MUST BE IDENTICAL. CHECK BLADE BOLTS DAILY FOR TIGHTNESS.
- INSPECT FOR DAMAGE AFTER STRIKING A FOREIGN OBJECT. MAKE REPAIRS BEFORE RESTARTING OPERATION.
- FIND AND REPAIR CAUSE OF ANY ABNORMAL VIBRATION.

2000572

61

52

48



KEYSWITCH (K) - The keyswitch has three positions: OFF, RUN, and START. Insert the key and turn it clockwise to move the switch from OFF to RUN. Turn it further to START and hold to engage the starter. Release the key and the switch will return to RUN from START. Turn the key counterclockwise to OFF to stop the engine.

THROTTLE (T) - Move the throttle lever forward to increase engine speed until the maximum governed engine RPM is reached. Move the lever rearward to decrease engine speed until the engine reaches its idle speed.

CHOKE (C) - Pull the choke control out to set the choke ON. Push it in to set the choke OFF.


POWER TAKE OFF (PTO) SWITCH (P) - Pulling the PTO switch out engages (turns on) the PTO and starts the blades or other attachment. Pushing the PTO switch in disengages (turns off) the PTO and stops the blades or other attachment.

NOTE: The PTO switch does not control attachments powered by a separate engine.

- Disengage the PTO whenever you stop or leave the operator's position.
- Shut off engine with the key and remove the spark plug wires before making adjustments or unplugging a clogged mower.
- Do not engage the PTO until ready to start mowing.

FUEL GAUGE (U) - Shows the level of fuel remaining in tank.

HOUR METER (M) - Records accumulated time the machine is in operation.




CONTROL LEVERS (L & OP) - Each of the two control levers controls the drive wheel located on its side. They control the forward and reverse movement of the machine, provide steering and also provide dynamic braking.

The left control handle is the operator presence. The operator presence must be held down for PTO operation and when machine is NOT in park. If the PTO switch is on or machine is NOT in park, the engine will kill.

HEIGHT OF CUT (HOC) HANDLE (X) - Used to secure the cutterdeck in transport position. To return to preset height of cut, lower HOC handle until latch lever contacts height of cut pin A.

HEIGHT OF CUT(HOC) PIN (A) - Sets height of cut and allows easy return from transport to desired height of cut. Raise the deck to transport using the HOC handle. Position pin A in the hole corresponding to the desired height of cut. Lower the HOC handle until it rests on pin A.



PARKING BRAKE (R) - Pull the parking brake lever into park to put the parking brake on. This will also lock the control handles. Push the parking brake to "CUT" to limit the speed for maximum recommended cutting speed. Push the parking brake to "TRANSPORT" to allow for maximum speed.

The parking brake must be ON to start the engine. It must also be ON to keep the engine running if the operator releases the operator presence control lever (OP).

**Parking brake in ON position
(operator's right side)**




PUSHING THE MACHINE

The machine may be pushed with the engine off, the parking brake off, and the bypass valves open.


Bypass valves are located on the frame by the rider platform. To open the bypass valves, move the parking brake to any **OFF** position, then lift and pull bypass control rod **C** through the large opening **D**, until the control rod stop is past the opening. Drop rod **C** into the small opening to lock in place. Repeat for the other bypass control rod.

To close the bypass valves, lift bypass control rod **C** allowing the control rod stop to retract through the large opening **D**.




BOB-CAT
QUICKCAT

TRACKING CONTROL (W) -Adjusts tracking so machine can drive straight ahead when both traction handles are pushed all the way forward.



FRONT POINT OF REFERENCE CONTROL (PC) - Adjust knob to move the front point of reference bar forward or back to set throw for comfort or a maximum cutting speed. Rotating the knob clockwise moves the bar forward and rotating the knob counter clockwise move the bar back.



PRE-OPERATION CHECK LIST

BOB-CAT
QUICKCAT


PRE-OPERATION CHECK LIST (OWNER'S RESPONSIBILITY)

- | | |
|---|--|
| <ul style="list-style-type: none">___ Review and follow all safety rules and safety decal instructions.___ Check that all safety decals are installed and in good condition. Replace if damaged.___ Check to make sure all shields and guards are properly installed and in good condition. Be sure that either the discharge shield or complete vacuum attachment is installed.___ Check that all hardware is properly installed and secured.___ Check that equipment is properly and securely attached to power unit.___ Check to be sure engine is free of dirt and debris. Pay particular attention to the cooling fins, governor parts and muffler. Clean air intake screen. Check air cleaner; service if necessary. | <ul style="list-style-type: none">___ Never allow riders.___ Inspect area and remove stones, branches or other hard objects that might be thrown, causing injury or damage.___ Clean area around oil fill dipstick. Remove dipstick and check to be sure oil is in operating range (between marks on dipstick). Add oil if necessary but Do Not Overfill. Install dipstick assembly firmly until cap bottoms out on tube. Dipstick assembly must always be secured into fill tube when engine is running.___ Check all lubrication points and grease as instructed in manual.___ Check hydrostatic fluid level. Check to be sure cooling fins on hydrostat are clean.___ Perform a functional check of the safety interlock system each time you operate the unit. |
|---|--|

CAUTION


Use caution when making turns. Slow down before making sharp turns to help maintain control and to prevent torn turf from skidding or spinning tires. To help prevent turf damage, keep both drive tires moving whenever a turn is made.

TIP: The best way to make a sharp "zero" turn is to come to a stop, get the machine moving in reverse with both drive wheels and then powering the machine around with the outside wheel. This technique keeps the drive tires turning and results in less turf damage.

	WARNING SERIOUS INJURY OR DEATH MAY RESULT FROM MACHINE ROLLOVER
	<ul style="list-style-type: none">• DO NOT OPERATE MACHINE ON STEEP SLOPES OR NEAR DROPOFFS• AVOID SHARP AND/OR QUICK TURNS
WARNING ROLLOVER MAY CAUSE PERMANENT INJURY OR DEATH. <ul style="list-style-type: none">• SUDDEN STARTS OR TURNS ON RAMPS OR SLOPES CAN CAUSE OVERTURN.• USE GREATER CARE ON RAMPS AND AS THE SLOPE INCREASES.	

FUELING

- Fill fuel tanks with good quality, clean, unleaded gasoline. Do not use hi-test fuel.
- Use a funnel to avoid spillage.

**BEFORE STARTING THE ENGINE**

- Be familiar with all controls, how each functions and what each operates.
- Check the engine oil level and add if necessary. Turn fuel valve to ON.
- **Choke:** For cold starts, set the throttle lever to the half-open position and pull the choke out to the ON position. For warm starts set the throttle to the half-open position and the choke to the OFF position.

OPERATOR PRESENCE INTERLOCK SYSTEM

To start the engine:

- The PTO switch must be **OFF**.
- The left handle operator presence handle must be in the neutral position.
- The parking brake must be **ON**.

To operate the machine:

1. The operator must hold the operator presence handle down or engaging the PTO will kill the engine.

STARTING THE ENGINE

1. Turn the key to operate the electric starter to start the engine. Release the key when the engine starts.
2. If the engine does not start immediately, do not crank for more than 10 seconds at a time. Allow 60 seconds for the starter motor to cool down between starting attempts to prevent the starter motor from burning out.
3. If the choke is ON when the engine starts, gradually back it off until the engine runs with no choke at all.

DRIVING


1. With the PTO disengaged, move the parking brake to CUT or TRANSPORT speed position.
2. Move control traction lever out of neutral.
3. Push both traction levers forward evenly to drive forward in a straight line. Pull both traction levers back evenly to drive backward in a straight line.

OPERATING NOTES


- Practice at slow engine and travel speeds with the PTO off until fully familiar with the controls.
- For normal cutting, the throttle should be set at the full open position. By using the traction levers to speed up or slow down the machine during use, maximum control and cutting efficiency can be maintained.
- Using the machine at less than full throttle in heavy conditions will cause the engine to labor and result in excessive wear to the engine and hydraulic system.

STEERING

Forward movement - To move the machine straight ahead, push both control levers forward equally from their neutral position. **Increase speed:** as the levers are moved farther forward from the neutral position. There are two maximum forward speeds. There is a "CUT" speed and a "TRANSPORT" speed. Cut speed is limited to a maximum recommended speed to obtain a good quality cut. Transport speed is limited to the maximum speed of the machine. **Decrease speed:** when traveling forward, pulling the traction levers rearward slows the machine. **Stopping:** The machine will stop when the levers reach the neutral position.



Reverse movement - To move the machine straight back, pull both traction levers back equally from their neutral position. Reverse speed increases as the levers are moved back farther. Maximum reverse speed is reached when the levers stop. When moving in reverse, pushing the levers forward slows the machine, and the machine stops when the neutral position is reached.




NOTE: The control levers are spring loaded to return to neutral in both forward and reverse. This spring resistance may be felt when moving the traction levers. When control levers are released, spring tension will return them to the neutral position.

To turn, move one lever forward and one back.

Turns during forward movement:


Forward Right turn

- move the right traction lever back toward neutral to slow the right drive wheel.





Forward Left turn

- move the left traction lever back toward neutral to slow the left drive wheel.





Turns during reverse movement:

- **Reverse right turn** - move the right traction lever forward toward neutral to slow the right drive wheel.
- **Reverse left turn** - move the left traction lever forward toward neutral to slow the left drive wheel.



Slow, sweeping turns are made with both traction levers on the same side of neutral and slightly apart. True zero radius turns about the center of the machine are made by having one lever in reverse while the other is in forward. By varying the relative positions of the two levers, the rate of turn is varied to suit the mowing situation.



Slow down before making sharp turns. The machine is capable of turning very rapidly when the levers are moved further apart from each other. Loss of control and/or turf damage may result.

STOPPING


1. Turn PTO switch to OFF.
2. Release control traction levers or move to neutral.
3. Put machine in PARK.
4. Turn key to OFF (counterclockwise).

CUTTING

1. Place the discharge chute in the down position or correctly fit a grass collector or mulcher plate.
2. Stand on rider platform.
3. Start the engine.
4. Turn the blades on by pulling up on the PTO switch. Do not start the blades at full throttle. Instead, use the slowest throttle setting that will allow the engine to pick up the blade load to reduce the wear on the belts and electric clutch.
5. After the blades are rotating, set the throttle to maximum. Use the traction levers to obtain the required cutting speed, to steer around obstacles and to turn at the end of a cut.

CUTTING TIPS

- When mowing large areas, start by turning to the right so that clippings will be discharged away from shrubs, fences, driveways, etc. After two or three rounds, mow in the opposite direction, left hand turns, until finished.
- If grass is extremely tall, it should be mowed twice, the first cut relatively high, the second cut to the desired height.
- Use the left side of the mower for trimming.
- Choose cutting directions so that clippings are thrown onto areas that already have been cut. This method results in the most even distribution of clippings and more uniform, better appearing cuts.
- Use a different mowing pattern each time a property is cut where possible. This helps prevent rutting and leads to a more uniform cut by keeping the grass from always laying the same way.



! DANGER

ROTATING BLADES

- KEEP HANDS AND FEET AWAY.
- STOP ENGINE AND LET BLADES STOP BEFORE REMOVING GRASS COLLECTOR OR UNCLOGGING.



! WARNING

THROWN OBJECTS

- KEEP AREA CLEAR OF PEOPLE AND PETS.
- REMOVE OBJECTS BLADE MAY STRIKE AND THROW.
- STOP BLADES TO CROSS GRAVEL AREAS
- DO NOT OPERATE WITHOUT CHUTE, MULCHER OR ENTIRE GRASS COLLECTOR IN PLACE.

MAINTENANCE CHART

BOB-CAT
QUICKCAT

MAINTENANCE OPERATION	Maintenance is an ongoing job. These intervals are maximum times between maintenance operations. Perform more often under severe conditions.							
	FIRST 5 HOURS	BEFORE EACH USE	EVERY 25 HOURS	EVERY 50 HOURS	EVERY 100 HOURS	EVERY 200 HOURS	EVERY 400 HOURS	YEARLY
ENGINE								
Consult the engine manual for additional information and instructions								
Check /Top Off Oil Level		X						
Check for Leaks		X						
Clean Air Intake Screen		X						
Clean Air Cleaner PreCleaner			X					
Clean Air Cleaner Element			X					
Clean Cooling Fins					X			
Change Oil And Filter	X	See engine manufacturer's manual						
Check / Replace Spark Plugs						X		
TRANSAXLE								
*CHANGE TRANSAXLE OIL AFTER INITIAL 75-100 HOURS								
Check Oil Level	X	X						
Check For Leaks	X	X						
Change Oil and Filter	*						X	
MACHINE								
Check Interlock Operation		X						
Check Tire Pressures		X						
Check/Top Off Battery								X
Lubricate All Points		X						

[illegible]21

CHECK DAILY

Operator Presence Interlock System - Start Operation

For the engine to crank, the parking brake must be ON, the PTO (blades) OFF. Stand on the operator platform and check, one by one, if the engine will crank with the parking brake OFF or the PTO (Blades) ON.

Operator Presence Interlock System - Run Operation

In order for the engine to run, the operator must either be standing on the platform, or walking behind the unit with the platform up, the parking brake in the OFF position and the LH control handle held down out of the neutral position.

The engine may also run if the parking brake is in the ON position, the LH control handle is in the NEUTRAL position rotated up, and the PTO (blades) are OFF.

To check:

1. Start the engine and run at 1/2 throttle.
2. With the LH control handle in the NEUTRAL position rotated up, move the parking brake lever to OFF and turn the PTO (Blades) ON. Each check should kill the engine after 1/2 second delay. (A 1/2 second delay is built into the system to prevent engine cut-out when traversing rough terrain.)

Repair machine before using if the Operator Presence Interlock System does not operate correctly in start or run. Contact your authorized BOB-CAT dealer.

Hardware

Tighten any nuts and bolts found loose. Replace any broken or missing cotter pins. Repair any other problems before operating.

Tire pressure

Rear Tires should be kept inflated at 12 lbs/in² (.84kg/cm²). Improper tire inflation can cause rapid tire wear and poor traction. Uneven inflation can cause uneven cutting. Front tires should be 15p.s.i. (1.05 kg/cm²)

BATTERY-AGM TYPE BATTERY SUPPLIED



WARNING Battery acid is caustic and fumes are explosive and can cause serious injury or death. Use insulated tools, wear protective glasses or goggles and protective clothing when working with batteries. Read and obey the battery manufacturer's instructions.

Be certain the ignition switch is OFF and the key has been removed before servicing the battery.

1. Verify battery polarity before connecting or disconnecting the battery cables.
2. When installing the battery, always assemble the RED, positive (+) battery cable first and the ground, BLACK, negative (-) cable last.

3. When removing the battery, always remove the ground, negative (-) cable first and the red, positive (+) cable last.

4. AGM type battery. **Use AGM charger when charging. P/N 4171973**

5. Clean the cable ends and battery posts with steel wool. Use a solution of baking soda and water to clean the battery. Do not allow the solution to enter into the battery cells.

6. Tighten cables securely to battery terminals and apply a light coat of silicone dielectric grease to terminals and cable ends to prevent corrosion. Keep terminal covers in place.

LUBRICATION


Every 50 hours of operation, lubricate the following points (1-3) with grease:

1. Deck lift pivots (4 points)
2. Deck idler pivot (1 point)

Every 500 hours or once a year:

3. Caster wheel pivots (2 points)

NOTE ON BLADE SPINDLES - The blade spindles on these machines use a superior sealed bearing that does not require re-lubrication.





ENGINE OIL

Perform all engine maintenance with the engine OFF, spark plug wires disconnected, and PTO disengaged.

AFTER FIRST FIVE (5) HOURS

While the engine is warm:

1. Release the oil drain hose assembly from the engine clip **J**. Lay hose assembly over the frame edge.
2. Remove the rubber cap **D** from the tip of the hose assembly and turn the drain valve to allow oil to drain from the engine. Dispose of used oil in accordance with local requirements.
3. Clean drain valve and tighten the plastic portion of the drain valve back into the metal portion of the valve. Replace rubber cap over the tip of the valve. Replace hose assembly back into engine clip.
4. Change oil filter.
5. Fill the crankcase with fresh oil to the full mark. Do not overfill. See engine manual for oil specifications.



DAILY

1. Check oil level with the dipstick.
2. If oil is needed, add fresh oil of proper viscosity and grade. See engine manual for oil specifications. Do not overfill.
3. Replace dipstick before starting engine.

PERIODIC OIL CHANGES

1. See engine manual for oil and filter change intervals after the break-in period.
2. Follow instructions for first oil change, above.

SPARK PLUGS

Remove each plug and check condition.

- Good operating conditions are indicated if the plug has a light coating of grey or tan deposit.
- A white blistered coating indicates overheating. A black coating indicates an “over rich” fuel mixture. Both may be caused by a clogged air cleaner or improper carburetor adjustment.
- Do not sandblast, wire brush or otherwise attempt to repair a plug in poor condition. Best results are obtained with a new plug.
- Set plug gap as specified in engine manual.

FUEL FILTER

An in line fuel filter is located in the fuel supply line. Inspect at every oil change to make sure it is clean and unobstructed. Replace if dirty.

TRANSAXLES

⚠ WARNING

Inattention to proper safety, operation, or maintenance procedures could result in personal injury, or damage to the equipment. Schiller Grounds Care, Inc. recommends returning the machine to your authorized Schiller Grounds Care, Inc. dealer for service or repair. Check and change oil after initial 75-100 hours. Change every 400 hours after that.

Perform transaxle maintenance with the engine off, spark plug wires disconnected and PTO disengaged.

TRANSAXLE FLUID CHANGE



Change the transaxle fluid every 400 hours of operation. It is essential that the exterior of the transaxle be free of debris, prior to fluid maintenance.

1. Remove the three 1/4" filter guard screws and filter guard **A**. Remove the oil filter **B** from the transaxle and discard. Dispose of used oil in accordance with local requirements.
2. Wipe the filter base surface off and apply a film of new oil to the gasket of the new replacement filter. Install the new filter by hand, turn 3/4 to one full turn after the filter gasket contacts the filter base surface.
3. Re-install the filter guard and torque the three screws to 65 in.-lbs. each.
4. Remove cap **C**, fill the transaxles through the expansion tank **D** with approximately 2 quarts of SAE 20W-50 engine oil PER TRANSAXLE.

CAUTION

Do not overfill! If you overfill the transaxle while the unit is "cold", it may overflow as it reaches normal operating temperatures. The oil level should not be above the manufacturer's suggestions. The oil level should be filled to the full cold line on the overflow tank. This will allow the space needed for the oil to expand as it warms up.

5. After starting engine, check the fluid level and continue to add oil to overflow tank **D** to fill line on tank.
6. Purge the transaxles, following the purging procedures.



PURGING TRANSAXLES

Due to the effects air has on efficiency in hydrostatic drive applications, it is critical that it be purged from the system.

These purge procedures should be implemented any time a hydrostatic system has been opened to facilitate maintenance or any additional fluid has been added to the system.


Purging may be required if the unit shows any of the following symptoms:

- Noisy operation.
- Lack of power or drive after short term use.
- High operation temperature, excessive oil expansion.

1. Check the transaxle fluid, fill to proper level, if required. Should be to the Full Cold Line.
2. Raise the drive wheels off the ground. Support unit with jack stands or other suitable means.
3. Open bypass valves. To open the bypass valves, move the parking brake to any **OFF** position, then lift and pull bypass control rod **C** through the large opening **D**, until the control rod stop is past the opening. Drop rod **C** into the small opening to lock in place. Repeat for the other bypass

control rod. Start engine, slowly move the control levers in both forward and reverse directions 5 to 6 times. As air is purged from the unit, the oil level will drop.


4. With the bypass valve closed, and the engine running, slowly move the control levers in both forward and reverse directions 5 to 6 times.
5. Stop engine. Check the transaxle fluid level, add fluid as required.
6. It may be necessary to repeat steps 3-5 until all the air is completely purged from the system. When the transaxle moves forward and reverse at normal speed, purging is complete.



ENGINE COOLING

Continued operation with a clogged cooling system will cause severe overheating and can result in engine damage.

- **Daily:** Clean air intake screen **S** on air cooled engines.
- **Every 100 hours:** Clean cooling fins beneath blower housing **H** with reference to information in the engine manufacturer's manual.




HEAVY DUTY CYCLONIC AIR CLEANER

Clean and replace the air cleaner element as specified in the service chart. Uneven running, lack of power or black exhaust fumes may indicate a dirty air cleaner.

To replace air cleaner elements:

1. Unclamp end cover **X** and remove existing cleaner elements.
2. Insert new elements **Y** and **Z** and replace cover. Ensure the breathing port **A** is pointing down and towards the front of the tractor.



SPECIFIC TORQUES

BLADE BOLTS	70 FT-LBS (95 Nm)
WHEEL LUG NUTS	75-100 FT-LBS (102-135.5 Nm)
CLUTCH MOUNTING BOLT	50 FT-LBS (68 Nm)
TRANSAXLE PULLY BOLT	28.3-41.5 FT-LBS (38-56 Nm)
TRANSAXLE DRAIN PLUG	15-20 FT-LBS (20-27 Nm)
TRANSAXLE FILTER	100-150 IN-LBS (14.6-16.9 Nm)

CLEANING MACHINE

Clean the machine after use. Compressed air is recommended. Do not use a pressure washer. The machine will run cooler and last longer if kept free of clippings and other debris. A clean machine also reduces the risk of fire due to accumulation of combustible debris and chaff.

Brush or blow clippings and debris off the cutterdeck and engine deck. Clippings and debris should be kept from accumulating around the exhaust system and under the exhaust guards. This can be done by using compressed air. DO NOT use a pressure washer.

WASHING MACHINE


CAUTION: Improperly washing a machine can cause water to enter bearings and other components. This can greatly reduce component life.

- Do not use a pressure washer. Do not direct water at bearings or seals. High pressure water can blow past seals and enter sealed bearings.
- Allow the machine to cool down before washing. Water on a warm machine can be sucked into sealed bearings as they cool.
- Avoid getting electrical connections wet. Water can cause electrical faults and corrosion of electrical components.

BLADE REMOVAL

Follow these instructions to prevent injury during blade removal:


1. Loosen with a box wrench or a socket and long breaker bar. To gain additional leverage, slip a long pipe or thick-walled tube over breaker bar or wrench.
2. Insert wood block **A** as shown, with grain perpendicular to blade, to prevent blade from turning when loosening.
3. Wear thickly padded gloves. Keep hands clear of blade path. Blades may rotate when bolt releases.



SHARPENING

Blades may be sharpened by filing or grinding.

- Inspect blades before sharpening.
- Replace bent or cracked blades.
- Replace blades when the lift portion has worn thin.
- Maintain cut angle at 30° .
- Do not overheat blades when sharpening.
- Always use BOB-CAT blades. Use of another manufacturer's blades may be dangerous.



BLADE BALANCE


Blade balance must be maintained at 5/8 oz-in (19.4 g-cm) or less. Failure to keep blades balanced causes excess vibration, wear, and shortened life of most components of the machine.

To balance a blade:

1. Sharpen blade first.
2. Balance the blade at the center.
3. Attach a 1/8 oz (3.9 g) weight at a distance 5" (127 mm) from center on the light end. This should make the light end the heavy end:
 - If it does, the blade is balanced.
 - If does not, file or grind the heavy end until the addition of the weight makes the light end the heavy end.

BLADE INSTALLATION

1. Wear thickly padded gloves to prevent cuts from the sharp blade.
2. Insert the blade bolt, in order, through the conical washer (cup side toward the blade, as shown), the blade, and the blade spacer.
3. Install assembly on the blade spindle.
4. Torque the blade bolt to 70 ft-lbs.



BELTS



All belts are tensioned by spring loaded idlers. No adjustment is required.

DECK LEVELING

1. Park the machine on a smooth, level surface. Raise the deck to the transport position. Ensure that rear tires are at 12 psi and front tires are at 15 psi.
2. Lower the deck onto a set of equal height blocks **A** under the rear corners of the deck. Place another set of blocks under the front of the deck so that the deck top is pitched forward 1/8".

NOTE: The front and rear of the deck are at different heights.

3. Measure the height of the blade cutting edge above the ground. Remove pin **B** and set the height of cut lever **E** to that height.
4. Loosen nuts on bolts **G**. Move bolts in slot to remove slack in chain. Tighten nuts on bolts **G**.



A 1/8" forward pitched deck provides the best horsepower.

A level deck provides the best quality of cut.

A 1/8" rearward pitched deck provides the best striping.

Certain grass types and conditions may vary.

HEIGHT OF CUT


The height of cut is set by moving height of cut pin **B** to the hole designated for the height of cut desired.

To change the height of cut:

1. Lift the deck to the highest position using the lift handle **E**.
2. Move pin **B** to the selected hole.
3. Lower the deck until the lift handle **E** is stopped by the pin.

NOTES:

- Height of cut may vary due to the amount of tread on the tires, tire diameter or inflation pressure.
- For best results, adjust the deck rollers for the height of cut to be used (next page).



ADJUSTMENTS

BOB-CAT
QUICKCAT

FRONT DECK LIP

Adjustable front deck lips have been provided on 36", 48", 52", and 61" cutterdecks for various grass types and cutting conditions.


To adjust per conditions:

1. Loosen the front bolts **S**.
2. Adjust height of **H**.
3. Retighten **S** once you have desired height.

Suggested heights for grass types:
(Factory setting is all the way down.)


-Southern season grasses generally will work with the lip down. When cutting Bahia grass or other grasses where seed pods grow higher than the actual grass blade, you will want to adjust the lip all the way up.

-Northern season grasses generally require the lip all of the way down.



DECK ROLLERS


The rear outside deck rollers are adjustable up and down to provide improved deck flotation and scalping protection at various heights of cut. They are not intended to ride continuously on the ground. Adjust no closer than 3/8" (10mm) to the ground.



Height of cut ranges for roller adjustment

FRONT POINT OF REFERENCE CONTROL (PC)

- Adjust knob to move the front point of reference bar forward or back to set throw for comfort or a maximum cutting speed. Rotate the knob clockwise to move the bar forward. Turn knob counter clockwise to move bar back.




PARKING BRAKE

NOTE: There are two brakes, one on each trans-axle.

The parking brake should keep the machine from moving. To check the parking brake, park the machine on a level surface, open the bypass valves and set the parking brake to **PARK**. Attempt to move the machine forward and backward by pushing it. If the machine moves, adjust the parking brake linkage as follows:

1. Move the machine to a flat horizontal surface.
2. Move the parking brake handle to the **PARK** position.
4. Loosen Nut **K**. Tighten brake locknut **N** as needed to engage brake. Loosen brake locknut **N** as needed to disengage brake sooner.
5. Retest to insure the machine does not move.




TRACKING CONTROL ADJUSTMENT

Tracking adjustment allows for the traction handles to be even with each other when pressed all the way forward. This adjustment works in transport speed. Only use tracking adjustment if it is required to “steer” the machine straight.

To adjust:

1. Remove rider pad and locate the tracking adjustment knobs on the control mounting brackets of the machine. Turn both tracking adjustment knobs counter clockwise until they stop.
2. Gently push both traction control handles all the way forward with transport speed selected. Turn the tracking adjustment knob clockwise until it touches the corresponding control arm so the tracking adjustment knob limits the stroke of the traction lever rather than the control stops on the hydrostat. Repeat for the other side.
3. Find a suitable level and open area. Get on the machine and start the engine. Run it at half throttle for better control.
4. Point the machine in a safe direction and drive it with both traction handles pushed completely forward. If the machine drives straight you are done. If the machine drifts from a straight line proceed to step 5.
5. Stop the machine, move the traction levers to the neutral position and set the parking brake. Turn the tracking knob on the outside of the drift 1/6 turn clockwise.
6. Drive the machine again and repeat the adjustment until the machine drives straight.




HYDROSTAT TRANSAXLE

A turnbuckle-style hydrostat neutral adjustment is provided.

Neutral adjustment is for setting the location of the control handles with respect to each other or the operator presence slot, or parking brake locks.

Neutral: (neutral is set by the hydrostatic transaxles)

1. Loosen jam nuts **A** at both ends of the control rod **B**.
2. Loosen the nuts **C** on the control lock rod **D**.
3. Rotate the control rod **B** until both left and right handle is aligned with the slot on the control panel.
4. Tighten the jam nuts **A** at the top and the bottom of the control rod **B**.
5. Press the control lock rod **D** into the slot in the control and tighten nut **C**.




DAMPERS

Dampers are provided on the traction controls to make it easier to operate the machine smoothly. There is one on each side. There are three mounting positions for each damper.

Center Position: Standard

Outer Position: Increase the damping and make traction controls stiffer to operate.


Inner Position: Decrease the damping and make the controls lighter to operate.



Note: Always use Schiller Grounds Care, Inc. replacement belts, not general purpose belts. Schiller Grounds Care, Inc. belts are specially designed for use on commercial mowers and will normally last longer.

CUTTERDECK BELT

1. Remove center, left and right belt guards.
2. Set the cutterdeck in a middle height-of-cut position.
3. Loosen bolt on belt guide so belt guide can be moved to remove the belt.
4. Insert 3/8" ratchet extension in hole A on the idler arm to back tensioning idler off to remove belt from idler. Remove belt from cutterdeck pulleys.
5. Remove belt from clutch pulley.
6. Install the new belt by performing these steps in reverse order.
7. Cutterdeck spring will require tension adjustment after belt installation. Adjust eyebolt so the distance between the inside of the spring hooks is $6\text{-}3/4" \pm 1/8"$.
8. Reinstall cutterdeck belt and guards.





NOTE: After usage of the machine, the belt will seat into the pulleys and reduce the length of the spring. DO NOT RE-ADJUST THE EYEBOLT. This is normal. If you do adjust the eyebolt, you will over tension the belt, greatly reducing the belt's life.

TRANSAXLE DRIVE BELT

1. Remove engine-cutterdeck belt. (See cutterdeck belt above)
2. To remove transaxle drive belt, use a 3/8" ratchet and extension. Insert ratchet extension in the square hole A of the transaxle idler arm. Rotate enough to remove the transaxle drive belt.
3. Install a new transaxle drive belt by performing these steps in reverse order.

NOTE: Inspect the fans. Replace if worn or damaged.



POWER UNITS

ENGINES:

Construction: Aluminum block with cast-in cast iron sleeves. Aluminum head.

Configuration: 4-stroke, vertical shaft, V-twin cylinder, overhead valve, air-cooled.

DRIVE SYSTEM:

Transaxles: Dual HydroGear ZT3400 Commercial Duty Hydrostatic transaxles (12cc Pumps)

Turn Radius: True Zero

OPERATOR PRESENCE

INTERLOCK SYSTEM:

Start Operation

For the engine to crank, the parking brake must be ON, the PTO (blades) OFF. Stand on the operator platform and check, one by one, if the engine will crank with the parking brake OFF or the PTO (Blades) ON.

Run Operation

In order for the engine to run, the operator must either be standing on the platform, or walking behind the unit with the platform up, the parking brake in the CUT or TRANSPORT position and the LH control handle held down out of the neutral position.

The engine may also run if the parking brake is in the ON position, the LH control handle is in the NEUTRAL position rotated up, and the PTO (blades) are OFF.

To check:

1. Start the engine and run at 1/2 throttle.
2. With the LH control handle in the NEUTRAL position rotated up, move the parking brake lever to OFF and turn the PTO (Blades) ON. Each check should kill the engine after 1/2 second delay. (A 1/2 second delay is built into the system to prevent engine cut-out when traversing rough terrain.)

Repair machine before using if the Operator Presence Interlock System does not operate correctly in start or run. Contact your authorized BOB-CAT dealer.

WEIGHT:

970 lbs (440 kg) w/48" deck & full tanks
995 lbs (451 kg) w/52" deck & full tanks
1030 lbs (467 kg) w/61" deck & full tanks

CONTROLS:

Throttle; choke; power takeoff (PTO) clutch switch; control lever; parking brake lever; lift lever.

FUEL SYSTEM:

One tank in the control tower with total capacity 6.5 gallons (24.6 liters) with a fuel guage. Replaceable fuel filter.

MAXIMUM GROUND SPEEDS:

Forward: Transport- 10.5 mph (16.9 km/h)

Cut - 8 mph

Reverse: 4 mph (6.4 km/h)

WHEELS & TIRES:

Drive wheels:

912480: 23 X 8.5-12 4-Ply Turf Tread Tires

912520 & 912610: 23 X 10.5-12 4-Ply Turf Tread Tires

Casters:

48", 52" & 61" : 13 X 6.5-6 tires

Pressure: Rear tires 12 p.s.i. (.84 kg/cm²)
Front tires 15 p.s.i. (1.05 kg/cm²)

ENGINES			
MODEL NUMBER	912480	912520	912610
MANUFACTURER	Kawaskai	Kawasaki	Kawasaki
MODEL	FX651V	FX691V	FX730V
CYLINDERS	2	2	2
COOLING	Air	Air	Air
BORE/STROKE	3.1 X 3.0" (78 X 76 mm)	3.1 X 3.0" (78 X 76 mm)	3.1 X 3.0" (78 X 76 mm)
DISPLACEMENT	44.3 cu. in. (726 cc)	44.3 cu. in. (726 cc)	44.3 cu. in. (726 cc)
COMPRESSION	8.2:1	8.2:1	8.2:1
OUTPUT POWER			
OUTPUT TORQUE	39.0 ft-lb (52.8J) @2200 rpm	39.4 ft-lb (53.4J) @2200 rpm	42.1 ft-lb (55.4J) @2400 rpm
LUBRICATION	FULL PRESSURE	FULL PRESSURE	FULL PRESSURE
GOVERNOR	Mechanical	Mechanical	Mechanical
AIR CLEANER	Heavy Duty Cyclonic	Heavy Duty Cyclonic	Heavy Duty Cyclone
IGNITION SYSTEM	Electronic	Electronic	Electronic
CHARGING SYSTEM	15 amp, regulated	15 amp, regulated	15 smp, regulated
BATTERY	BCI group U1	BCI group U1	BCI group U1
FUSES	Two, 20 amp blade	Two, 20 amp blade	Two, 20 amp blade

CUTTERDECKS			
MODEL NUMBER	912480	912520	912610
TYPE	Side Discharge	Side Discharge	Side Discharge
CUTTING WIDTH	47.25" (120 cm)	52.5" (133 cm)	61" (155cm)
WIDTH (CHUTE UP)	48.38" (122.5 cm)	53.88" (137 cm)	62" (157sm)
WITDH (CHUTE DOWN)	60.88" (154.5cm)	66.38" (168.5 cm)	73" (18sm)
BLADE	high lift	high lift	high lift
NUMBER OF BLADES	3	3	3
BLADE LENGTH	16.25" (41 cm)	18" (46 cm)	21" (53cm)
BLADE THICKNESS	.205" (5.2 mm)	.205" (5.2 mm)	.25 (6.35mm)
TIP SPEED	17773 ft/min 5420 m/min @3600 Engine RPM	18585 ft/min 5665 m/min @3600 Engine RPM	18850 ft/min 5745 @3600 Engine RPM
ANTI-SCALP ROLL-ERS	4	4	7

CONSTRUCTION:

Fabricated and welded 7-gauge, double-layer steel top with 7-gauge side skirts. Full floating design.

CUTTERDECK DRIVE SYSTEM:

Electric clutch/brake drives belt directly from engine to cutterdeck. No twists in drive belt.

Torque information located on page 27.

SPINDLES:

Bottom mounted and maintenance free, with 1" shaft in precision machined, cast iron housing

CUTTING HEIGHT & PRODUCTION:


Height: Lever allows easy setting of cut heights from 1-1/2" to 4-1/2" in 1/4" increments.

PARTS SECTION

ENGINE DECK ASSY

BOB-CAT
QUICKCAT

FIGURE 1



ENGINE DECK ASSY

BOB-CAT
QUICKCAT

FIGURE 1


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME W/ LABELS	1	28	48412-01	CLIP-CABLE 3/4 J X 10.32	2
2	4172751.7	PLATE-ENGINE	1	29	88042-03	CLAMP, HOSE 5/8	2
3	4164366	ENGINE-22HP KAW FX USED ON 48" ONLY	1	30	48228A	CABLE CLIP-INSULATED	1
	4164367	ENGINE-24HP KAW FX USED ON 52" ONLY	1	31	64006-01	LOCKWSHR-1/4 HELICAL USED ONLY ON 48" & 52" MODELS	1
	4164368	ENGINE-26HP KAW FX USED ON 61" ONLY	1		64006-02	LOCKWSHR-5/16 HELICAL USED ONLY ON 61" MODELS	1
4	4170548-04	MUFFLER-ENGINE	1	32	64025-01	1/4-20 HEX NUT USED ONLY ON 48" & 52" MODELS	1
*	4170548-02	MANIFOLD-MUFFLER	1		64207-01	NUT-HEX M8-1.25 USED ONLY ON 61" MODELS	1
*	4170548-03	CLAMP-MUFFLER	1				
5	4170170	PULLEY-4.5 INCH	1	33	4176548.7	GUARD-MUFFLER	1
6	4171141	CLUTCH-ELECTRIC	1	34	64018-51	BLT-CRG 5/16-18 X 3/4	2
7	4169106	PIN-CLUTCH, TALL	1	35	4171542.7	GUARD-EXHAUST MNFLD	1
8	4173452.7	WLDMT-CLUTCH STOP	1	36	64263-007	BLT-FLG HD M8-1.25 X 20	1
9	38665	SOLENOID USED ONLY ON 48" & 52" MODELS	1	37	64266-02	NUT-FL CRWN LCK M8-1.25	3
10	4164252-001	FITTING-3/8NPT TO 3/8	1	ITEMS 38-40 USED ON "CA" MODELS ONLY			
11	4164251	DRAIN VALVE	1	38	4171036	CANISTER-CARBON, 9GAL	1
12	69053-05	HOSE-HYD 3/8 ID X 55 (17IN)	1	39	4172179.7	BRKT-CARB CANISTER	1
13	64006-03	LOCKWSHR-3/8 HELICAL	5	40	64262-006	BLT-FLG HD 5/16-18 X 3/4	2
14	64123-16	BLT-HEX 3/8-16X1-1/4	4				
15	64164-12	KEY-1/4X1 SQ	1				
16	64006-06	LOCKWSHR-7/16 HELICAL	1				
17	64123-155	BLT-HEX 7/16-20 X 3	1				
18	64018-44	BLT-CRG 3/8-16X1 NECK)	5				
19	4171826	WSHR-5/16 TEF	4				
20	38304-03	BEARING-FLANGED PLAS	1				
21	64123-54	BLT-HEX 5/16-18 X .75	4				
22	64268-02	NUT-FL NY LOCK 5/16-18	6				
23	64001-6	NUT-HEX JAM 3/8-16	4				
24	64268-03	NUT-FL NY LOCK 3/8-16	4				
25	64263-007	BLT-FLG HD M8-1.25 X 20	5				
26	64018-2	BLT-CRG 1/4-20X3/4 USED ONLY ON 48" & 52" MODELS	2				
27	64229-01	NUT-NYLON LOCK 1/4-20 USED ONLY ON 48" & 52" MODELS	2				

* NOT ILLUSTRATED

RIDER PLATFORM ASSY

FIGURE 2

BOB-CAT
QUICKCAT



BOB-CAT
QUICKCAT

FIGURE 2


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME W/ LABELS	1				
2	4171132.7	WLDMT-FTPLTE MOUNT	1				
3	4170585	BUMPER-RADIAL	4				
4	4170388	SPACER-FTPLATE LATCH	1				
5	4170383.7	BRKT-LATCH, FOOTPLATE	1				
6	4171366	S-FOOTPLATE w/ LABELS	1				
7	4171113.7	PLATE-TANK SKID	1				
8	4170670	MAT-FOOTPLATE	1				
9	4171672	BUMPER-FOOTPLATE	2				
10	4175836	LABEL-BOB-CAT	1				
11	4166324-04	BEARING-SLEEVE	2				
12	4171254	SPACER-.625X11GAX1.375	2				
13	64229-10	NUT-NYLON LOCK 10-24	4				
14	64152-49	SCREW-SLT HH 10-24X3/4	4				
15	64018-44	BLT-CRG 3/8-16X1	10				
16	64268-03	NUT-FL NYLON LOCK 3/8-16	12				
17	64262-006	BLT-FLG HD 5/16-18 X 3/4	1				
18	64268-02	NUT-FL NYLON LOCK 5/16-18	5				
19	64262-027	BLT-FLG HD 3/8-16 X 2-1/4	2				
20	64272-03	FLT-HEX SCR 5/16-18X2-1/2	4				
21	64163-31	WSHR 25/64X1X12	2				
22	4171365	CAP-LATCH FOOTPLATE	1				

***NOT ILLUSTRATED**

WHEEL & TRANSAXLE ASSY

BOB-CAT
QUICKCAT

FIGURE 3




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME W/ LABELS	1	27	64268-02	NUT-FL NYLON LOCK 5/16-18	4
2	4171630	S-ASSYTRANSAXLE-LH (INCLUDES ITEM 37)	1	28	64262-025	BLT-FLG HD 3/8-16 X 2-1/2 LG	4
3	4171631	S-ASSYTRANSAXLE-RH (INCLUDES ITEM 37)	1	29	64268-03	NUT-FL NYLON LOCK 3/8-16	4
4	64018-2	BLT-CRG 1/4-20X3/4	2	30	64229-01	NUT-NYLON LOCK 1/4-20	2
5	4175248	ASSY-WHL 23X10.50-12 BLK	2	31	64168-2	COTTER-HAIRPIN .08 X 1.19	2
	4171868-01	TIRE-23X10.5-12 OTR		32	64123-15	BLT-HEX 3/8-16X3/4	2
	4175248-02	RIM-12X8.5 BLK USED ON 52" & 61" ONLY		33	64268-01	NUT-FL NYLON LOCK 1/4-20	2
	4176239	ASSY-WHL 23 X 8.5-12 BLK	2	34	4142808-01	CAP-TANK, HYDRA	1
	4176239-01	RIM-12 X 7 BLACK		35	4176331.7	BRKT-TANK EXPANSION	1
	4174236-01	TIRE-23 X 8.5-12 USED ON 48" ONLY		36	64123-38	BLT-HEX 7/16-14X1	2
6	4170275	ASSY-IDLER ARM (INCLUDES ITEMS 38-41)	1	37	4171150	KIT-FAN/PULLEY TRNSXL	2
7	2308000	PULLEY-IDLER 4.00 EOD	1	38	64144-40	SNAP RING-26MM INTERNAL	1
8	4128002	CAP-26 X 7 END	1	39	4170274.7	WLDMT-IDLER ARM	1
9	2188131	SPRING, EXT	1	40	4128004	BEARING-BALL 10 X 26 X 8	2
10	4170486	BELT-TRANSAXLE DRIVE	1	41	4127999	SEAL-16 X 24 X 7	1
11	4148698.7	LINK-DUMP VALVE	2	42	64229-04	NUT-NYLON LOCK 7/16-14	2
12	4148697	ROD-PULL FREEWHEEL	2				
13	2720977	SPRING-COMPRESSION	2				
14	4173339.7	PLATE-TRANSAXLE	2				
15*	4142045-06	FILTER-TRANSAXLE	2				
16	4142808	TANK-HYDR, EXPAN W/CAP	1				
17	2690030-02	FTG-9/16-18 ORB X 1/2	2				
18	4176445-01	TUBING-1/2ID CLEAR, 15IN	2				
19	64163-61	WSHR .81X.406X16GA	1				
20	108094-12	CLAMP-HOSE SAE6	4				
21	64018-49	BLT-CRG 3/8-16 X 1-1/2	1				
22	64270-01	BLT-HEX M10-1.5x30	1				
23	64151-34	NUT-HEX LOCK, 3/8-16 JAM	3				
24	33148-01	SPACER-0.379X0.750X0.25	1				
25	64187-03	NUT-WHEEL 1/2-20	8				
26	64139-30	BLT-WLFS 5/16-18 X 3-1/2	4				

***NOT ILLUSTRATED**

FUEL TANK & BATTERY ASSY

FIGURE 4

BOB-CAT
QUICKCAT



FUEL TANK & BATTERY ASSY

BOB-CAT
QUICKCAT

FIGURE 4


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME W/ LABELS	1				
2	4175912	TANK-FUEL	1				
		INCLUDES ITEMS 24-30					
3	4176531	CAP-FUEL 3.5", W/SCRATCH	1				
4	4142808	TANK -HYDRO EXPANSION	1				
		INCLUDES ITEM 5					
5	4142808-01	CAP-HYDRO TANK	1				
6	4176331.7	BRKT-TANK, EXPANSION	1				
7	4165864	FITTING-1/4 TO 3/16	1				
8	4162989-001	HOSE-FUEL LINE, 25IN	1				
9	64006-03	LOCKWSHR-3/8 HELICAL	4				
10	64123-50	BLT-HEX 3/8-16X1	4				
11	64163-69	WSHR .391X.88X10 GA	4				
12	88042N	CLAMP-HOSE	4				
13	88042-01	CLAMP-HOSE 3/16	2				
14	4171099	BATTERY-190CCA	1				
*	4171973	CHARGER-BATTERY, AGM					
15	4168635	S-BRKT, BATTERY W/LABS	1				
		INCLUDES ITEM 20					
16	4171586	BUMPER-RUBBER	1				
17	64262-002	BLT-FLG HD 1/4-20 X 3/4	2				
18	64163-03	WSHR .256ID X.62OD X 18 GA.	2				
19	64025-01	1/4-20 HEX NUT	2				
20	2000590	LABEL-WARN BATTERY	1				
21	2000570	LABEL-WARN FUEL PICT	1				
22	4162977-001	HOSE, FUEL LINE 6 INCH	2				
23	64123-49	BLT-HEX 1/4-20 X1/2	4				
24	64152-46	SCREW-SLT HH 10-24X1/2	5				
25	4174343	GROMMET-ROLLOVER VENT	1				
26	4165763	TANK VENT	1				
27	4132325	GROMMET-SEALING	1				
28	4175912-02	TUBE-FUEL, PICK-UP	1				
29	4175914	GASKET-FUEL SENDER	1				
30	4175912-01	SENDER-REED, FUEL 22"	1				
31	64006-01	LOCKWASHER-1/4 HELICAL	4				
32	64018-2	BLT-CRG 1/4-20X3/4	2				
33	64268-01	NUT-FL NYLON LK 1/4-20	2				
34	108094-12	CLAMP-HOSE SAE6	4				
35	4176445-01	TUBING-1/2ID CLEAR, 15IN	2				

***NOT ILLUSTRATED**

PARKING BRAKE ASSY

FIGURE 5

BOB-CAT
QUICKCAT



PARKING BRAKE ASSY

BOB-CAT
QUICKCAT

FIGURE 5


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4171630	S-ASSYTRANSAXLE-LH	1				
	4171631	S-ASSYTRANSAXLE-RH	1				
2	4173481	WLDMT-PRKNG BRK/SPD CNTRL	1				
3	4170934.7	PLATE- BRK & SPD CNTRL	1				
4	4177194	S-BRKT, CONTROL RH	1				
5	4172259.7	PLATE-PRKNG BRK SPRING	2				
6	64229-03	NUT-NYLON LOCK 3/8-16	4				
7	64123-68	BLT-HEX 5/16-18X1	2				
8	64123-15	BLT-HEX 3/8-16X3/4	4				
9	64123-88	BLT-HEX 3/8-16X2-3/4	2				
10	64268-03	NUT-FL NYLON LOCK 3/8-16	4				
11	2308065	SPRING-EXTENSION	2				
12	64168-2	COTTER-HAIRPIN .08 X 1.19	3				
13	4170367	ROD-PARKING BRAKE, LOWER	1				
14	64018-57	BLT-CRG 5/16-18X6	1				
15	64188-65	PIN-CLEVIS, 1/4 X .62	1				
16	4168217.7	BRACKET-CLIP, RETAINER	1				
17	4176179.7	BRKT-PAKNG BRAKE UPPER	1				
18	64123-12	BLT-HEX 5/16-18X2-1/2	2				
19	64025-02	NUT-HEX 5/16-18	3				
20	64268-02	NUT-FL NYLON LOCK 5/16-18	5				
21	4176054	WLDMNT-SPD CNTRL HANDLE	1				
22	4176120	KNOB-1.32" TAPERED, 3/8 THRD	1				
23	516544	BUSHING (PLATING)	2				
24	64262-014	BLT-FLG HD 3/8-16 X 2	1				
25	41-053	SPRING COMP .681 X 1.125	1				
26	4177195	S-BRKT, CONTROL LH	1				
27	64025-15	NUT-HEX #10-24 KEPS	2				
28	64152-49	SCREW-SLT HH 10-24X1/2	2				
29	2188145-01	BEARING-.75ID BRZ SELF ALIGN	2				
30	64141-6	NUT-WLF 5/16-18	2				
31	2188156	SWITCH-NONO DBL POLE	1				

*NOT ILLUSTRATED

UPPER WIRE HARNESS

FIGURE 6

BOB-CAT
QUICKCAT



UPPER WIRE HARNESS

BOB-CAT
QUICKCAT

FIGURE 6


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4176733	HARNESS-WIRING, UPPR	1				
2	128010	SWITCH, KEY	1				
3	2188154	MODULE-DELAY	1				
4	2721505	SWITCH-PTO	1				
5	2188156	SWITCH-NONO DBL POLE	2				
6	4177930	METER-HOUR MAG SENSOR	1				
7	4173756	FUSE-20 AMP MINI	2				
8	4173755	RELAY-SPDT MICRO	4				
9*	64018-41	BLT-CRG 1/4-20 X 5/8	3				
10*	64268-01	NUT-FL MYLON LOCK 1/4-20	3				
11	4176734	HARNESS-JUMPER, FUEL GAUGE	1				
12	4176839	GAUGE, FUEL	1				

***NOT ILLUSTRATED**

48" & 52" LOWER WIRE HARNESS

BOB-CAT
QUICKCAT

FIGURE 7



48" & 52" LOWER WIRE HARNESS

BOB-CAT
QUICKCAT


FIGURE 7

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4173594	HARNESS-WIRING, LOWER	1				
2	4171141	CLUTCH-ELECTRICAL	1				
3	38665	SOLENOID	1				
4	108061-04	CABLE-BATTERY 20 RED	1				
5	2720949	ASSY-CLUTCH WIRE	1				
6	4171099	BATTERY-190CCA	1				
*	4171973	CHARGER-BATTERY,AGM					
7	30-419	CABLE-BATTERY BLACK 29	1				
8	112386	BOOT-BATTERY TERM POS	1				
9	2722227-02	CABLE-BATTERY W/CONDUIT	1				
10	2308095	COVER-TERMINAL	3				

61" LOWER WIRE HARNESS

BOB-CAT
QUICKCAT

FIGURE 8



61" LOWER WIRE HARNESS

BOB-CAT
QUICKCAT

FIGURE 8


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4173593	HARNESS-WIRING, LOWER	1				
2	4171141	CLUTCH, ELECTRIC	1				
3	2722227-02	CABLE-BATTERY W/CONDUIT	1				
4	2308095	COVER-TERMINAL	1				
5	2720949	HARNESS-CLUTCH-JUMPER	1				
6	4171099	BATTERY-190CCA	1				
*	4171973	CHARGER-BATTERY,AGM					
7	30-419	CABLE-BATTERY BLACK 29	1				
8	112386	BOOT-BATTERY TERM POS	1				

*NOT ILLUSTRATED

TOWER ASSY

BOB-CAT
QUICKCAT

FIGURE 9




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4176941	S-CONTROL PANEL W/LABELS	1				
2	4176341.2	PANEL-TOWER FRONT	1				
3	4170601.7	GUARD-FAN,LH	1				
4	4176343.2	PANEL-TOWER LH	1				
5	4176342.2	PANEL-TOWER RH	1				
6	4176609.7	BRKT-RELAY MNTG	1				
7	4176700	KNOB-FLUTED, 5/16-24 X 2.00	1				
8	4173635.7	WLDMT-PARKING BRK STOP	1				
9	4176266.7	ROD-POR, FRONT	1				
10	4167343-01	ROD END-FML W/BALL STUD	1				
11	800889	NUT .31-18 NS SPD J W/NUT	4				
12	56-046-03	TRIM LOK 28.00" LONG	1				
13	64262-007	BLT-FLG HD 5/16-18 X 1	4				
14	64018-44	BLT-CRG 3/8-16X1 SN	4				
15	64268-03	NUT-FL NYLON LOCK 3/8-16	6				
16	64268-01	NUT-FL NYLON LOCK 1/4-20	5				
17	64018-41	BLT-CRG 1/4-20 X 5/8	3				
18	64123-70	BLT-HEX 3/8-16X1-1/2	2				
19	4176287-01	BEARING-SMALL SLF ALGN	2				
20	64268-02	NUT-FL NYLON LOCK 5/16-18	4				
21	4116380-01	SPACER .272X.438X.635	4				
22	64018-51	BLT-CRG 5/16-18 X 3/4 SN	4				
23	64229-08	NUT-NYLON LOCK 5/16-24	2				
24	4169895	WASHER-FRICTION,UHMW	1				
25	4169871	WASHER-BELLVILLE,.382 ID	1				
26	64229-01	NUT-NYLON LOCK 1/4-20	4				
27	4170600.7	GUARD-FAN,RH	1				
28	4176706	LABEL-QUICKAT 4000	1				
29	4175929	LABEL-BOBCAT, 1.38X8.96	2				
30	64018-2	BLT-CRG 1/4-20X3/4	2				
31	64018-67	BLT-CRG 1/4-20X1-1/4	4				
32	4177207	LABEL-POR ADJUSTMENT	1				

*NOT ILLUSTRATED

RIDER PAD & FENDER ASSY

FIGURE 10

BOB-CAT
QUICKCAT



RIDER PAD & FENDER ASSY

BOB-CAT
QUICKCAT


FIGURE 10

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4176340.2	PANEL-REAR TOWER	1				
2	4176396	PAD-RIDER, WIDE	1				
3	4170384.7	BRKT-PAD,SUPPORT	1				
4	4171100	TETHER-WIRE, COATED	1				
5	4170598.7	FENDER-WHEEL	2				
6	4167193	PLUG-PLASTIC, 1.125"	1				
7	64018-41	BLT-CRG 1/4-20 X 5/8	2				
8	4160281	S-DOCUMENT TUBE/LABEL	1				
9	2000735	LABEL-OPER MAN	1				
10	38061A	CAP-BLACK VINYL	1				
11	64262-007	BLT-FLG HD 5/16-18 X 1	2				
12	4170388	SPACER-FOOTPLATE LATCH	2				
13	64268-01	NUT-FL NYLON LOCK 1/4-20	3				
14	64018-15	BLT-CRG 5/16-18X1 SN	6				
15	64268-02	NUT-FL NYLON LOCK 5/16-18	10				
16	64018-2	BLT-CRG 1/4-20X3/4	1				
17	64123-114	BLT-HEX 1/4-20X1	3				
18	64006-01	LOCKWSHR-1/4 HELICAL	6				
19	64163-02	WSHR .321X.593X11GA	2				
20	4175836	LABEL-BOB-CAT,2.0X15.5	1				
21	4170614.7	BRKT-SHIELD,FILLER	1				
22	64018-51	BLT-CRG 5/16-18 X 3/4 S/N	2				
23	64123-89	BLT-HEX 1/4-20X3/4	3				

CONTROLS

BOB-CAT
QUICKCAT

FIGURE 11



BOB-CAT QUICKCAT


FIGURE 11

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4173339.7	PLATE-TRANSAXLE	1	34	64141-15	NUT-WLF 10-24	2
2	4176941	S-PANEL-CONTROL W/LAB	1	35	64168-2	COTTER-HAIRPIN .08 X 1.19	1
3	4176939	S-CONTROL,LH (INCLUDES ITEM 6)	1	36	2188156	SWITCH-NONO DBL POLE	1
				37	128010	SWITCH KEY 5	1
4	4170532	SHAFT-CONTROL HANDLE	1	38	2721505	SWITCH-PTO	1
5	4177195	S-BRKT CONTROL LH INCLUDES ITEM 45	1	39	4177930	METER-HOUR, ALERTS	1
				40	64152-49	SCREW-SLT HH 10-24X3/4	2
6	4166324-05	BEARING-SLEAVE .625X.50	4	41	4176580	LABEL-CONTROL	1
7	4167343-02	ROD END-5/16 FEM LFT	2	42	4171409	SPACER-.625X.386X1.26	1
8	4167343-01	ROD END-5/16 FEM RHT	2	43	4166324-04	BEARING-PLASTIC .625X1	1
9	4176180	ROD-CONTROL	2	44	4176839	GAUGE-FUEL	1
10	4173321	ROD-POINT OF REFERENCE	1	45	4173804	RIVET NUT 5/16-18 X 0.312	2
11	108009-03	CONTROL-CHOKE 51	1	46	4177194	S-BRKT CONTROL RH INCLUDES ITEM 45	1
12	118020-22	CONTROL-THROTTLE, 57.5IN	1				
13	4172963	GRIP-3/4 X 7.5	2	47	4163446	KNOB-3 PRONG MALE, 5/16-18	2
14	4176940	S-CONTROL,RH (INCLUDES ITEM 6)	1	48	64163-55	WSHR .328X.75X14 GA	2
				49	41-053	SPRING COMP .681 X 1.125	2
15	4171587	S-HANDLE OP PRESENCE	1	50	64151-41	NUT-HEX,5/16-18 NYLON JAM	2
16	4171171	CONTROL HANDLE	1	51	2228065	DAMPER-NON-CAVITATING	2
17	4171344	LABEL-OPS MANUAL	1				
18	4171461	SPRING, EXT	1				
19	64018-51	BLT-CRG 5/16-18 X 3/4 SN	4				
20	64268-02	NUT-FL NYLON LOCK 5/16-18	8				
21	64221-02	E-RING .625	2				
22	64229-08	LOCKNUT NYLON 5/16-24	4				
23	64268-05	NUT-FLNYLON LOCK 1/2-13	2				
24	64152-46	SCREW-SLT HH 10-24X1/2	2				
25	64025-15	NUT-HEX #10-24 KEPS	4				
26	64025-03	NUT-HEX 5/16-2424	2				
27	64025-33	NUT-HEX 5/16-24 LH	2				
28	64262-013	BLT-FLG HD 3/8-16 X 1-1/2	2				
29	64262-027	BLT-FLG 3/8-16 X 2-1/4	1				
30	64268-03	NUT-FL NYLON LOCK 3/8-16	3				
31	64163-31	WSHR-.25/64X1X12	1				
32	64025-04	NUT-3/8-24 HEX	1				
33	64158-01	EYE BOLT-10-24 X 1.25	1				

DECK LIFT ASSY / HOC

FIGURE 12

BOB-CAT
QUICKCAT




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME 36IN W/ LABELS	1				
2	64268-03	NUT-FL NYLON LOCK 3/8-16	6				
3	4176158.7	WLDMT-HOC HANDLE	1				
4	C100018	GRIP-HANDLE	1				
5	4173208	SPACER-HOC ARM	2				
6	517162	SPACER, RUBBER .328 (8mm)	2				
7	64163-31	WSHR 25/64X1X12	2				
8	64262-029	BLT-FLG HD 3/8-16 X 1-3/4	2				
9	4173145.2	WLDMT-HOC	1				
10	4173146.2	PLATE-HOC, OUTSIDE	1				
11	4170653	LABEL-HOC	1				
12	4170988	LABEL-HOC	1				
13	2183071-05	SPACER	2				
14	64262-027	BLT-FLG HD 3/8-16 X 2-1/4 GR8	2				
15	4177355	ASSY-PIN & LANYARD	1				
16	4167826	ROD-DECK LIFT	2				
17	64221-04	E-RING .875	4				
18	4176557.7	WLDMT-HOC HANDLE TOP	1				
19	4169126-01	CHAIN-6.35 (.250) 7 LINKS	4				
20	64123-281	BLT-HEX 1/2-13X2 FLL THRD	8				
21	64141-13	NUT-WLF 1/2-13	16				
22	64229-06	NUT-NYLON LOCK 5/8-11	2				
23	4168424	ZERK-1/4-28 SHT NECK STP	4				
24	4174098.7	WLDMT-PULLARM	2				
25	2188145-02	BEARING-.75ID SELF ALIGN	4				
26	64018-44	BLT-CRG 3/8-16X1 SN	8				
27	64229-03	NUT-NYLON LOCK 3/8-16	8				
28	64123-168	BLT-HEX 5/8-11X2-1/2	2				

* NOT ILLUSTRATED

CASTER ASSY

FIGURE 13

BOB-CAT
QUICKCAT




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177193	S-FRAME W/ LABELS	1				
2	4170130.2	WLDMT-CASTER ARM, LH (INCLUDES ITEM 4) USED ON 48" & 52"	1				
	4170993.2	WLDMT-CASTER ARM, LH (INCLUDES ITEM 4) USED ON 61"	1				
3	4170131.2	WLDMT-CASTER ARM, RH (INCLUDES ITEM 4) USED ON 48" & 52"	1				
	4170994.2	WLDMT-CASTER ARM, RH (INCLUDES ITEMS 4) USED ON 61"	1				
4	48043-03C	CUP OUTER BEARING	4				
5	48043-04C	CONE-OUTER BEARING	4				
6	48480	SEAL CR 12411	2				
7	4167764.7	WLDMT-CASTER YOKE	2				
8	64140-5	COTTER PIN-1/4-2	2				
9	4162986	CAP-END	2				
10	4175255	ASSY-WHEEL 13X6.5-6 BLK	2				
11	2722230-03	SPANNER-13X6.5 WHEEL	2				
12	2722231	SPACER-END	4				
13	4177357.7	COVER-BELT, CNTR	1				
14	38524	KNOB-4 PRONG 3/8-16	1				
15	64209-17	WSHR-CON SPRNG .75X1.5	2				
16	64025-20	NUT-HEX 3/4-16 SLOT U	2				
17	85010N	ZERK 1/4-28 STR SLF THD	2				
18	64123-223	BLT-HEX 3/4-10X10	2				
19	64229-07	NUT-NYLON LOCK 3/4-10	2				
20	64262-011	BLT-FLG HD 3/8-16 X 1	8				
21	64229-03	NUT-NYLON LOCK 3/8-16	8				
22	64018-39	BLT-CRG 3/8-16X1-3/4 FL TH	1				
23	64163-98	WSHR-.515X.875X14GA	1				
24	64141-4	NUT-WLF 3/8-16	1				
25	4175836	LABEL-BOB-CAT	1				
26	4143354	BUMPER-RUBBER	2				
27	64141-6	NUT-WLF 5/16-18	2				

48" SIDE DECK ASSY

FIGURE 14

BOB-CAT
QUICKCAT



48" SIDE DECK ASSY

BOB-CAT
QUICKCAT

FIGURE 14


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177047	S-CUTTERDECK 48" W/ LABELS	1	38	64123-133	BLT-HEX 5/8-18X3	3
2	4174965-2	ASSY-CTRDCK SPINDLE (INCLUDES ITEMS 21-24)	3	39	64018-33	BLT-CRG 1/2-13 X 4-1/2	1
3	4174433	PULLEY-SPINDLE,48IN	3	40	4164269	LABEL-WRNNG THRWN	1
4	4174961-1	SPINDLE-SPACER, BLADE 0.63	3	41	2000577	DECAL, "ROTATING PARTS"	3
5	112111-01	BLADE 16.25 OFFST HLFT	3	42	4162914	LABEL-DECK SIZE,48	1
5	112111-01-LE	BLADE 16.25 LAZER EDGE (OPT)		43	4116761	LABEL-MADE IN USA	1
6	4170021.7	WLDMT-IDLER PIN	1	44	64018-44	BLT-CRG 3/8-16X1 SN	3
7	4163014	SPACER	1	45	4175081	SPINDLE-SPACER, SLINGER	3
8	4163155	INNER RING	1	46	64209-16	SPRING WASHER .669 X 1.75	3
9	4171371	S-IDLER ARM (INCLUDES ITEMS 10-15)	1	47	64123-187	BLT-HEX 5/8-18X3-3/4	3
10	521438	GREASE SEAL	1	48	64268-03	NUT-FL NYLON LOCK 3/8-16	25
11	548138	BRG NDL.88 1.12 1.00 END	1	49	64158-08	EYE BOLT 5/16-18 X 2.5	1
12	4128004	BEARING-BALL 10 X 26 X 8	1	50	64018-16	BLT CRG 1/2-13 X 5	1
13	85010N	ZERK 1/4-28 STR S-THRD	1	51	64268-05	NUT-FL NYLON LOCK 1/2-13	3
14	64144-40	SNAP RING-26MM INTERNAL	1	52	4170596.7	SHIELD-BELT,48IN	1
15	4170610.7	WLDMT-IDLER ARM	1	53	64018-15	BLT-CRG 5/16-18X1	2
16	4170510.7	WLDMT-IDLER BELT GUIDE	1	54	64268-02	NUT-FL NYLON LOCK 5/16-18	2
17	4171864	BELT-48IN DECK	1	55	4171408	LABEL-SPRING LENGTH	1
18	4169716	SPRING-EXTENSION	1	56	64209-03	WSHR-CON SPRING .67 ID	3
19	4152578-01	SPACER-2.0 X .516 X .938	3				
20	4176836	PULLEY IDLER 5.50	1				
21	4174958-2	SPINDLE-HOUSING,MCHND 5.76	3				
22	4174962	BRNG-BALL,PEER 6206	6				
23	64123-340	BLT-HEX,3/8-16X1-1/2 GR8	18				
24	4174959-2	SHAFT-SPINDLE LONG	3				
25	4175082-5	SPINDLE-SPACER,1.767	3				
26	2000572	LABEL-WARNING BLADES	1				
27	64018-34	BLT-CRG 5/16-18 X 1-1/2	1				
28	4128002	CAP-26 X 7 END	1				
29	2721512	ROLLER-5X2.75 CENTERED	4				
30	2720685	SPACER-ROLLER	4				
31	64270-02	BLT-HEX M10-1.5x30	1				
32	4163802-02	SPACER-1.0 X .516 X 1 3/16	1				
33	64229-02	NUT-NYLON LOCK 5/16-18	1				
34	64141-6	NUT-WLF 5/16-18	2				
35	64123-173	BLT-HEX 3/8-16X4-1/2	1				
36	64018-30	BLT-CRG 3/8-16 X 4-1/2	3				
37	4170088	PULLEY-5.25" X 2.5"W	1				

*NOT ILLUSTRATED

52" SIDE DECK ASSEMBLY

BOB-CAT
QUICKCAT

FIGURE 15



52" SIDE DECK ASSEMBLY

BOB-CAT
QUICKCAT

FIGURE 15


ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177049	S-52" DECK W/ LABELS	1	35	64123-173	BLT-HEX 3/8-16X4-1/2	1
2	4174965-2	ASSMBLY-SPNDL,5.76 (INCLUDES ITEMS 21-24)	3	36	64018-30	BLT-CRG 3/8-16 X 4-1/2	3
3	4174432	PULLEY-SPINDLE 52IN	3	37	4170088	PULLEY-5.25IN OD X 2.5IN	1
4	4174961-1	SPINDLE-SPACER 0.63IN	3	38	64123-133	BLT-HEX 5/8-18X3	3
5	112111-02	BLADE 18.00 OFFST HLFT	3	39	64018-33	BLT-CRG 1/2-13 X 4-1/2	1
	112111-02-LE	BLADE 18.00 LAZER EDGE (OPT)		40	4164269	LABEL-WARNING THROWN	1
6	4170021.7	WLDMT-IDLER PIN	1	41	2000577	DECAL, "ROTATING PARTS"	3
7	4163014	SPACER	1	42	4162915	LABEL-DECK SIZE, 52	1
8	4163155	INNER RING	1	43	4116761	LABEL-MADE IN USA	1
9	4171371	S-IDLER ARM ASSY (INCLUDES ITEMS 10-15)	1	44	64018-44	BLT-CRG 3/8-16X1	3
10	521438	GREASE SEAL	1	45	64268-03	NUT-FL NYLON LOCK 3/8-16	25
11	548138	BRG NDL.88 1.12 1.00	1	46	64209-16	WSHR-CON SPRING 1.75	3
12	4128004	BEARING-BALL 10 X 26 X 8	1	47	64123-187	HEX 5/8-18X3-3/4	3
13	85010N	ZERK 1/4-28 STR	1	48	4175081	SPINDLE-SPACER, SLINGER	3
14	64144-40	SNAP RING-26MM INTERNAL	1	49	64158-08	EYE BOLT 5/16-18 X 2.5	1
15	4170610.7	WLDMT-IDLER ARM	1	50	64018-16	BLT CRG 1/2-13 X 5	1
16	4170510.7	WLDMT-IDLER BELT GUIDE	1	51	64268-05	NUT-FL NYLON LOCK 1/2-13	3
17	4170484	BELT-52IN DECK	1	52	4171408	LABEL-SPRING LENGTH	1
18	4169716	SPRING-EXTENSION	1	53	64209-03	WSHR-CON SPRING .67 ID	3
19	4152578-01	SPACER-2.0 X .516 X .938	3				
20	4176836	PULLEY IDLER 5.50	1				
21	4174958-2	SPINDLE-HOUSING,5.76	3				
22	4174962	BRNG-BALL	6				
23	64123-340	BLT-HEX,3/8-16X1-1/2 GR8	18				
24	4174959-2	SPINDLE-SHAFT, 6.26IN	3				
25	4175082-5	SPINDLE-SPACER 1.767	3				
26	2000572	LABEL-WARNING BLADES	1				
27	64018-34	BLT-CRG 5/16-18 X 1-1/2	1				
28	4128002	CAP-26 X 7 END	1				
29	2721512	ROLLER-5X2.75 CENTERED	4				
30	2720685	SPACER-ROLLER	4				
31	64270-02	BLT-HEX M10-1.5x30 ISO	1				
32	4163802-02	SPACER-1.0 X .516 X 1 3/16	1				
33	64229-02	NUT-NYLON LOCK 5/16-18	1				
34	64141-6	NUT-WLF 5/16-18	2				

***NOT ILLUSTRATED**

61" SIDE DECK ASSEMBLY

BOB-CAT
QUICKCAT

FIGURE 16




ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177050	S-61" DECK W/ LABELS	1	42	64123-187	BLT-HEX 5/8-18X3-3/4	3
2	4174965-2	ASSMBLY-SPNDL,CST IRON 5.76 (INCLUDES ITEMS 18, 20, 21,41)	3	43	64209-16	WSHR-CON SPRING .669 X 1.75	3
3	4173961	PULLEY-SPINDLE,61IN	3	44	64123-133	BLT-HEX 5/8-18X3	3
4	4174961-1	SPINDLE-SPACER,BLADE 0.63	3	45	64018-44	BLT-CRG 3/8-16X1	3
5	112111-03	BLADE 21.00 OFFST HLFT	3	46	64270-02	BLT-HEX M10-1.5x30 I CL10.9	1
6	4170021.7	WLDMT-IDLER PIN	1	47	64158-08	EYE BOLT 5/16-18 X 2.5 THD	1
7	4163014	SPACER	1	48	64141-6	NUT-WLF 5/16-18	2
8	4163155	INNER RING	1	49	64229-02	NUT-NYLON LOCK 5/16-18	1
9	4171371	ASSY-IDLER ARM (INCLUDES ITEMS 29-34)	1	50	64018-33	BLT-CRG 1/2-13 X 4-1/2	1
10	4128002	CAP-26 X 7 END	1	51	4171408	LABEL-SPRING LENGTH	1
11	4163802-02	SPACER-1.0 X .516 X 1 3/16	1	52	64018-34	BLT-CRG 5/16-18 X 1-1/2	1
12	4170088	PULLEY-5.25" X 2.5"W	1	53	64268-05	NUT-FL NYLON LOCK 1/2-13	3
13	4170510.7	WLDMT-IDLER BELT GUIDE	1	54	64018-16	BLT CRG 1/2-13 X 5	1
14	4170952	BELT-61IN DECK	1	55	4175081	SPINDLE-SPACER, SLINGER	3
15	4169716	SPRING-EXTENSION	1	56	64209-03	WSHR-CON SPRING .67 ID	3
16	4152578-01	SPACER-2.0 X .516 X .938	3				
17	4176836	PULLEY IDLER 5.50	1				
18	4174958-2	SPINDLE-HOUSING,MCHND 5.76	3				
19	4175082-1	SPINDLE-SPACER,PULLEY .397	3				
20	4174959	SPINDLE-SHAFT	3				
21	4174962	BRNG-BALL	6				
22	64018-30	BLT-CRG 3/8-16 X 4-1/2	4				
23	64123-173	BLT-HEX 3/8-16X4-1/2	1				
24	64123-31	BLT-HEX 1/2-13X3	2				
25	64141-13	NUT-WLF 1/2-13	4				
26	2721512	ROLLER-5X2.75 CENTERED	5				
27	2720685	SPACER-ROLLER	5				
28	4163332	ROLLER, ANTI-SCALP	2				
29	4170610.7	WLDMT-IDLER ARM	1				
30	4128004	BEARING-BALL 10 X 26 X 8	1				
31	548138	BRG NDL.88 1.12 1.00	1				
32	521438	GREASE SEAL	1				
33	64144-40	SNAP RING-26MM INTERNAL	1				
34	85010N	ZERK 1/4-28 STR SLF THRD	1				
35	4164269	LABEL-WARNING THROWN	1				
36	2000577	DECAL, "ROTATING PARTS"	3				
37	4162916	LABEL-DECK SIZE, 61	1				
38	4116761	LABEL-MADE IN USA	1				
39	2000572	LABEL-WARNING BLADES	1				
40	64268-03	NUT--FLNYLON LCK 3/8-16	26				
41	64123-340	BLT-HEX,3/8-16X1-1/2 GR8	18				

48"/52" CHUTE, BAFFLES & EDGES ASSY

BOB-CAT
QUICKCAT

FIGURE 17



48"/52" CHUTE, BAFFLES & EDGES ASSY

BOB-CAT
QUICKCAT


FIGURE 17

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177047	S-CUTTERDECK 48 W/LBLS	1				
	4177049	S-CUTTERDECK 52 W/LBLS	1	36	4176866.7	COVER-BELT, 48 RH	1
					4176868.7	COVER-BELT, 52 RH	1
2	64268-03	NUT-FL NYLON LOCK 3/8-16	10				
3	64268-02	NUT-FL NYLON LOCK 5/16-18	2	37	64268-01	NUT-FL NYLON LOCK 1/4-20	3
4	2188145-02	BEARING-.875ID BRZ	4	38	64018-2	BLT-CRG 1/4-20X3/4	7
5	64018-23	BLT-CRG 3/8-16X3/4 SN	5	39	64229-01	NUT-NYLON LOCK 1/4-20	4
6	64229-03	NUT-NYLON LOCK 3/8-16	8				
7	4174098.7	WLDMT-PULLARM	2				
8	64123-168	BLT-HEX 5/8-11X2-1/2	2				
9	64229-06	NUT-NYLON LOCK 5/8-11	2				
10	4173420.2	BAFFLE-DISCHARGE, 48 / 52	1				
11	64141-2	NUT-WLF 1/4-20	7				
12	64123-114	BLT-HEX 1/4-20X1	7				
13	64123-16	BLT-HEX 3/8-16X1-1/4	2				
14	4166930.2	EXTENSION-48 DECK, LH	1				
	4166479.2	EXTENSION-52 DECK, LH	1				
15	4166929.2	EXTENSION-DECK,48IN RH	1				
	4166478.2	EXTENSION-DECK,52IN RH	1				
16	4165972.7	BAFFLE,-FRONT,CNTR 48	1				
	4165966.7	BAFFLE-FRONT, CNTR 52	1				
17	4176796.7	BAFFLE-FRONT, LH 48	1				
	4176141.7	BAFFLE-FRONT, LH 52	1				
18	4168527.7	BAFFLE-FRONT, RH 48	1				
	4168516.7	BAFFLE-FRONT, RH 52	1				
19	64018-7	BLT-CRG 3/8-16X1-1/4	2				
20	64163-61	WSHR .81X.406X16GA	2				
21	64018-9	BLT-CRG 5/16-18X3/4 G5	2				
22	4172339	PAD-WEAR, TRIM SIDE	1				
23	4173063.7	PLATE-CHUTE	1				
24	4172328	CHUTE-DISCHARGE	1				
25	4169895	WASHER-FRICTION, UHMW	2				
26	4169871	WASHER-BELLVILLE, .382 ID	2				
27	4177410.7	BRKT-CHUTE REAR	1				
28	4177411.7	BRKT-CHUTE FRONT	1				
29	64189-28	BLT-HEX SOC, 3/8-16X3/4	1				
30	64018-44	BLT-CRG 3/8-16X1 SN	10				
31	64151-34	NUT-HEX LOCK, 3/8-16 JAM	2				
32	38524	KNOB-4 PRONG 3/8-16	2				
33	4168515.7	BRKT-BAFFLE MNTG, RH USED ON 52"	1				
34	4168514.7	BRKT-BAFFLE MNTG, TABBED QTY 2 ON 52", QTY 3 ON 48"					
35	4176865.7	COVER-BELT, 48 LH	1				
	4176867.7	COVER-BELT, 52 LH	1				

61" CHUTE, BAFFLES & EDGES ASSY

BOB-CAT
QUICKCAT

FIGURE 18



61" CHUTE, BAFFLES & EDGES ASSY

BOB-CAT
QUICKCAT

FIGURE 18

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	4177050	S-CUTTERDECK 61 W/LBLS	1				
2	64268-03	NUT-FL NYLON LOCK 3/8-16	15				
3	64268-02	NUT-FL NYLON LOCK 5/16-18	2				
4	2188145-02	BEARING-.875ID BRZ	4				
5	64018-23	BLT-CRG 3/8-16X3/4 SN	10				
6	64229-03	NUT-NYLON LOCK 3/8-16	8				
7	4174098.7	WLDMT-PULLARM	2				
8	64123-168	BLT-HEX 5/8-11X2-1/2	2				
9	64229-06	NUT-NYLON LOCK 5/8-11	2				
10	4179173.2	BAFFLE-DISCHARGE, 61	1				
11	64141-2	NUT-WLF 1/4-20	7				
12	64123-114	BLT-HEX 1/4-20X1	7				
13	64123-16	BLT-HEX 3/8-16X1-1/4	2				
14	4166481.2	EXTENSION-61 DECK, LH	1				
15	4172771.2	EXTENSION-DECK, 61IN RH	1				
16	4176065.7	BAFFLE,-FRONT,CNTR 61	1				
17	4176064.7	BAFFLE-FRONT, LH 61	1				
18	4176066.7	BAFFLE-FRONT, RH 61	1				
19	64018-7	BLT-CRG 3/8-16X1-1/4	2				
20	64163-61	WSHR .81X.406X16GA	2				
21	64018-9	BLT-CRG 5/16-18X3/4 G5	2				
22	4172339	PAD-WEAR, TRIM SIDE	1				
23	4173063.7	PLATE-CHUTE	1				
24	4172328	CHUTE-DISCHARGE	1				
25	4169895	WASHER-FRICTION, UHMW	2				
26	4169871	WASHER-BELLVILLE, .382 ID	2				
27	4177410.7	BRKT-CHUTE REAR	1				
28	4177411.7	BRKT-CHUTE FRONT	1				
29	64189-28	BLT-HEX SOC, 3/8-16X3/4	1				
30	64018-44	BLT-CRG 3/8-16X1 SN	10				
31	64151-34	NUT-HEX LOCK, 3/8-16 JAM	2				
32	38524	KNOB-4 PRONG 3/8-16	2				
33	4176869.7	COVER-BELT, 61 LH	1				
34	4176870.7	COVER-BELT, 61 RH	1				

SCHILLER GROUNDS CARE, INC.
ONE BOB-CAT LANE
P.O. BOX 469
JOHNSON CREEK, WI 53038
920-699-2000
www.schillergc.com



©Schiller Grounds Care, Inc. 2010