

INTRODUCTION: This instruction sheet covers the installation of the WB200 Front Weight Bar. Weights are added by using a weight bar attachment to counter balance rear mounted equipment. For tractors equipped with a 3 point hitch, a WB200 Front Weight Bar Kit is recommended.

ASSEMBLY INSTRUCTIONS: (Figure 1)

1. Match slots on weight bar weldment to pegs on tractor hitch frame and secure.
2. Add weights to weight bar.
3. Install security rod and pin.

KIT PARTS LIST

ITEM	PART NO	DESCRIPTION	QTY
1	4166949.7	WLDMT-FRONT WEIGHT BAR	1
2	62-540.7	WEIGHT-50# TRACTOR BALLAST	4
3	4167002	ROD-SECURITY	1
4	64168-1	HAIRPIN-COTTER .120 X 2-3/8	1

FIGURE 1

