



PARTS MANUAL

EstatePro PLUS SERIES

Models:

- 642283 BUNTON EstatePro PLUS-17.5HP 48 SD**
- 642284 BUNTON EstatePro PLUS-18HP 52 SD**
- 642285 BUNTON EstatePro PLUS-25HPI 52 SD**
- 642286 BUNTON EstatePro PLUS-20HP 52 SD**



WARNING: If incorrectly used this machine can cause severe injury. Those who use and maintain this machine should be trained in its proper use, warned of its dangers and should read the entire manual before attempting to set up, operate, adjust or service the machine.



CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Californie Proposition 65
Avertissement

Les échappements des moteurs diesel et certains de leurs composés sont reconnus par l'Etat de Californie pour être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.



AVERTISSEMENT

L'émission du moteur de ce matériel contient des produits chimiques que l'Etat de Californie considère être cancérigènes, provoquer des défauts congénitaux et d'autres dangers en matière de reproduction.

California Advertencia
de la Proposicion 65

El estado de California hace saber que los gases de escape de los motores diesel y algunos de sus componentes producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.



ADVERTENCIA

El estado de California hace saber que los gases de escape de este producto contienen productos químicos que producen cáncer, defectos de nacimiento y otros daños en el proceso de reproducción humana.

ESTATE PRO PLUS

IMPORTANT MESSAGE

Thank you for purchasing this Bunton product. You have purchased a world class mowing product, one of the best designed and built anywhere.

This machine comes with an Operation and Safety Manual. The useful life and good service you receive from this machine depends to a large extent on how well you read and understand these manuals. Treat your machine properly, lubricate and adjust it as instructed, and it will give you many years of reliable service.

Your safe use of this Bunton product is one of our prime design objectives. Many safety features are built in, but we also rely on your good sense and care to achieve accident-free operation. For best protection, study the manual thoroughly. Learn the proper operation of all controls. Observe all safety precautions. Follow all instructions and warnings. Do not remove or defeat any safety features. Make sure those who operate this machine are as well informed and careful in its use as you are.

See a Bunton dealer for any service or parts needed. Bunton service ensures that you continue to receive the best results possible from Bunton's products. You can trust Bunton replacement parts because they are manufactured with the same high precision and quality as the original parts.

Bunton designs and builds its equipment to serve many years in a safe and productive manner. For longest life, use this machine only as directed in the manuals, keep it in good repair and follow safety warnings and instructions. You'll always be glad you did.

Jacobsen, a Textron Company
One Bob Cat Lane
Johnson Creek, WI 53038-0469

TABLE OF CONTENTS	FIGURES	PAGE
SAFETY		2
PART SECTION		3
FRAME-ENGINE/CLUTCH ASSY	FIGURE 1	4, 5
FUEL TANK/BUMPER & CONTROL PANEL	FIGURE 2	6, 7
DECK LIFT ASSEMBLY	FIGURE 3	8, 9
CASTER ASSEMBLY	FIGURE 4	10, 11
KICKPLATE/SEAT ASSEMBLY	FIGURE 5	12, 13
STEERING	FIGURE 6	14, 15
PARKING BRAKE	FIGURE 7	16, 17
WIRE HARNESS	FIGURE 8	18, 19
48" SIDE DISCHARGE	FIGURE 9	20, 21
52" SIDE DISCHARGE	FIGURE 10	22, 23
BELTS-CUTTERDECK	FIGURE 11	24, 25
DECALS-POWERUNIT	FIGURE 12	26, 27

NOTICE !!!

Unauthorized modifications may present **extreme** safety hazards to operators and bystanders and could also result in product damage.

Jacobsen, a Textron Company strongly warns against, rejects and disclaims any modifications, add-on accessories or product alterations that are not designed, developed, tested and approved by Jacobsen Engineering Department. Any Jacobsen product that is altered, modified or changed in any manner not specifically authorized after original manufacture—including the addition of “after-market” accessories or component parts not specifically approved by Jacobsen—will result in the Jacobsen Warranty being voided.

Any and all liability for personal injury and/or property damage caused by any unauthorized modifications, add-on accessories or products not approved by Jacobsen will be considered the responsibility of the individual(s) or company designing and/or making such changes. Jacobsen will vigorously pursue full indemnification and costs from any party responsible for such unauthorized post-manufacture modifications and/or accessories should personal injury and/or property damage result.



This symbol means:
ATTENTION!
BECOME ALERT!

Your safety and the safety of others is involved.

Signal word definitions:

The signal words below are used to identify levels of hazard seriousness. These words appear in this manual and on the safety labels attached to Jacobsen machines. For your safety and the safety of others, read and follow the information given with these signal words and/or the symbol shown above.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.

WARNING


WARNING indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices or property damage.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, **MAY** result in property damage.



MODEL NUMBER: This number appears on sales literature, technical manuals and price lists.


SERIAL NUMBER: This number appears only on your mower. It contains the model number followed consecutively by the serial number. Use this number when ordering parts or seeking warranty information.

PARTS SECTION

FRAME-ENGINE/CLUTCH ASSY

ESTATE PRO PLUS

FIGURE 1



ESTATE PRO PLUS

FRAME-ENGINE/CLUTCH ASSY

FIGURE 1


ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1	50	4128004	BEARING-BALL 10X26X8	2
2	4125862	ROD-PULLARM MOUNT	1	51	64144-40	SNAP RING-26MM INTERNAL	1
3	4125860.7	WLDMT-PULLARM	2	52	4128000	SEAL-16X26X7	1
4	64001-1	NUT-HEX JAM,5/8-18	2	53	2722010	ENG-BRIGGS INTEK 18HP	1
5	2188142-01	ROD END 5/8	2		2722461	AIR FILTER CARTRIDGE	1
6	64140-15	COTTER PIN-1/4-2	1		2722462	FOAM PRE-CLEANER	1
7	64123-114	BOLT-HEX 1/4-20X1	1		2722463	OIL FILTER	1
8	64229-01	LOCKNUT-NYLON 1/4-20	1		2722464	FUEL FILTER	1
9	64152-23	1/4-20X3/8 LG SP SCREW	8	54	4126614	ENGINE-B&S INTEK 17.5HP	1
10	38665	SOLENOID	1		4127247	AIR FILTER	1
11	2722034	MUFFLER	1		4127248	FOAM PRE-CLEANER	1
12	4133020.7	COVER-FAN	2		4127249	FUEL FILTER	1
13	64270-01	BOLT-MET, HEX M10-1.5x30	1	55	4127681	ENG B&S 25HPW/INVERTER	1
14	38304-03	BRG-FLANGED PLASTIC	1		2722461	AIR FILTER CARTRIDGE	1
15	2721331.7	WLDMT-CLUTCH STOP	1		2722462	FOAM PRE-CLEANER	1
16	64229-02	LOCKNUT-NYLON 5/16-18	16		2722463	OIL FILTER	1
17	64164-12	KEY-1/4X1/4X1 SQ END	1		2722464	FUEL FILTER	1
18	64123-54	BOLT, 5/16-18X3/4 HEX	4		(EXHAUST BOLTS SUPPLIED WITH ENGINE)		
19	64163-55	WASHER .328X.75X14 GA	2		(ITEMS 56-61 USED ON 18, 20 & 25 HP ONLY)		
20	64006-06	LOCKWASHER-HEL 7/16	1	56	48024-17A	NIPPLE-PIPE 3/8 X 5	1
21	38219	SPRING-TENSION	1	57	64123-89	BOLT-HEX 1/4-20X3/4	1
22	64123-70	BOLT-HEX 3/8-16X1-1/2	1	58	2722459	SPCR-.375ODX.259IDX.16LG	1
23	4128001	END CAP-24 X 7	1	59	2186147.7	WLDMT-CLUTCH BRACKET	1
24	64123-87	BOLT-HEX 3/8-16X1-3/4	1	60	4132287	PULLEY-ENGINE	1
25	2228016	PULLEY-IDLER PUMP	2	61	64123-78	BOLT-HEX 7/16-20X2-1/2	1
26	64163-31	WASHER, 25/64X1X12	4		(ITEMS 62-67 USED ON 17.5 HP ONLY)		
27	64123-104	BOLT-HEX 5/16-18X2-3/4	4	62	4127558.7	WLDMT-CLUTCH BRKT	1
28	64229-03	LOCKNUT-NYLON 3/8-16	2	63	64123-226	BOLT-HEX, 7/16-20X5	1
29	4132964.7	PLATE-TRANSAXLE	1	64	4132494.7	PULLEY-ENGINE, 17.5 HP	1
30	69051-01	PLUG-PIPE 3/8	1	65	48024-20A	NIPPLE-PIPE 3/8NPTF X 4.0	1
31	2222125.7	BRKT-BATTERY HOLD	1	66	4128580	SPACER-0.375x0.259x0.57	1
32	4132069	BELT-TRANSAXLE	1	67	64123-80	BOLT-HEX 1/4-20X1-1/4	1
33	4133247	ROD-BATTERY CLAMP	2		(INCLUDES ITEM 71)		
34	108055	BATTERY	1	68	4132434	TRANSAXLE, LH	1
35	64123-12	BLT-HEX 5/16-18X2-1/2	8	69	4132435	TRANSAXLE, RH	1
36	810149	BUMPER, RUBBER	2	70	4134496	BREATHER	2
37	64006-01	LOCKWASHER-1/4 HEL	1		(INCLUDES ITEM 71)		
38	2722016	CLUTCH-ELECTRICAL	1	71	4134499	CAP-BREATHER	2
39	64025-02	NUT-HEX 5/16-18	2	72	4134501	PULLEY-TRANSAXLE	2
40	64123-168	BLT-HEX 5/8-11X2-1/2	2		(INCLUDES ITEMS 73 & 74)		
41	64163-73	WSHR-.625IDX1.12ODX.062	4	73	4134502	FAN-TRANSAXLE	2
42	85010N	ZERK, 1/4-28	2	74	4134503	NUT-PULLEY	2
43	64229-06	LOCKNUT, NYLON 5/8-11	2	75	4134504	COG-BRAKE	2
44	64163-03	WSHR-.256IDX.62ODX18GA	1	76	4134505	PAWL-BRAKE	2
45	2690033-01	ELBOW-3/8 PIPE, 90 DEG	1	77*	4134508	FILTER-TRANSAXLE	2
46	64197-005	BLT-TDFM 3/8-16X1-1/4	4				
47	4132433	ASSY-WHEEL, 20X8-10	2				
48	64187-03	WHEEL NUT 1/2-20	8				
49	4133302	S-ASSY-IDLER ARM PUMP	1				
	(INCLUDES ITEMS 50-52)						

* NOT ILLUSTRATED

FUEL TANK/BUMPER & CONTROL PANEL

ESTATE PRO PLUS

FIGURE 2



ESTATE PRO PLUS

FUEL TANK/BUMPER & CONTROL PANEL


FIGURE 2

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	4125836	FUEL TANK	1				
3	4125839	FENDER	1				
4	4134307.7	BUMPER	1				
5	4127004	S-CONTROL PANEL,	1				
6	128010-03	S-COVERED KEY	1				
7	128010-01	S-KEY SWITCH NUT 5/8-32	1				
8	2721505	SWITCH-PTO	1				
9	2308073	CAP-FUEL TANK	1				
10	2188178	SWITCH-RETAINER	1				
11	128010	SWITCH, KEY	1				
12	64152-46	SCREW-SLT HH 10-24X1/2	2				
13	64025-15	NUT-HEX #10-24 KEPS	2				
14	64262-001	BLT-FLG HD 1/4-20 X 1/2	4				
15	64123-15	BOLT-3/8-16X3/4 HEX	8				
16	64006-03	WASHER, 3/8	8				
17	64163-31	WASHER, 25/64X1X12	8				
18	64262-010	BLT-FLG HD 3/8-16 X 3/4	4				
19	09007	HOSE.25X.5 27"	1				
20	38540	VALVE-FUEL W/FILTER	1				
21	48310	BUSHING, FUEL TANK	1				
22	88042N	HOSE CLAMP	2				
23	48228A	CABLE CLIP-INSULATED	1				
24	64152-23	SCREW, 1/4-20X3/8 LG SP	1				
25	118020-14	CONTROL-THROTTLE	1				
		(USED ON 18, 20 & 25 HP MODELS ONLY)					
26	38357-07	CONTROL-THROTTLE	23.50 1				
		(USED ON 17.5HP ONLY)					

DECK LIFT ASSEMBLY

ESTATE PRO PLUS

FIGURE 3



ESTATE PRO PLUS

DECK LIFT ASSEMBLY


FIGURE 3

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	85010N	ZERK, 1/4-28 STR	1				
3	4126355.7	WLDMT-DECKLIFT, FRONT	1				
4	4125855.7	WLDMT-DECKLIFT REAR	1				
5	4109960	WLDMT-DECK LIFT ROD	2				
6	64144-34	SNAP RING.50	1				
7	4126687.7	BRKT-LIFT LINK	1				
8	2188143	GRIP	1				
9	64123-50	BOLT-HEX 3/8-16X1	17				
10	85051	ZERK-1/8 PIPE	4				
11	64229-03	LOCKNUT-NYLON 3/8-16	22				
12	2182356.7	BRACKET-SHAFT HANGER	4				
13	64205-029	BLT-METRIC M12X1.75X40	8				
14	64246-04	NUT-WHIZ M12-1.75	16				
15	2188127	CHAIN-6.35 (.250) 5 LINKS	4				
16	64163-65	WASHER-.890X1.375X18GA	9				
17	64221-04	E-RING.875	5				
18	4133132.7	BRKT-OUTER DECK LIFT	1				
19	2183071-03	SPACER-15.88X10.32X24	2				
20	2720501.7	LEVER-DECK LIFT	1				
21	64168-2	COTTER-HAIRPIN.08X1.19	2				
22	64061-37	ROLL PIN-1/8X1.00	1				
23	64188-53	PIN-CLEVIS 1/2X1.0	1				
24	4132290.7	WLDMT-DECKLIFT LEVER	1				
25	2720544	SPRING-COMPRESSION	1				
26	64123-67	BLT-HEX 3/8-16X2	1				
27	64168-1	COTR-HAIRPIN.120X2-3/8	1				
28	4126611	LABEL-H.O.C. OUTER,	1				
29	2720511.7	WLDMT-LVR STOP LATCH	1				
30	2720517.7	BRKT-INNER DECK LIFT	1				
31	64175-05	PUSHNUT-1/2 DIA	1				
32	64123-82	BOLT-HEX 3/8-16X2-1/2	1				
33	2188141	ASSY, PIN & LANYARD	1				
34	2720743	LBL-ZT200 HT CUT INNER	1				
35	2720503	ROD-LIFT STOP	1				
36	64163-29	WASHER-21/64X1X11GA	2				
37	64123-70	BOLT-HEX 3/8-16X1-1/2	2				

CASTER ASSEMBLY

ESTATE PRO PLUS

FIGURE 4



ESTATE PRO PLUS

CASTER ASSEMBLY


FIGURE 4

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	64163-07	WASHER, 1-1/32X1-3/4X1/4	4				
3	85010N	ZERK, 1/4-28	2				
4	2722443.7	WLDMT-CASTER YOKE	2				
5	64123-212	BOLT-5/8-11X6.00	2				
6	64229-06	LOCKNUT, NYLON 5/8-11	2				
7	64144-24	SNAP RING 1.00 EXT	2				
8	64163-64	WSHR 1.015X1.500X14GA	4				
9	2722230-01	SPANNER-11" WHEEL	2				
10	2722233	WHEEL-11"ASSY	2				
11	2722231	SPACER-END	4				

KICKPLATE/SEAT ASSEMBLY

ESTATE PRO PLUS

FIGURE 5



ESTATE PRO PLUS

KICKPLATE/SEAT ASSEMBLY

FIGURE 5

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	4126406	SEAT	1				
3	4133517.7	PLATE-SEAT	1				
4	4124009	SWITCH-SEAT NO	1				
5	64139-10	BLT-WLF 5/16-18X1-1/4	4				
6	33138-09	PIN-CLEVIS GRVD .38 X 1.31	2				
7	64144-30	SNAP RING .375	2				
8	38371-01	BRG-NYLINER 3/8	2				
9	2720975-07	SPACER-NYLON 3/8"	4				
10	2721861	MAT-FOOT PLATE UPPER	1				
11	48030N	HOUR METER ASSEMBLY	1				
12	64197-015	BLT-TDFM 10-32X1/2	2				
13	2188154	MODULE-DELAY	1				
(ITEMS 14 & 15 NOT USED ON 17.5 HP UNITS)							
14	64025-04	NUT-3/8-24 HEX	1				
15	108009-07	CONTROL-CHOKE, 59	1				
16	4132492	S-FRONT PLATE	1				
17	64262-010	BLT-FLG HD 3/8-16 X 3/4	4				
18	4132446	S-FOOTPLATE	1				
19	4129955	MAT-FOOT PLATE MIDDLE	1				
20	2721859	MAT-FOOT PLATE LOWER	1				
21	64262-011	BOLT-FLG HD 3/8-16X1	4				
22	64229-03	LOCKNUT-NYLON 3/8-16	4				
(ITEMS 23-30 USED ON 25 HP UNITS ONLY)							
23	4132493	S-FRONT PLATE	1				
24	4127677-01	COIL	1				
25	4127677-02	GFCI RECEPTACLE	1				
26	64152-60	SCREW-#6-32 X 1/2	6				
27	2721815	SWITCH-LIGHT	1				
28	4127677	MODULE-POWERLINK	1				
29	64152-27	1/4-20X5/8 LG SP SCREW	2				
30	4127676	MODULE-POWERLINK	1				
31	64152-10	10-24X3/4 MACH SCREW	1				
32	64025-15	NUT-HEX #10-24 KEPS	1				
33	64268-03	NUT-FL NYLON LOCK 3/8-16	2				

FIGURE 6





FIGURE 6

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	4132434	TRANSAXLE, LH	1				
3	4132435	TRANSAXLE, RH	1				
4	4133172	TUBE-SPANNER	1				
5	64123-69	BOLT-5/16-18X1-1/2 HEX	4				
6	4133157	GUIDE-CONTROL LEVER	2				
7	4133156	SPACER-.500X.334X.760	2				
8	4122172.7	LEVER-TRACTION CNTRL	2				
9	64221-05	E-CLIP, .328 ID	1				
10	85010N	ZERK, 1/4-28 STR SF THRD	2				
11	64006-03	LOCKWSHR-HEL 3/8	4				
12	64123-16	BOLT-HEX 3/8-16X1-1/4	4				
13	64229-02	LOCKNUT-NYLON 5/16-18	12				
14	64123-47	BLT-HEX 5/16-18X1-1/4	7				
15	38369-01	ROD END BALL JOINT RH	4				
16	64025-03	NUT-HEX 5/16-24	4				
17	2188140-4	TURNBUCKLE	2				
18	64025-33	NUT-HEX 5/16-24 LH	4				
19	38369-02	ROD END BALL JOINT LH	4				
20	4132022.7	WLDMT-CNTRL BELLCRANK	1				
21	2188140-3	TURNBUCKLE	2				
22	4133130.7	WLDMT-BELL CRANK	1				
23	4127142	BUSHING-CONTROL ARM	8				
24	64221-03	E-CLIP	4				
25	4132189	BAR-HANDLE	2				
26	64229-03	LOCKNUT-NYLON 3/8-16	1				
27	2188144	GRIP, .75ID X 12	2				
28	64123-68	BOLT-HEX 5/16-18X1	1				
29	2721246	DAMPNER	2				
30	64123-205	BOLT-HEX 5/16-24X4	2				
31	2188139	SPRING-COMPRESSION	2				
32	64163-55	WASHER .328X.75X14 GA	4				
33	64163-54	.516X.75X12GA THK WSHR	2				
34	38304-02	BRG, FLGD PLASTIC	2				
35	64237-05	LOCKNUT-NYLON M8-1.25	4				
36	64197-015	BLT-TDFM 10-32X1/2 TORX	4				
37	108208	SWITCH DBL POLE	2				
38	4132028.7	WLDMT-CONTROL, RH	1				
39	4132026.7	WLDMT-CONTROL, LH	1				
40	4132068	ROD-RH CONTROL	1				
41	4132064	WLDMT-BRAKE ARM	1				
42	64229-08	LOCKNUT NYLON 5/16-24	2				
43	64123-130	BOLT-HEX 3/8-16X5-1/2	1				
44	4132492	S-FRONT PLATE	1				
	(USED ON	17.5, 18 & 20 HP UNITS)					
45	4132493	S-FRONT PLATE	1				
	(USED ON	25 HP UNITS)					

PARKING BRAKE

ESTATE PRO PLUS

FIGURE 7



ESTATE PRO PLUS

PARKING BRAKE


FIGURE 7

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4134450	S-FRAME W/LABS, BUNTON	1				
2	4132434	TRANSAXLE, LH	1				
3	4132435	TRANSAXLE, RH	1				
4	4133943	SPRING-COMPRESSION	3				
5	64163-17	WASHER, 25/64X2X11GA	1				
6	33103	SWIVEL	1				
7	64168-2	COTTER-HAIRPIN.08X1.19	8				
8	4132051	ROD-BRAKE	2				
9	4133521	LINK-PARKING BRAKE	2				
10	64163-02	WASHER-.328X.608X11GA	1				
11	4133253	ROD-BYPASS CONTROL	2				
12	4132050	ROD-BRAKE	1				
13	64197-016	BOLT-TDFM 3/8-16X1/2	4				
14	4133536.7	BRKT-BRAKE BEARING	2				
15	4133539	WLDMT-BRAKE SHAFT	1				
16	64229-03	LOCKNUT-NYLON 3/8-16	5				
17	64163-31	WASHER, 25/64X1X12	2				
18	2188156	SWITCH-NONO DBL POLE	1				
19	64197-015	BLT-TDFM 10-32X1/2 TORX	2				
20	2188155	GRIP, 1/4X1X4-1/2	1				
21	4132041.7	ARM-BRAKE	1				
22	64123-89	BOLT-HEX 1/4-20X3/4	1				
23	4127142	BUSHING-CONTROL ARM	6				
24	64221-03	E-CLIP	4				
25	64163-34	WSHR.256/.267X1X11GA	1				
26	64006-01	LOCKWASHER-1/4 HELICAL	1				
27	4132026.7	WLDMT-CONTROL, LH	1				
28	4132064	WLDMT-BRAKE ARM	1				
29	4132492	S-FRONT PLATE (USED ON 17.5, 18 & 20 HP UNITS)	1				
30	4132493	S-FRONT PLATE (USED ON 25 HP UNITS)	1				

WIRE HARNESS

FIGURE 8

ESTATE PRO PLUS



ESTATE PRO PLUS

WIRE HARNESS


FIGURE 8

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4127204	WIRE HARNESS	1				
2	148082-20	FUSE 20 AMP	2				
3	108061-13	CABLE-BATTERY 36 BLK	1				
4	4124009	SWITCH-SEAT NO	1				
5	64141-2	NUT-WLF 1/4-20	1				
6	48030N	HOUR METER ASSY	1				
7	2722227-01	CABLE-BATTERY (INCLUDES ITEMS 17 & 20)	1				
8	128010	SWITCH, KEY	1				
9	2722325	RELAY-40AMP SEALED	3				
10	2188154	MODULE-DELAY	1				
11	2721505	SWITCH-PTO	1				
12	2722016	CLUTCH-ELECTRICAL	1				
13	112386	BOOT,BAT TERM POS	1				
14	108208	SWITCH DBL POLE	2				
15	2188156	SWITCH-NONO DBL POLE	1				
16	38665	SOLENOID	1				
17	2308095	COVER-TERMINAL	3				
18	108061-04	CABLE-BATTERY 20 RED	1				
	(ITEMS 19-24 USED ON 25HP MODEL ONLY)						
19	4127676	MODULE-POWERLINK	1				
20	4127677	MODULE-POWERLINK OUT	1				
	(INCLUDES ITEMS 20 & 21)						
21	4127677-01	COIL	1				
22	4127677-02	GFCI RECEPTACLE	1				
23	4127678	CONNECTOR-SWITCH	1				
24	2721815	SWITCH, RESET	1				

48" SIDE DISCHARGE

ESTATE PRO PLUS

FIGURE 9



ESTATE PRO PLUS

48" SIDE DISCHARGE


FIGURE 9

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4126523	S-48 CUTTERDECK W/LABS	1	42	4120180.7	BAFFLE-48 FRONT RH	1
2	4127852.5	COVER-BELT, 48 LH	1	43	64268-01	LOCKNUT-1/4-20 NYLON	2
3	4127853.5	COVER-BELT, 48 RH	1	44	2188131	SPRING-EXTENSION	2
4	64163-68	WSHR-1.015X1.5X9GA	1	45	38348-01	BEARING-SPINDLE SEALED	6
5	32723.5	CHUTE-DISCHARGE	1	46	2721096	HOUSING-SPINDLE 6 HOLE	3
6	64018-2	BLT-CRG 1/4-20X3/4	2	47	64144-38	SNAP RING	3
7	64229-03	LOCKNUT-NYLON 3/8-16	24	48	38315	NUT-SPINDLE	3
8	64205-029	BLT-MET M12X1.75X40	8	49	2183070-01	SHAFT-SPINDLE LONG	1
9	64246-04	NUT-WHIZ M12-1.75	16			(USED ON 4115849 CENTER SPINDLE ONLY)	
10	2188127	CHAIN-6.35 (.250) 5 LINKS	4				
11	2308140	PULLEY-ENGINE	3	50	2183070-02	SHAFT-SPINDLE	2
12	112111-01	BLADE 16.25 OFFST HLFT	3			(USED ON 4115850 OUTER SPINDLE ONLY)	
13	4120208.7	BAFFLE-DISCHARGE 32-48	1				
14	64262-012	BLT-FLG HD 3/8-16 X 1-1/4	18				
15	4121584.7	WLDMT-IDLER ARM	1				
16	64018-18	BOLT-CARRIAGE 3/8-16X2	2				
17	2302125.7	GUIDE-BELT	1				
18	48393	PULLEY-V IDLER	1				
19	38297	IDLER, 5 OD FLANGED	1				
20	2228034	PULLEY-5.25 DEEP GRV	1				
21	64209-03	SPRING WASHER.67 ID	6				
22	64164-12	KEY-1/4X1/4X1 SQ END	4				
23	128169	PULLEY, IDLER 5.50	1				
24	4115849	S-ASSY SPINDLE, CENTER	1				
		(INCLUDES ITEMS 45-49)					
25	4110580.7	WLDMT-DECK IDLER	1				
26	4115850	S-ASSY SPINDLE OUTER	2				
		(INCLUDES ITEMS 45-48 & 50)					
27	64268-03	NUT-FL NYL LOCK 3/8-16	8				
28	64018-3	BOLT-3/8-16X1 CARRIAGE	1				
29	64006-05	LOCKWSHR-HELICAL 1/2	1				
30	64123-05	BLT-HEX 1/2-20X1-1/2	1				
31	64163-46	WASHER.383/.393X.88X7GA	5				
32	64221-04	E-RING.875	2				
33	64123-138	BLT-HEX 3/8-16X3-3/4	1				
34	4116712	PIN-PIVOT	1				
35	64123-50	BOLT-HEX 3/8-16X1	9				
36	4116661	PIN-PIVOT	1				
37	4118314	SPACER-BLADE 16MM	3				
38	4120175.7	BAFFLE-48 FRONT LH	1				
39	64123-187	BLT-HEX 5/8-18 X 3 3/4	3				
40	64123-208	BLT-HEX 5/8-18X1.5	3				
41	64163-65	WASHER-.890X1.375X18GA	4				

52" SIDE DISCHARGE

ESTATE PRO PLUS

FIGURE 10




ESTATE PRO PLUS

52" SIDE DISCHARGE

FIGURE 10

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4126527	S-52 DECK W/LABS	1	42	4118428.7	BAFFLE-FRONT RH	1
2	2722574.5	COVER-BELT RH	1	43	64268-01	NUT-FL NYL LOCK 1/4-20	2
3	2722575.5	COVER-BELT LH	1	44	2188131	SPRING-EXTENSION	2
4	64018-2	BLT-CRG 1/4-20X3/4	2	45	64163-68	WSHR-1.015X1.5X9GA	1
5	32723.5	CHUTE-DISCHARGE	1	46	38348-01	BEARING-SPINDLE SEALED	6
6	64166-17	BLT-SHLDR 3/8-16X1.12	4	47	2721096	HOUSING-SPINDLE 6 HOLE	3
7	64229-03	LOCKNUT-NYLON 3/8-16	28	48	64144-38	SNAP RING	3
8	64205-029	BLT-MET M12X1.75X40	8	49	38315	NUT-SPINDLE	3
9	64246-04	NUT-WHIZ M12-1.75	16	50	2183070-01	SHAFT-SPINDLE LONG (USED ON 4115849 CENTER SPINDLE ONLY)	1
10	2188127	CHAIN-6.35 (.250) 5 LINKS	4				
11	2308140	PULLEY-ENGINE	3	51	2183070-02	SHAFT-SPINDLE (USED ON 4115850 OUTER SPINDLE ONLY)	2
12	112111-02	BLADE 18.00 OFFST HLFT	3				
13	4115864.7	BAFFLE-DISCHARGE	1				
14	64262-012	BLT-FLG HD 3/8-16 X 1-1/4	18				
15	4121584.7	WLDMT-PTO IDLER	1				
16	64018-18	BOLT-CARRIAGE 3/8-16X2	2				
17	2302125.7	GUIDE-BELT	1				
18	48393	PULLEY-V IDLER	1				
19	38297	IDLER, 5 OD FLANGED	1				
20	2228034	PULLEY-5.25 DEEP GRV	1				
21	64209-03	SPRING WASHER.67 ID	6				
22	64164-12	KEY-1/4X1/4X1 SQ END	4				
23	128169	PULLEY, IDLER 5.50	1				
24	4115849	S-ASSY SPINDLE, CENTER (INCLUDES ITEMS 46-50)	1				
25	4110580.7	WLDMT-IDLER	1				
26	4115850	S-ASSY SPINDLE OUTER (INCLUDES ITEMS 46-49 & 51)	2				
27	64268-03	NUT-FL NYL LOCK 3/8-16	8				
28	64018-3	BOLT-3/8-16X1 CARRIAGE	1				
29	64006-05	LOCKWSHR-HELICAL 1/2	1				
30	64123-05	BLT-HEX 1/2-20X1-1/2	1				
31	64163-46	WASHER.383/.393X.88X7GA	5				
32	64221-04	E-RING.875	2				
33	64123-138	BLT-HEX 3/8-16X3-3/4	1				
34	4116712	PIN-PIVOT	1				
35	64123-50	BOLT-HEX 3/8-16X1	9				
36	4116661	PIN-PIVOT	1				
37	4118314	SPACER-BLADE 16MM	3				
38	4118427.7	BAFFLE-FRONT LH	1				
39	64123-187	BLT-HEX 5/8-18 X 3 3/4	3				
40	64123-208	BLT-HEX 5/8-18X1.5	3				
41	64163-65	WASHER-.890X1.375X18GA	4				

FIGURE 11




**ESTATE PRO
PLUS**

BELTS-CUTTERDECK

FIGURE 11

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	2188176	BELT-CUTTERDECK 52 (USED ON 52" DECK)	1				
2	2720815	BELT-PTO 48	1				
3	128110	BELT-CUTTERDECK (USED ON 48" DECK)	1				

FIGURE 12



ESTATE PRO PLUS

DECALS-POWERUNIT

FIGURE 12

ITM	PART NO.	DESCRIPTION	QTY	ITM	PART NO.	DESCRIPTION	QTY
1	4126803	LABEL-CONTROL PANEL	1				
2	2000570	LABEL-WARN FUEL PICT.	1				
3	340830	DECAL, CAUTION	1				
4	4124264	LABEL-BUNTON DIECUT	1				
5	2000590	LABEL, WARN BATTERY	1				
6	2000701	LABEL - LH TRACTION	1				
7	4133527	LABEL-ESTATE PRO PLUS	2				
8	4126804	LABEL-PARKING BRAKE	1				
9	4126802	LABEL-TIRE PRESSURE	1				
10	4118843	LABEL-WARNING	1				
11	2000696	LABEL - BLADE INSTALL	1				
12	2000572	LABEL-WARNING BLADES	1				
13	2000677	LABEL-DANGER/WARNING	2				
14	4126873	LABEL-KICKPLATE, ESTATE	1				
15	2720743	LABEL-ZT200 HOC INNER	1				
16	2000577	LABEL, WARNING	3				
17	4126611	LABEL-H.O.C. OUTER	1				
18	2000700	LBL - RH TRACTION	1				
(ITEMS 19 & 20 USED ON 25HP ONLY)							
19	4127996	LABEL-POWERLINK	1				
20	4127984	LABEL-WARNING, ELECTR.	1				
21	4128578	LABEL-CHOKE (USED ON 17.5 HP ONLY)	1				
22	4133980	LABEL-MAINTENANCE	2				

World Class Quality, Performance And Support



Equipment from Jacobsen, a Textron company, is built to exacting standards ensured by ISO 9001 and ISO 14001 registration at all our manufacturing locations.

A worldwide dealer network and factory-trained technicians backed by Textron Parts Xpress provide reliable, high-quality product support.



BOB-CAT BROWER BUNTON CUSHMAN RYAN STEINER