


I.S.-KIT ECO PLATE (970404) (970405) (970406) (970426)

4166287 REV B

INTRODUCTION: This instruction sheet covers the installation of the ECO plate to the 48", 52", 61" and 72" cut-terdecks of the ZT, G series mowers.

1. Attach the ECO plate **Item 1**, as shown, using (1) COTTER-HAIRPIN.120X2-3/8 **Item 2**.



ITEM	PART NO.	DESCRIPTION	QTY
1	4166852.7	ECO PLATE 48" (USE ON 48" DECKS ONLY)	1
	4165293.7	ECO PLATE 52" (USE ON 52" DECKS ONLY)	
	4165294.7	ECO PLATE 61" (USE ON 61" DECKS ONLY)	
	4165773.7	ECO PLATE 72" (USED ON 72" DECKS ONLY)	
2	64168-1	COTTER-HAIRPIN.120X2-3/8	1