

## Service Bulletin

Date: November 2, 2012


Bulletin No: JC-019-12

## Product Type: STEINER 440

**Customer Issue:** Roll-over Protective Structure (ROPS) can move back and forth on the frame.

Cause: The 4 mounting bolts to the frame are not tightened properly in assembly.

Action required: Torque all 4 roll bar mounting bolts 64018-11 to 65 - 100 Foot pounds



Products Involved: 75-72010, 75-72011, 75-72012, and 75-72013. 75-72010 serial numbers 75720100070- 75720100217 75-72011 serial numbers 75720110070- 75720110162 75-72012 serial numbers 75720120070- 75720120133 75-72013 serial numbers 75720130070- 75720130138

**Warranty:** You may claim up to .25 hour of labor for units covered under this bulletin. Please file warranty using Service Bulletin Number JC-019-12 with one unit per claim.

If you have any questions, please contact our Customer Service Department at 920-699-2000.

This bulletin is relevant to the departments checked below. Please circulate as appropriate.

